



Qutie


Content

EN	Quick Start Guide -----	1
JP	取扱説明書 -----	6
KR	사용 설명서 -----	11

Product Introduction

EN

Appearance and Components



Packing List



Printer



Lanyard



USB cable



Quick Start Guide

Product Introduction


LED Indicator Status

- Red LED Error Status
 - ON: Error (Paper jam/Paper end/Cover opened)
 - Quick Flash: TPH is over temperature
 - Slow Flash: Low power
- Green LED Basic Status
 - ON: Charging finished/Printer is ready
 - Slow Flash: Charging

Button Operation


- 1 Hold down the power button for a few seconds: Turn on/off the printer
- 2 Press the power button: Position and calibrate the location of thermal label paper and heating line

Paper Loading



1

Place your hands on both sides of the side cover, push upward per the direction shown in the figure to open it.



2

Load the paper as shown in the figure and make sure the thermosensitive layer faces up.



3

Close the side cover and pull some extra paper.

App Download

Scan the QR code to download App.



Connection and Printing

01

Turn on Bluetooth of mobile phone, then open App, select “Qutie” in the device list. Click “Search device” and find “Qutie-XXXX”, click it to connect.



02

Edit the label as need, and then click “Print” after editing.



03


Push the cutter button to manually cut the paper.



Note: App operation shall be subject to the latest version.

Battery Charging


When the battery power is low, the red LED indicator will flash slowly. Please charge it by the exclusive USB cable in time. If you continue printing, it may power off automatically.



Note: The printer can be charged via computer USB port or AC adapter. Please note that the AC adapter is not supplied.

製品の紹介

外観とコンポーネント



ボックス内の目次



プリンター



ストラップ



USBケーブル



取扱説明書

製品の紹介


ランプ状態

- 赤ランプ 異常状態
 - 点灯:異常(紙詰まり/紙切れ/カバーが開いている)
 - 高速点滅:サーマルヘッドが過熱状態です
 - ゆっくり点滅:電池残量が少ない
- 緑ランプ 基本状態
 - 点灯:充電完了/レディー状態
 - ゆっくり点滅:充電中

電源ボタン


- ① 電源ボタンを長押し:オン/オフ
- ② 電源ボタンを短く押し:ラベル用紙の位置を調整する

紙入れ



1

両手をカバーの両側に置きます。図示方向に押して、カバーを開けます。



2

ロール紙を図示方向に置きます。印刷面を上に向けます。



3

カバーを取り付け、紙の一部を引き出します。

Appのダウンロード

QRコードをスキャンしてAppをダウンロード:



接続して印刷

01

Appを開き、「デバイス接続」をクリックして、「Qutie」を選択します。



02

好みに応じてラベルを編集し、編集後に[印刷]をクリックします。



03


カッターボタンを上を押すと、手動で印刷用紙がカットされます。



ヒント:Appの操作は実際に準じてください。

充電

バッテリー残量が少なくなると、指示ランプが点滅します（赤いランプがゆっくり点滅します）。サポートするUSBケーブルを使用して時間内に充電してください。印刷を続行すると、プリンターが自動的にシャットダウンする場合があります。




注：プリンターは、アダプターなしで出荷されます。電源アダプターまたはコンピューターの USB から充電できます。

제품 소개

KR

외관 및 구성



개봉 명세서



프린터



스트랩



USB 케이블



사용 설명서

제품 소개


표시등 상태

- | | | |
|-------|-------|--|
| ● 빨간불 | 이상 상태 | <div style="border-left: 1px dashed black; padding-left: 10px;"><p>점등:이상(종이 JAM/용지 없음/커버 열림)</p><p>빠른 깜박임:TPH 과열</p><p>천천히 깜박임: 배터리 부족</p></div> |
| ● 초록불 | 기본 상태 | <div style="border-left: 1px dashed black; padding-left: 10px;"><p>점등:충전 완료/프린터 준비 완료</p><p>천천히 깜박임:충전 중</p></div> |

버튼 조작


- ① 전원 스위치 길게 누름:전원 켜/끔
- ② 전원 스위치 짧게 누름:감열지와 열선 위치 정렬 및 교정

용지 장착 설명



1

양손을 옆 커버 양쪽에 놓고, 그림과 같이 위로 밀어서 옆 커버를 엽니다.



2

그림과 같이 롤종이를 설치하고 감열지 면이 위 쪽을 향하도록 합니다.



3

종이를 일정량 꺼내고 커버를 닫습니다.

App다운로드

App QR 코드를 스캔하여 앱을 다운로드 하세요.



인쇄 연결

01

먼저 휴대폰에서 블루투스를 켜고 앱을 켜서 모델명 목록에서 'Qutie'를 선택하고 오른쪽 상단 '장치 검색'을 클릭하여 'Qutie-XXXX'를 찾아 연결을 클릭하면 됩니다.



02

필요에 따라 라벨을 편집하고, 편집을 완료한 후 인쇄를 클릭하면 됩니다.



03


커터 버튼을 위로 밀면 종이를 수동으로 자를 수 있습니다.



힌트: App조작은 실제조작에 준해 주시기 바랍니다.

배터리 충전

배터리 전력이 낮으면 표시등이 깜박입니다(빨간불 천천히 깜박임).
USB 케이블로 즉시 충전을 하십시오. 계속 인쇄를 한다면 프린터가
자동으로 꺼질 수 있습니다.



주의: 전원 어댑터나 컴퓨터 USB로 전기를 공급할 수 있으며, 출하 시 전원 어댑터를 제공하지 않습니다.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC' s RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.



Note: All the drawings of product and accessories in the manual are for reference only, please subject to the actual product.

Manufacturer: Xiamen Hanin Electronic Technology Co., Ltd.
Address: No.96, Rongyuan Road, Tong'an District, Xiamen, China 361100
E-mail: support@hpert.com
Web: www.hpert.com