



Quick Guide

Indoor Pan & Tilt Camera


Model: WC-400PHB



1.Package Contents



Indoor Pan & Tilt Camera




Ethernet Cable



Power Adapter



Screw X 2



Mounting plate




Pin Tool




Drywall Anchor X 2


2.Mounting Plate




Drill small holes as displayed 3m apart



Install anchors into drill hole





Align mounting brackets as shown and install screws into anchors




Place the bottom of the camera onto the mounting plate and twist rightwards

3.Set-Up the Camera



* In the event that you forget your password, insert the pin tool into the pin hole and push the reset button



4. Connect with apps

SCAN →

**Learn how
to set up
with apps**



SkylinkCam 1



Orbit



SkylinkNet

5. Warranty/Customer service

This product is guaranteed to be free of defects in materials and workmanship for 1 year from the date of purchase. If this product is defective, call 1-800-304-1187 for repair or replacement parts. Guarantee does not include normal wear and tear or batteries.

If you have any questions, problems or missing parts, please call:
Skylink Customer Support
1-800-304-1187
9:00am – 5:00pm EST, Monday-Friday.
Or e-mail us at support@skylinkhome.com
www.skylinkhome.com