


WIRELESS KEYBOARD
AND MOUSE COMBO
USER MANUAL




After-sales service email:
earlylitcsm001@126.com



EN


SETUP



- 1.Fetch the wireless keyboard and mouse. Take out the USB receiver from the mouse battery compartment.
- 2.Insert one 1.5 V AAA battery into the keyboard according to the positive and negative sign. And turn on the power switch of keyboard.
- 3.Insert one 1.5 V AA battery into the mouse according to the positive and negative sign. And turn on the power switch of mouse.
- 4.Plug the USB receiver into the USB port of your computer.
- 5.The mouse and keyboard are ready to work after the driver is installed automatically on the computer.

EN

INDEPENDENT MULTIMEDIA KEYS



FEATURES

- 1.The mouse and keyboard share a common receiver. And the receiver is in the battery compartment at the bottom of the mouse.
- 2.Adjustable mouse DPI levels: 800-1200-1600 (default setting is 1200).
- 3.It has automatic Sleep mode and Wake up mode. When the combo hasn't been used for 8 min, it will enter sleep mode. Press any button to wake up the combo. If it will be unused for a long time, turn off the power switch to save power.
- 4.Compatabilities: Windows XP / VISTA / 7 / 8 / 10; Mac (Functions of combination keys are not available).

CONSIDERATIONS

- 1.Use 1.5 V AAA or AA battery only. To prevent from damage to internal elements, avoid using excessive-voltage batteries. If the product will be unused for a long time, take out the battery to prevent from corrosion.
- 2.The product adopts the 2.4 GHz wireless transmission with a 10-meter transmission distance. The distance may be shortened for big obstructions and low battery.
- 3.For the first use, the product may fail to work (connection error etc.) for it has been unused for a long time. Try pairing again.

SOLUTION TO CONNECTION FAILURES

Keyboard

- 1.Take out the battery from the keyboard and the receiver from the computer.
- 2.Reinstall the battery into the keyboard, and plug the receiver into the USB port of the computer.
- 3.Turn on the power switch of the keyboard, which should be within 20cm away from the receiver. Press and hold “Esc” and “K” keys together to pair again.

Mouse

- 1.Take out the battery from the mouse and the receiver from the computer.
- 2.Reinstall the battery into the mouse, and plug the receiver into the USB port of the computer.
- 3.Turn on the power switch of the mouse, which should be within 20cm away from the receiver. Press and hold the Right button and Scroll button together to pair again.

Note: If the above solution doesn't help, repeat the above procedures to pair again. If it still cannot work, please contact our service team to work for you. (earlylitcsm001@126.com)

SOLUTION TO PROBLEMS OF WAKING
COMPUTER FROM SLEEP MODE BY KEYBOARD

- Please verify that your device is allowed to wake the computer by following steps :
1. Open the Keyboard control panel.
 - A: In Windows Vista or Windows 7 and later versions , Click Start, type keyboard in the Start Search box, and then click Keyboard or Microsoft Keyboard in the Programs list.
 - B: In Windows XP and earlier versions, click Start, click Run, type Control keyboard, and then click OK.
 2. Click the Hardware tab, and then click Properties.
 - 3.Click the Change Settings button (Note: This step requires Administrator access).
 4. Click the Power Management tab, and then verify that the Allow this device to wake the computer is enabled.
 5. Click OK, and then click OK again.

SOLUTION TO PROBLEMS OF WAKING
COMPUTER FROM SLEEP MODE BY MOUSE

PLEASE REFER TO ABOVE INSTRUCTION FOR KEYBOARD

More Methods for Troubleshoot problems waking computer from sleep mode , please refer to :
<https://support.microsoft.com/en-us/topic/troubleshoot-problems-waking-computer-from-sleep-mode-6cf5b22f-5111-92c3-4a28-eec6e6ff908e>

CORRCT DISPOSAL OF THIS PRODUCT

- (Waste Electrical& Electronic Equipment)
- This Marking shown on the product or its literature, indicate that it should not be disposed with other household wastes at the end of its working life.
- To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.
- Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.
- Business users should contact their supplier and check the terms and conditions of the purchase contact. This product should not be mixed with other commercial wastes for disposal.

FCC STATEMENT

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RADIATION EXPOSURE STATEMENT

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.