

怎样使用

How to use

- 1.开机: 向上滑动开关键开机;
- 2.蓝牙配对: 指示灯快闪4秒进入 配对状态,配对状态指示灯闪烁, 使用手机搜索 "Selfie" 来匹配, 配对成功后指示灯熄灭;
- 3.拍照: 自拍器与手机处于连接状 态时,短按拍照键,指示灯闪烁:
- 4.无配对: 开机后, 在无配对连接 状态下,无操作5分钟自动关机;
- 5.配对: 在自拍器与手机处于连接 状态时,10分钟无操作将进入休 眠状态,再过10分钟无操作自动 关机;
- 6.关机: 开机及休眠状态下,向下 滑动开关键关机,指示灯闪烁后 熄灭。

按键功能

取出自拍器并连接手机后使用





关机

拍照键 单击: 拍照/录视频



夹手机

取出自拍器

先拉出杆子再向上滑动即可取出 手柄底部位置拨开即可打开





可调整多种角度

怎样打开三脚架

用手机一端顶推动夹子向上即可一可调整角度拍摄



How to open a tripod



自由伸缩

加长稳固的杆身可自由伸缩





规格

- ·材料:ABS+不锈钢
- · 折叠长度:210mm
- · 总长度:1130mm
- ·尺寸:210x55x35mm ·产品重量:200g
- ·电池:CR1632(可更换)
- (电池不得暴露在诸如日照、火烤或类似过热环境中)

○提醒

自拍杆兼容Android4.4以上 和iphone的ios5.0以上 (Android设备:如果你在相机 选项下改变了你的"音量键功 能",一定要把它改成默认,或 者"拍照",让自拍杆正常工作)

感谢您的支持!

FC (C O RoHS E

2. Bluetooth pairing: The indicator light flashes quickly for 4s to enter the pairing state, the pairing status indicator flashes, use the mobile phone to search for

1. Turn on: Slide the power key up to power

- 3. Taking pictures: When the remote control and the phone are connected, short press the camera button and the indicator light
- no pairing connection, it will automatically shut down if there is no operation for 5 mins.
- connected to the phone, it will enter the sleep state without any operation for 10mins, and it will automatically shut down after another 10 mins without any operation.
- 6. Turn off: In the power-on and hibernation and the indicator light flashes and then turns off.

the phone.



Take out the remote

Use after taking out the Selfie and connecting Pull the rod out first, then slide it up to remove. The bottom of the handle can be opened to



Clip phone





open the tripod.





Adjust various angles Adjust various angles to shoot.





Extendable

Extended and stable pole can be extended



Specification

Main Material:Stainless steel+ABS

Folded Length: 210mm

Extended Length: 1130mm

Product Reference : 210x55x35mm

• Product Weight: 200g

 Remote control battery : CR1632 (Batteries must not be exposed to sunlight, fire or similar

REMIND

The selfie stick is compatible with Android4.4 and above & iOS 5.0 and above. (Android device: If you change your volumekey function on the camera, be sure to change it to the default value. Or take a picture and let the selfie stick to work normally) Thank you for your support!

F© (€ © RoHS 🖺

Stainless Steel (1)-**Selfie Stick** Photo o-

User Manual

key Compatible

☑ios ☑ Android

"Selfie" to match, and the indicator light turns off after successful pairing.

will flash. 4. No pairing: After power on, in the state of

- 5. Pairing: When the remote control is
- state, slide the switch down to power off,

Key Function



Use one end of the phone to push the clip



Power off

click: Take pictures/video



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.

