

# Srhythm

Find the rhythm of your soul



**NiceComfort 45 (NC45)**

User Manual



# User Manual

## Safety instructions

### Hearing safety:

- 1.Please don't use the headphone during charging for your safety.
- 2.DON'T use the headphones for any other purpose while driving.
- 3.Please use cautiously and stop using headphone in dangerous situation.
- 4.Please do not listen for a long time at high volume to avoid hearing damage.
- 5.For your safety,please do not turn the volume too high while running outside to ensure that you can hear sound in your surroundings.
- 6.Clean only with a dry cloth.


### Operation Safety:

- 1.Use original or certified cables for charging and voltage within 6.3V.Power will be cut off and start protection mode when the voltage exceed 6.3V and within 36V.Headphone will be broken when the voltage over 36V.
- 2.Keep away from children to avoid danger from improper use.
- 3.Headphones can't be charged or turned on in the extreme temperature. Please use headphones within the operating temperature range: 32° F (0°C) – 113° F (45°C).
- 4.Do not submerge headphone in the water.
- 5.Do not use corrosive cleaner/oil to clean headphone.
- 6.Turn off headphone Bluetooth and ANC function to save power when you do not use headphone.


## What's in the Box




NC45 Headphone\*1




Quick Start Guide\*1



Portable Carry Case\*1




Audio Cable \*1




Type-C  
Charging Cable \*1

## At a Glance



ANC/Power ON/OFF  
Button



Microphone

Charging Port

LED Indicator Light

Volume Up/Next Song

Play/Pause Button

Volume Down/Previous Song

## How to Use

### Use ANC/Transparency Function



Click the ANC/ Power ON/ OFF Button to switch between ANC mode, Transparency mode, and Normal Mode after powering on.

### Use Bluetooth Function



3S

Power ON



5S

Power OFF



x1

Volume up



2S

Next Track



x1

Play/Pause Music; Answer/End Call



x2

Activate Voice Assistant/Reject Call



x1

Volume down



2S

Previous Track



+ 5S

Delete Pairing

(In Pairing Mode)

## Function Details

### Easy Pairing

1. Hold the ANC/Power ON/OFF Button for 3–5 seconds to turn headphone Bluetooth on, then enter pairing mode.(the LED indicator light will be blue and red flashing quickly.)
2. Keep headphone and your mobile phone as close as possible during pairing process.
3. Turn on your mobile phone Bluetooth. Search for headphone Bluetooth signal on mobile phone and click “Srhythm NC45” to pair.(the LED indicator light will be blue flashing slowly after pairing successfully.)
4. If you are asked for a password/PIN code during pairing procedure,please enter "0000" (four zeros).

### Pair to the Second Bluetooth Device

Step 1: Pair NC45 with First device via Bluetooth successfully and then turn off the First device's Bluetooth.

Step 2: Pair NC45 with the Second device via Bluetooth.

Step 3: Turn on Bluetooth of the first device and pair it with headphone again.

Now both of your devices are paired with NC45 for easy switching.

## Active Noise Cancelling (ANC) / Transparency Mode

Press the ANC/Power ON/OFF Button to switch between ANC mode, Transparency mode, and Normal mode.


## Wired Mode

Headphone support AUX input for wired external audio source connection. Simply turn headphone Bluetooth off and plug in the audio cable.


1. The ANC mode, Transparency mode, and Buttons Control work in both wired and Bluetooth mode
2. The microphone CAN NOT work in wired mode.
3. Please note Bluetooth cannot be turned on in wired mode.

## Voice Dialing


Press the Play/Pause Button 2 times to activate voice dialing function (compatible with iPhone Siri and selected Android voice dialing software)




## Portable and Adjustable



90° inward rotation





85° inward folding



Adjustable Headband

## If your headphone has no sound or the microphone is not working

Please make sure that the headphone is connected before starting software



## Headphone Specification

### LED Indicator Light

- ● Pairing: Blue and red lights flash alternately
- Paired: Blue light slowly flashes
- Playing: Blue light slowly flashes
- Charging: Red light turns on
- ● Full Charge: Blue light turns on
- Battery Low: Red light slowly flashes with voice prompt
- ANC ON: Green light turns on
- Transparency mode: Green light turns on
- ANC OFF: Green light turns off

\* Please kindly note that perhaps sometimes these LED indicator light color will be mixed to become other colors(pink,purple,etc..) occasionally.

## Technical Specification


- Product name: Srhythm NC45
- Battery capacity: 600mAh
- Input: 5V/1A
- Chip: JL7018F
- Charging time: About 2.5 hours
- Bluetooth version: V5.3
- Use time (ANC OFF): 40 hours
- Use time (ANC ON): 33 hours
- Bluetooth profile: A2DP, AVRCP, HSP, HFP
- Bluetooth range: 15m/50ft
- Waterproof rating: IPX4
- Net weight: 271g/0.59lb
- Impedance: 32 Ω
- Driver diameter: Φ40mm
- Frequency response: 20—20KHz

## Charging

Use the included Type-C charging cable to connect to headphone Charging Port. Connect the other end of charging cable to a computer USB port or USB wall charger under 6.3V voltage. Turn off headphone Bluetooth function before charging.

### NOTE:

1. Please don't use the headphone during charging for your safety.
2. Ambient temperature exceeds the charging temperature range of 32°F (0°C) – 113°F (45°C)



If any issues, here tips for you:

1. Please full charge your headphone with original USB-A to USB-C charging cable and 5–10W power wall charger (don't use fast charger).
2. Delete Pairing: Hold “Volume Up” and “Volume Down” Buttons simultaneously for 5 seconds in pairing mode.

## Q&A

### 1. Q: Why can't headphone pair with my mobile phone?

A: Please check if your headphone is in pairing mode or re-connection mode, check if Bluetooth search function of your Bluetooth device is turned on, if all done, then go to Bluetooth menu of your Bluetooth device, delete/ignore the headphone Bluetooth pairing name "Srhythm NC45". After that, you can try to reconnect Bluetooth according to above "Easy Pairing" steps.

### 2. Q: Why can't headphone turn on?

A: Please double check the battery status of your headphone.

### 3. Q: Can I replace battery in the headphone?

A: No, you can not. Headphone uses a built-in non-detachable Li-Polymer battery that can't be replaced.

### 4. Q: Can I use headphone while driving?

A: For your safety, we strongly recommend that you do not use headphone while driving to avoid distraction.

### 5. Q: Why does headphone sometimes disconnects with Bluetooth device within 10 meters?

A: Please check if there are any metal materials or obstacles within a relatively close range or your surroundings that perhaps interfering with Bluetooth connection. This may happen because Bluetooth is a radio technology which is sensitive to objects between headphone and other devices. Delete the Bluetooth pairing name on your ALL devices (it will toggle between your connected devices due to multi-point connection), restart it. then reconnect it.

### 6. Q: Why can't I hear any sound from my computer or mobile phone?

A: Please check if output channel of your computer supports A2DP profile. Also check the volume settings on your headphone and computer/mobile phone.

### 7. Q: Why am I unable to use headphone to control the volume of a track playing on an APP on my mobile phone?

A: Due to configurations of different application software, headphone may not be completely compatible with some APPs.

### 8. Q: What do I do if Bluetooth can not close or open?

A: Please reset Bluetooth function of headphone by inserting an audio cable into headphone audio port, then removing it. Before re-connecting, kindly remember to delete/ignore headphone Bluetooth pairing name "Srhythm NC45" on your mobile phone.

### 9. Q: Why does Bluetooth turn off when I connect an audio cable?

A: This is one of our special features. When users insert an audio cable into headphone audio port, all Bluetooth feature buttons stop working and Bluetooth turns off. But, Bluetooth will be available again when audio cable is moved.

### 10. Q: Why does audio quality become poor on Windows PC?

A: Some customers have mentioned poor audio quality on Windows PC. Please note that there are "Headset" and "Headphone" modes you can toggle by changing your output device. Selecting "Headphone Mode" will drastically improve the audio quality. "Headset Mode" is designed for highly compressed VOIP calls, etc. That's not the fault of headphone product, that's just the limitation of that protocol. If you are in "Headphone Mode", the audio quality is fantastic.



## FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

## IMPORTANT NOTE:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with distance  $<5\text{mm}$  between the radiator & your body.

## ISED/C warning

This device complies with Innovation, Science, and Economic Development Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions:

(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device is compliance with RF exposure guidelines, users can obtain Canadian information on RF exposure and compliance. The distance from body to use the device is  $<5\text{mm}$ .

Le présent appareil est conforme

Après examen de ce matériel aux conformité ou aux limites d'intensité de champ RF, les utilisateurs peuvent sur l'exposition aux radiofréquences et la conformité and compliance d'acquérir les informations correspondantes. La distance minimale du corps à utiliser le dispositif est de 5mm.