


Quick Start Guide

Α

Getting to Know your Tower Fan

- A. Control Panel/Display
- B. Body
- C. Support Base Front
- D. Support Base Rear
- E. Exhaust Grille
- F. EZ Grip Carry Handle
- G. CarbonX Filter
- H. Filter Frame
- I. Air Intake Grille
- J. Safety ScrewK. Remote Control
- L. Remote Control Storage



Easy 1-2-3 Assembly



C- Support Base Front

Align the slots on part D with tabs on part C. Snap Together.



Lay product down on a flat surface. Attach base to the body, using alignment pin as a reference.



Twist until base clicks into place.

How To Use Your Tower Fan

Controls

Power Button - Press to Turn Fan ON/OFF.

Oscillation Button - Press to START and STOP Oscillation.

Timer Button - Set timer up to 12 hours. Continue pressing the button until desired time setting is reached.

Fan Speed Button - Set speed from 1-6. Continue pressing the button until desired speed is reached. Remote has (+) (-) button which will allow you to increase and decrease speed.

Mode Button - You can choose between Night, Auto, Natural, Custom Mode.

Screen Snooze Button - Press to turn OFF your display.






Easy Filter Installation Guide

Filter Placement / Replacement Instructions

Pre-installation note: it is recommended that the fan is laid down on a flat surface while placing orreplacing your fan filter.



Place the filter inside of the air intake grille.

Install the Filter Frame to the air intake grille by aligning the arrows on the top of each part and snapping the filter tabs into the air intake grille.

Reattach the air intake grille to the rear of the body of the fan. Align the tabs as shown above.

Reinstall the safety screw on the back.