

7072-2BK
OPERATIONS MANUAL

4MODERN
HOME



Where to Place Your Outdoor Wall Lights

If you have one light next to your entryway or garage door, then it should be 1/3 of the height of the door. If you will be placing one light on each side of the door, then the lights should be 1/4 of the height of the door. To do this, measure from the floor to the top of your door, then divide by 4 for two lights or 3 for one light. For example, if your door is 80" tall, divide by 4, and buy two lights that are each 20" tall. The lights should also be placed 66" from the floor or ground to properly illuminate the lock and handle. Lights should also be placed 6" from the edge of the door. If you choose to have only one light, make sure it is placed on the side of the door closest to the door handle.

What should I do if the glass lampshade I received is cracked or broken?

We understand that receiving a damaged product can be disappointing. If you find that your glass lampshade is cracked, broken, or otherwise not in perfect condition, please contact us immediately. Our customer service team is dedicated to providing you with the best possible solution and ensuring your satisfaction.

1.Does it feature a dusk-to-dawn sensor?

Absolutely, it does! This sleek exterior light fixture boasts an intelligent dusk-to-dawn sensor that seamlessly transitions from off to on as nightfall approaches, automatically adjusting to ambient light levels below 20 LUX. And in the morning, when brightness exceeds 90 LUX, it turns off, saving you energy and eliminating the need for manual operation.

2.What could be the reason if the lamp does not turn on during installation?

If you find that the lamp remains off during installation, it's most likely due to the dusk-to-dawn sensor's natural deactivation during daylight hours. To verify the lamp's functionality, simply cover the sensor with your hand or a cloth after turning on the power switch. If the lamp illuminates, this confirms that the lamp is working as intended and the issue is related to the sensor's automatic day/night cycle.

3.What if I do not need the dusk-to-dawn functionality?

No worries! This fixture comes thoughtfully designed with a convenient rubber cap that allows you to easily disable the dusk-to-dawn feature. Simply slide the cap over the sensor whenever you prefer manual control over the lamp's operation.

4.What should I do if the glass lampshade I received is cracked or broken?

We understand that receiving a damaged product can be disappointing. If you find that your glass lampshade is cracked, broken, or otherwise not in perfect condition, please contact us immediately.

Code	Part Description	QTY
A	Junction box	0
B	Mounting bracket	1
C	Mounting screws1	2
D	Wire caps	3
E	Mounting screws2	4
F	Photoelectric switch	1
G	Mounting screws3	4
H	Lamp body	1
I	Light bulb	0

Installation steps for 7072-2BK:

Step 1: Unscrew screw G from the lamp body and remove lamp holder H;

Step 2: Remove screw E from the lamp body and remove hanging plate B;

Step 3: Use screw C to lock hanging board B onto junction box A;

Step 4: Use terminal D to light up the car body in black,

white, and black respectively. Connect the grounding wire and input wire separately;

Step 5: Use screw E to lock the lamp body onto hanging plate B;

Step 6: Move the knob of bulb I onto the lamp body;

Step 7: Use screw G to lock the lamp body H onto the

lamp body;

Step 8: Use screw E to lock the lamp body onto hanging plate B;

Step 9: Move the knob of bulb I onto the lamp body;

Step 10: Use screw G to lock the lamp body H onto the

lamp body;

Step 11: Use screw G to lock the lamp body H onto the

installation is complete

