


# Smart Projector



HY310

※Quick Installation Guide※


## Attention

Please read this manual carefully before use and keep it for future reference.


- 1.The projector is non dustproof or waterproof.
- 2.In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
- 3.Please use the original power adapter. The projector should work under specified rated power supply.
- 4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
- 5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
- 6.Regularly clean projector vents, or dust may cause cooling malfunction.
- 7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
- 8.Please handle with care during daily use.
- 9.Please cut off the power if the projector is out of use for long time.
- 10.Non-professionals are forbidden to disassemble the projector for testing and maintenance.

## Structure description

This manual is for reference only. It is subject to change without prior notice. Hotack reserves the right of final interpretation.




## Air Remote



### Calibration of the flying squirrel micro-drift:


After the remote control is connected to the projector, simultaneously press and hold the "OK" and "HOME" buttons on the remote control for 2 seconds. At this time, the indicator light will stay on. Then place the remote control flat on the desktop. After keeping it still for 5 seconds, the light will go off, and the flying squirrel will be successfully calibrated.

## remote controller pairing




Note: the matching interface of the remote control, Press "Voice input" button to bring up the matching guide.

## Select your Language




## App Store

In the App Store, applications can be installed with one click, and they can be used directly after installation. Our company also brings the applications to the market, enabling users to obtain and use them easily and conveniently.




## Settings

Enter to Projection settings, Network settings, Bluetooth, Application Management, Language, Date and time, Other Setting, System information.



## Projection Setting

Setting - Projector setting, enter to setup projection mode, Display settings, Installation mode, Digital scaling, Auto Trapezoidal Correction, Auto Focus, Manual trapezoidal.




## Networking Setting

Settings - Networking Setting - WIFI setting, WIFI "ON", select objective WIFI ID and input password to connect internet.




## Language Setting

Settings - Language Setting, enter to setup language and select input method.




## Date And Time Setting

Setting - Date And Time Setting, enter to Date, Time and Use 24-hour format.




## Other Setting

Setting - Other Setting, enter to get Button sound, Screen saver, Timed shutdown and Restore factory settings.




## Screen saver

Setting - Other Setting - Screen saver, Screen saver time setting (The projection will enter screensaver mode at the set time without any operation or playback), screensaver mode can be released by pressing the power button.



## System information

Setting - System information, enter to UI version, Resolution, Running memory and Storage space.




## Safety instructions

- Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.
- Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.
- Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations), etc. Strong ambient light (avoid direct sunlight), etc.
- Do not cover projector vents.
- Please use the original power adapter.
- Keep adequate ventilation and make sure vents are not covered to avoid projector overheating
- When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.
- Do not bend or drag the power cord.
- Do not put power cord under projector or any heavy objects.
- Do not cover other soft materials on power cord.
- Do not heat the power cord.
- Avoid touching power adaptor with wet hands.

## Wireless Screen

Ensure that Android devices(phone,pad,ect)are in the same local wireless LAN with these devices

Operations on Devices:  
Home Screen→My Apps→ScreenCast→Open ScreenCast service  
→Turn on the phone mirroring→Connection.



## Disclaim

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Please keep your device properly. We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims.

This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.



### Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes. Kids should use the projector under the supervision of adults.

Thanks for purchasing! Need help?  
Please send email inclose item name to our BrandSupport Team (support@magcubic.com) in order to get better experience, promptly and further assistance