



VISIT US ONLINE:
Have a question?
Need service or repair?
Want to leave a comment?
PyleUSA.com/ContactUs

PYLE

Questions? Issues?

We are here to help!

Phone: (1) 718-535-1800

Email: support@pyleusa.com

PYLE
PyleUSA.com



PPHP854B

8" Wireless BT Portable PA Speaker

Portable PA & Karaoke Party Audio Speaker
with Built-in Rechargeable Battery, Flashing Party Lights,
MP3/USB/ FM Radio (300 Watt MAX)

User Manual

WARNING



1. **DO NOT** place objects on top of the device, as objects may scratch the device.



2. **DO NOT** expose the device to dirty or dusty environments.



3. **DO NOT** insert any foreign objects into the device.



4. **DO NOT** expose the device to strong magnetic or electrical field.



5. **DO NOT** use the device in the rain



6. Please check with your Local Authority or retailer for proper disposal of electronic products.




7. **DO NOT** disassemble the device. Only a certified service technician should perform repair.



8. The device has apertures to disperse heat. **DO NOT** block the device ventilation, the device may become hot and malfunction as a result.

Illegal operation may cause personal injury, which could be fatal and may cause damage to property.

FRONT PANEL FUNCTIONS



1. Master volume control
2. Charge LED indicator
3. DC 5V input jack
4. Short press to choose input signal, press and hold to turn ON/OFF light
5. Next/select saved radio station.
6. Play/Pause/TWS function/In FM mode, press and hold to search radio station automatically and save.
7. Previous/select saved radio station
8. AUX input jack
9. USB input jack
10. Microphone input jack
11. Display screen

REMOTE CONTROL FUNCTIONS

1. **Power:** Used to turn on and off the MP3 player power

2. **MODE:** Used to switch the AUX/USB/Wireless BT/Radio

3. Mute button

4. Play/Pause/Press and hold for TWS/
In FM mode, press and hold to search radio station automatically and save

5. Next song/In FM mode, short press to select saved radio station

6. Previous song /In FM mode, short press to select saved radio station

7. EQ solution


8. Increase volume

9. Choose song number directly/
In FM mode, choose FM Frequency directly

10. Choose USB or SD signal directly
(Only suitable for models with USB & SD both)

11. Decrease volume

12. Repeat song



TWS FUNCTION

For increase sound effect, our unit provides TWS function as follows:

- Step-1:** Turn ON BT mode on your device and connect the machine.
- Step-2:** Press and hold each control board “TWS” button more than 3's, and you will see "ON" on display, unit will start to connect the other unit automatically, now you can enjoy stereo sound, and adjusting one unit volume will affect the other unit.

Remark:

1. After connection, press and hold again one of control board "TWS" button more than 3's, you will see "OFF" on display, unit's TWS disconnection.

TROUBLESHOOTING

Fault	Possible Cause	Solution
No sound	1. No input sound source. 2. Volume is too low.	1. Use a better music signal. 2. Adjust volume.
Distortion of sound	1. Volume too high. 2. Speaker may be damaged	1. Turn down the volume. 2. If speaker is damaged, repair or replace it.
Karaoke does not work	1. Microphone plug is not fully inserted. 2. Microphone switch is not on. 3. Microphone volume knob is at the lowest position.	1. Plug microphone properly into the socket. 2. Turn on microphone switch. 3. Adjust microphone volume properly.
MP3 does not play	1. The audio format in the U disc is incorrect. 2. Improper operation has caused a process disorder. 3. USB disc is disconnected.	1. Convert audio format into Mp3 format. 2. Reboot the machine. 3. Insert USB disc properly.

Features:

- True Wireless Stereo System
- Portable Speaker System
- High-Powered PA Loudspeaker Style
- Wireless BT Music Streaming Ability
- Multi-Color Flashing LED Party Lights
- Built-in Rechargeable Battery
- FM Radio with Digital LED Display
- Connect & Stream Audio from External Devices
- Aux (3.5mm) Input Connector Jack
- USB Flash Memory Reader
- 6.5mm Microphone input
- Battery Level LED Indicator Lights
- Rugged & Durable Molded Cabinet Design
- Convenient Extendable Carry Handle
- For Indoor / Outdoor Use

Wireless BT Streaming:

- Built-in BT for Wireless Music Streaming
- Simple & Hassle-Free Pairing
- Works with All of Today's Latest Devices
- Smartphones, Tablets, Laptops, Computers, etc.
- Wireless BT Version: 4.2
- Wireless BT Network Name: 'PYLEUSA'
- Wireless Range: Up to 32' ft.

What's in the Box:

- PA Speaker System
- Remote Control
- Power Adapter
- Straps

Technical Specs:

- Material: Polypropylene (PP)
- Max Power Output: 300 Watt Max
- Sound System: 8" -inch Subwoofer
- Impedance: 3.0 Ohm
- Frequency Response: 50Hz-12KHz
- USB Interface Type: 2.0
- Digital Audio File Support: MP3
- Maximum USB Flash Support: 32GB
- Remote Control Battery Operated, 1 Piece Button Cell Battery CR-2025 (Included)
- Battery Life: Up to 2 Hours (Charge Time: Approx. 4 Hours)
- Rechargeable Battery: 3.7V, 1800mAh – 6.66 Wh
- Power Supply: 120/240V, Switchable (5V/2A Power Adapter)
- Dimensions (L x W x H): 9.9" x 6.5" x 11.8" -inches



This product can expose you to a chemical or group of chemicals, which may include "Lead and lead compounds" which is known in the state of California to cause cancer, birth defects, or other reproductive harm. For more info, go to <https://www.p65warnings.ca.gov/>.