



IMPORTANT - RETAIN FOR FUTURE REFERENCE - READ CAREFULLY

Follow these warnings and the assembly instructions carefully. Keep for future reference.

This cot converts into a cot bed suitable for children from about 15 months up to 20 kg weight.

Follow these warnings and the assembly instructions carefully. Keep for future reference.

Minimum recommended mattress size for this cot/cot bed is 120 cm x 60 cm and with a thickness not exceeding 12 cm. See marking on the cot.



WARNING

- Do not use the cot if any part is broken, torn or missing. Contact your local IKEA store for replacement parts. Do not substitute parts.
- Do not leave anything in the cot or place the cot close to another product, which could provide a foothold or present a danger of suffocation or strangulation, e.g. strings, blind/curtain cords, etc.
- Do not use more than one mattress in the cot.
- Be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the cot.



WARNING:

Do not attach any item to the cot, for example hooks or handles. These can present a strangulation hazard, which may result in harm to your baby.

Important safety information!

- Tighten all assembly fittings properly before use. Check all fittings regularly and retighten as necessary.
- The lowest position of the bed base is the safest. To prevent falls the mattress base should be adjusted to the lowest position as soon as the baby is old enough to sit up.
- Thickness of the mattress shall be such that the height from the upper surface of the mattress to the upper edge of the cot frame is at least 500 mm in the lowest position of the cot base and at least 200 mm in the highest position of the cot base.
- To prevent injury from falls when the child is able to climb out of the cot, the cot shall no longer be used for that child.

- Never use plastic shipping bags or other plastic film as mattress covers because they can cause suffocation.

Important!

Children can become trapped between the bed and the wall. To avoid risk of serious injury the distance between the bed and the wall must always be less than 65 mm or more than 230 mm.

Cot bed

- When the child is able to climb out of the cot, convert cot to cot bed following the assembly instructions provided.
- Tighten all assembly fittings properly before use. Check all fittings regularly and retighten as necessary.
- Do not use the cot bed if any part is broken, torn or missing. Contact your local IKEA store for replacement parts. Do not substitute parts.
- Do not place the cot bed near a window where cords from blinds or drapes may strangle a child.

Care and maintenance

Wipe clean with a cloth dampened in a mild cleaner. Wipe dry with a soft, clean cloth.

חשוב- שמרו על העלון לעיון בעתיד- קראו בתשומת לב

קראו בעיון את האזהרות והוראות ההרכבה. יש לשמור לשימוש עתידי.

עריסה זו הופכת למיטת תינוק המתאימה לילדים מגיל 15 חודשים במשקל של עד 20 ק"ג.

קראו בעיון את האזהרות והוראות ההרכבה. יש לשמור לשימוש עתידי.

גודל המזרן המינימלי המומלץ למיטה / מיטת תינוק זו הוא 120 ס"מ x 60 ס"מ ובעובי שאינו עולה על 12 ס"מ. ראו סימון על גבי מיטת התינוק.

⚠ אזהרה:

- אין להשתמש במוצר זה באם חסר חלק כלשהו, או אם חלק כלשהו ניזוק או שבור. צרו קשר עם חנות IKEA הקרובה כדי להחליפם וכדי לקבל יעוץ נוסף, הוראות התקנה והרכבה ומידע בטיחותי. אין להשתמש בחלקים שאינם מקוריים.
- אין למקם את המיטה ליד קיר שמשתלשלים ממנו חוטים ולילון, העלולים להוות סכנת חנק. לעולם אין להשאיר חפצים במיטה שניתן לטפס עליהם או שעלולים להוות סכנת חנק.
- אין להשתמש ביותר ממזרן אחד במיטה.
- היא מודעים לסכנה שבאש פתוחה ומקורות חום אחרים (למשל, תנורי גז) בקרבת המיטה.

⚠ אזהרה:

אין לחבר אף פריט לעריסה, לדוגמה ווים או ידיות. אלה יכולים להוות סכנת חנק, דבר אשר עלול לגרום נזק לילדך.

מידע בטיחותי חשוב!

- יש לחזק ולהדק את כל החיבורים לפני השימוש. בדקו כל חיבור מעת לעת וחזקו מה שניתן לפי הצורך.
- האיזור הנמוך של המזרן הוא הבטוח ביותר. כדי למנוע סכנת נפילה, יש להתאים את בסיס המזרן לנקודה הנמוכה ביותר כאשר הפעוט מסוגל להתיישב.
- בחרו מזרן שהגובה בין שטח הפנים שלו לקצה העליון של מסגרת המיטה יהיה לא פחות מ-500 מ"מ כאשר בסיס המיטה נמצא במצבו הנמוך ביותר, ולפחות 200 מ"מ כשבסיס המיטה נמצא במצבו הגבוה ביותר.
- כדי למנוע סכנת פציעות כתוצאה מנפילה: כאשר הילד גדול וכבר יכול לטפס אל מחוץ למיטה, היא כבר אינה מתאימה לו עוד.
- לעולם אין להשתמש באמצעי אחסון ומשלוח מפלסטיק או בריעות פלסטיק לשם כיסוי המזרן - שכן הם עלולים לגרום לחנק.

חשוב!

הילדים עלולים להילכד בין המיטה והקיר. כדי למנוע סכנה לפגיעה גופנית חמורה, על המרחק בין המיטה לקיר להיות קטן מ-65 מ"מ או גדול מ-230 מ"מ.

- כאשר הילד גדל וכבר יכול לשבת, יש להפוך את העריסה למיטת פעוטות לפי הוראות ההרכבה המצורפת.
- יש לחזק היטב את כל ההברגות לפני השימוש. בידקו באופן קבוע את כל החיבורים וחזקו לפי הצורך.
- אין להשתמש במיטה אם חלק כלשהו שבור, קרוע או חסר. פנו לסניף איקאה הקרוב אליכם להחלפת החלקים האמורים. אין להשתמש בחלקים שאינם מקוריים.
- אין למקם את המיטה ליד קיר שמשתלשלים ממנו חוטים ולילון, העלולים להוות סכנת חנק.

ניקוי ואחזקה

נקו במטלית לחה וחומר עדין. יבשו במטלית רכה, יבשה ונקייה.