

User manual

Drawing of Dyson zone air-purifying headphones and outline of visor.



Contents

In the box	Active noise cancelling
Download the MyDyson™ app	Audio joystick
Getting started	LEDs
Assembling your headphones	In-flight adaptor
Fitting the face coverings	Changing your filters
Pairing your headphones	Cleaning your headphones
Charging your headphones	Reassembling your headphones
Activity modes	Cleaning your Community face covering
Using audio	Replaceable FFP2 Community face covering

User manual

Drawing of Dyson zone air-purifying headphones and outline of visor.



Contents

In the box

Download the MyDyson™ app

Getting started

Assembling your headphones

Fitting the face coverings

Pairing your headphones

Charging your headphones

Activity modes

Using audio

Active noise cancelling

Audio joystick

LEDs

In-flight adaptor

Changing your filters

Cleaning your headphones

Reassembling your headphones

Cleaning your Community face covering

Replaceable FFP2 Community
face covering


In the box

Some accessories may not be included.
You can buy additional accessories at
www.dyson.com

Drawing of Dyson Zone™
air-purifying headphones



Dyson Zone™ air-purifying
headphones




Drawing of 'Quarter
Turn' hard case

'Quarter Turn'
hard case

CHINA

CHINA


Drawing of
Community



Community




FFP2 Community
Drawing of FFP2
Community



Drawing of
Electrostatic
carbon
filters x2

Electrostatic
carbon filters x2

Drawing of
USB-C




USB-C

Drawing of
Visor cleaning
brush



Visor cleaning
brush

Drawing of
Visor sleeve



Visor sleeve

Download the MyDyson™ app

An essential part of your experience, the
MyDyson™ app lets you control your Dyson Zone™
air-purifying headphones – wherever you are.
If you haven't already, download the app now
for extra features and the latest updates.

Download the MyDyson™ app from the
App Store or Google Play.
Open the app and follow the on-screen
instructions to create a new account.



Apple and the Apple logo are trademarks of Apple Inc., registered
in the U.S. and other countries. App Store is a service mark of
Apple Inc., registered in the U.S. and other countries. Google Play
and the Google Play logo are trademarks of Google Inc.

In the box


Some accessories may not be included.
You can buy additional accessories at
www.dyson.com

Drawing of Dyson Zone™
air-purifying headphones




Dyson Zone™ air-purifying
headphones

Drawing of
Explorer case



Explorer case

CHINA




Drawing of
Community

Community

CHINA



FFP2 Community
Drawing of FFP2
Community




Drawing of
Electrostatic
carbon filters

Electrostatic
carbon filters x4




Drawing of
Soft pouch

Soft pouch



Drawing of
USB-C

USB-C



Drawing of
In-flight
adaptor kit

In-flight adaptor kit



Drawing of
Visor
cleaning
brush

Visor
cleaning
brush

Download the MyDyson™ app

An essential part of your experience, the
MyDyson™ app lets you control your Dyson Zone™
air-purifying headphones – wherever you are.
If you haven't already, download the app now
for extra features and the latest updates.

Download the MyDyson™ app from the
App Store or Google Play.
Open the app and follow the on-screen
instructions to create a new account.



Apple and the Apple logo are trademarks of Apple Inc., registered
in the U.S. and other countries. App Store is a service mark of
Apple Inc., registered in the U.S. and other countries. Google Play
and the Google Play logo are trademarks of Google Inc.

Getting started

Audio joystick

Lets you control music, adjust volume and access your voice assistant – on the back of your right ear cup.



Access audio joystick in the back centre of the right ear cup



Use your smartphone to download the MyDyson app

Download the MyDyson™ app

Control your environment – wherever you are. Access live reporting on air quality and noise, check the status of your battery, filter life and more.

Auto-activity mode


Control airflow for your activity. Use the button on the left ear cup to scroll through the activity modes, or use the app.



Auto activity mode is located at the back centre of the left ear cup


Ergonomic ear cup
Angled at minus 13° and oval-shaped to sit over the ear.

Electrostatic carbon filter



Twist and release filter cover
For hygienic and easy filter replacement.


Filter cover can be removed from the main body of the machine by twisting and releasing outwards



Transparency mode

To switch to Transparency mode, double tap either ear cup. Surrounding sounds are amplified.

The visor is adjustable to suit faces of different shapes and sizes



The headband adjusts across the top of head to cater for different head sizes


Slide adjustor
Adapts to different face shapes and sizes.

Contactless visor

Supplies purified air, comfortably and hygienically.

USB-C charger

Charge your headphones using the USB-C cable.



Drawing of USB-C charger


Assembling your headphones

Insert your filters


Twist off both ear cup covers, anti-clockwise.

Hold the filters on the plastic edges and secure them into the ear cups.

Replace the covers and twist them clockwise to secure into position.



Return ear cup and ear cup covers to the main body of the machine.




Adjust your headphones

Put your headphones on.

Adjust the headband, sliding both sides until you have a comfortable fit.


Arrows show how to adjust the headband by sliding it left or right




Attach visor

Remove any packaging from the visor and fully extend the visor arms.

Pull visor arm away from visor centre to extend the arms.




Reveal extra length and adjust as you see fit.




With the visor positioned below your mouth, attach it to each ear cup with the magnetic connectors.

Push the visor up to cover your nose and mouth.




Close-up of magnetic connectors at the end of the visor arms



Dyson logo on the right-hand side of visor.

Adjust visor

Adjust the visor until it's in a comfortable position, close to – but not touching – your face. The airflow will start automatically.



Close-up of adjustor strip.

Fitting the face coverings


Reusable Community.

Replaceable FFP2 Community.

These can be re-ordered from www.dyson.com

CHINA

Drawing of Community



Community


Drawing of FFP2 Community



FFP2 Community

Remove visor


Detach the magnetic connection from the bottom of both ear cups.




Fit the face covering

Push the face covering into position inside your visor, making sure it's attached to both the top and bottom.

Attach face covering on the inside of the visor.




Face covering in position behind the visor.



Attach visor

With the visor positioned below your mouth, attach it to each ear cup with the magnetic connectors.

Lift the visor up to cover your nose and mouth. Adjust it until it's approximately one centimetre away from your nose.



Pairing your headphones

Connecting to the MyDyson™ app

Download the MyDyson™ app from the App Store or Google Play. Open the app and follow the on-screen instructions to create a new account.

If you already have an account, select 'Add machine' and follow the instructions.



Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries. Google Play and the Google Play logo are trademarks of Google Inc.

Turn on your headphones


Press and hold the Airflow button on your left ear cup to turn on the power. The LED light will turn white.

You can turn them off by holding down the airflow button for 5 seconds when you are not using them. Holding it down for a further 5-10 seconds will reset your headphones.

Pair your headphones

Press and hold the airflow button until the LED light starts to pulse blue.


Your MyDyson™ app will alert you when pairing is complete.



Connect audio using Bluetooth®

Open Bluetooth® in your mobile device's settings menu. Check that Bluetooth® is turned on and select your Dyson Zone™ headphones.

When your device has connected to your headphones, return to the MyDyson™ app.




Charging your headphones

Your headphones will need to have more than 20% charge to run purification.

You can check charge level by pressing the airflow button.

Battery life

The battery life of your air-purifying headphones will improve with use. Allow at least 5 hours of initial use to achieve the best runtime performance.



Action and LED behaviour

Battery is more than 20% charged
The LED will turn green.



Battery is less than 20% charged
The LED will turn a solid amber for five seconds.



Charging
When connected to a power supply and charging, the LED will pulse amber. When fully charged, the LED will turn green and then fade to off.



Insufficient charge for purification
The LED will flash amber for five seconds.



Activity modes

Your Dyson Zone™ air-purifying headphones will detect your level of activity and adjust the airflow automatically. You can also choose to adjust the levels manually.

Use your MyDyson™ app to select Auto, or adjust the modes manually. Alternatively, use the button on the back of the left ear cup to select modes.

Battery life
You can extend battery life by using low airflow settings.


Auto

Low

Medium


High

Off



List of modes shown that the headphones will scroll through. List reads: Auto, Low, Medium, High, Off.

Airflow button located at the back centre of the ear cup.



Auto mode
Airflow will adapt to your activity level.



Low
Lowest airflow setting. Battery life is extended in this mode.



Medium
Increased airflow setting.



High
Highest available airflow setting.



Battery life
Your battery life will be extended by using low airflow speeds.



Using audio

To play audio through your headphones, you'll need to either connect them using Bluetooth® or the audio cable.


You can play audio through your headphones without the visor being attached.

Use the audio button

Control your audio using the MyDyson™ app or the joystick on the back of your right ear cup.

Play and pause

Press the middle of the joystick to play. Press it again to pause.



Skip and seek

Tap the joystick on the left or right to skip tracks. Press and hold to fast forward or rewind.




Image shows audio button and an arrow pointing left and right for which way to press to skip.

Volume

Push the joystick up or down to adjust the volume.



Image shows audio button and an arrow above and below to indicate how to change the volume.



Activating voice assistant

Press and hold the middle of the joystick to activate the voice control on your mobile device.




Image shows audio button and how to press it to activate voice assistant.

Active noise cancelling

Use Active noise cancelling (ANC) to reduce the background noise around you.


Isolation mode

The maximum level of ANC, reducing surrounding and background noise. This is the default setting for your headphones.




Transparency mode

To toggle to Transparency mode, double tap either ear cap. Surrounding sounds are amplified.




Conversation mode

Flip the visor down to pause airflow, audio and noise cancelling. Voices are amplified so you can hear with your headphones on.



Audio joystick

How to use the Audio joystick
Control your audio using the joystick
on the back of your right ear cup.



Action

At all times

Increase volume slowly Press joystick up.	▲
Increase volume quickly Press joystick up – volume increases until joystick is released.	▲
Decrease volume slowly Press joystick down.	▼
Trigger voice assistant Press and hold joystick.	●

While listening to audio

Play/pause audio Press joystick once to play/pause audio.	●
Skip to previous audio file (or restart track) Press joystick to the left.	◀
Rewind Press joystick to the left.	◀
Skip to next audio file Tap joystick to the right once.	▶
Fast forward Press and hold joystick to the right.	▶

While using the voice assistant on device

End use of voice assistant Press joystick.	●
--	---

While call is ringing


Accept call Press joystick.	●
Decline call Press and hold joystick.	●

While call is in progress

End call Press joystick.	●
------------------------------------	---

LEDs







LEDs will let you know when your Dyson Zone™ air-purifying headphones need your attention.



Action

Power on White LED – momentary (off to on).	
Power off White LED – momentary (on to off).	

Battery

Battery is over 20% charged When taken off head or left button pressed – green LED.	
Battery is under 20% charged When taken off head or left button pressed – orange LED.	
Connected to power – fully charged Constant green LED for 5 minutes, then fade to off.	
Connected to power – charging Orange LED – pulse while charging.	
Insufficient charge to use the purifier Orange LED – flash for 5 seconds.	
Battery charge under 20% Orange LED – solid for 5 seconds.	



Bluetooth®

Bluetooth® in discoverable mode Blue LED – continuous pulse.	
Bluetooth® successfully connected Blue LED – solid. Audio – welcome tone.	

Filter

Filter needs changing Pink LED – pulse.	
---	---

Alerts


Seek Dyson support Red LED – flash for 5 seconds.	
Update installing White LED – pulsed flashing.	

In-flight adaptor

Connect the In-flight cable to the 2-pin adaptor, then plug into the plane's entertainment system via the audio port.

The In-flight adaptor will only charge you Dyson Zone™ headphones when the USB-C cable is also used.

Please note that the audio controls on your Dyson zone™ headphones will not function when the In-flight adaptor is in use.



Warning

The In-flight 2-pin adaptor is for connection to an audio outlet only. Plugging in to a mains socket outlet may result in a fire or pose a risk of an electric shock.

Changing your filters

Filter life

Your MyDyson™ app and headphones will alert you when your filter life is running low. The filter life will depend on the amount of time you use your headphones and the level of your activity.

Your filters are not washable and should be replaced once the MyDyson™ app has alerted you to do so.

Remove the cover

Twist the covers on the ear cups until they release.


Remove the filters

Lift out the filters carefully. Avoid dropping any dust into the ear cups. Dispose of the filters.

Insert filters

Remove the new filters from any packaging and place in the ear cups.


Replace the covers and twist clockwise to lock into position.



Cleaning your Dyson Zone™ purifying headphones

It is important to carry out regular cleaning of your headphones maintain maximum performance. Allow enough time to dry your headphones before you need to use them again.

Due to the materials and manufacturing processes used, your machine inclusive of the packaging, may produce a slight odour.



Quick clean

Ear covers

Wipe away dust or debris from the perforations in the ear cup covers with a soft, damp, lint-free cloth.

Ear cushions

Wipe away dust or debris with a soft, damp, lint-free cloth.

Visor

Wipe away dust or debris with a soft, damp, lint-free cloth.




Regular cleaning

Remove the visor


Push the visor down and gently pull it away from the ear cups.



Pinch the outer edges of the mesh until it pops out of the visor.



Slide the side extensions out and unclip from the visor.



Wash visor


Wash the visor and mesh with warm water and dish soap. Use the Dyson visor cleaning brush to reach all areas.

Rinse all parts thoroughly.



Dry visor

Leave your visor to dry in a well-ventilated, warm place.




Reassembling your headphones


Reassemble visor

Make sure all parts of your visor are completely dry before reassembling.


Slide in side extensions until they click into position.



Clip in the inner mesh.



Reattach the visor to your headphones.



Cleaning your Community face covering

Gently pull the Community face covering away from the visor.


Wash

Use warm water and dish soap.
Rinse thoroughly.

Dry

Leave your Community face covering to dry in a well-ventilated, warm place.

CHINA




Pull out community face covering – located in centre of visor.

Replaceable FFP2 Community face covering

Gently pull the Community face covering away from the visor and dispose of it.

CHINA


Pull out FFP2 face covering – located in centre of visor and dispose of it.



Cleaning your Community face covering

Gently pull the Community face covering away from the visor.


CHINA



Pull out community face covering – located in centre of visor.


Wash

Use warm water and dish soap.
Rinse thoroughly.



Dry

Leave your Community face covering to dry in a well-ventilated, warm place.



Replaceable FFP2 Community face covering

Gently pull the FFP2 Community face covering away from the visor and dispose.

CHINA

Pull out FFP2 face covering – located in centre of visor and dispose of it.

