

The background of the entire page is a dense, repeating pattern of various open-earbud designs. These designs are rendered in a light gray, sketch-like style, showing different shapes, sizes, and internal components of the earbuds. The pattern is scattered across the entire page, creating a textured, technical background.

RAYCON

**THE ESSENTIAL
OPEN EARBUDS**

<https://rayconglobal.com>

CONTENTS

INTRODUCTION	01
WHAT'S IN THE BOX	02
UNIT AT A GLANCE	03
FUNCTIONS	04
Touch Controls	04
USING YOUR EARBUDS	05
Connecting via Bluetooth	05
Charging Your Device	06
LED Status	07
FINDING THE BEST FIT	08
ADVANCED FEATURES	09
Multipoint	09
TROUBLESHOOTING / FAQ	10
SAFETY & WARRANTY	12
COMPLIANCE & REGULATORY INFORMATION	13


INTRODUCTION

Introducing your new Essential Open Earbuds — an audio companion as strong as you are.


At Raycon, we believe in creating innovative tech designed to embrace and empower your every day. We've teamed up with expert engineers, leading taste-makers, and platinum artists to design wireless audio you'll love to use and every day tech that can take whatever life throws your way. We believe in the early risers and the one-more-milers of the world. Premium audio, inspired by you.

To get the most out of your Essential Open Earbuds, we strongly encourage you to fully read through this user guide. You can also visit our support center at www.rayconglobal.com/support. This web page has more specific guidelines and helpful videos for you to navigate your product. For best performance, charge fully before first use.


WHAT'S IN THE BOX




1. Charging Capsule



2. Raycon Open Earbuds



3. USB to USB-C Charging Cable




4. Lanyard



5. Quick Start Guide & Compliance Booklet


UNIT AT A GLANCE




1. Microphone (2 total)

2. LED Status Indicator

3. Touch Control Surface




4. Battery LED Indicator













5. Charging Port

FUNCTIONS / TOUCH CONTROL _____




LEFT/RIGHT EARBUD CONTROLS:

	Power On	<i>Hold for 5 seconds</i>		Play/Pause	<i>Tap once</i>
	Power Off	<i>Hold for 10 seconds</i>		Voice Command	<i>Tap 5 times</i>
	Answer Call	<i>Tap once</i>		Skip Track	<i>Tap twice</i>
	End Call	<i>Tap once</i>		Previous Track	<i>Tap 3 times</i>
	Reject Call (While receiving a call)	<i>Tap twice</i>		Switch Sound Profile	<i>Tap 4 times</i>


USING YOUR EARBUDS

CONNECTING VIA BLUETOOTH

1. Take your earbuds out of the capsule. Both earbuds will connect to each other automatically and will enter Pairing Mode.




2. From the source device, go to Bluetooth settings and ensure Bluetooth is on. Search for “Raycon Essential Open Earbuds” and select it to pair.







CHARGING YOUR DEVICE


1. Plug the USB-C connector in the capsule port or place on Wireless Charging Pad.




2. When charging, the Capsule LED will start to breathe. The LED color will indicate capsule battery. Once fully charged, the LED will hold a Green light. Our Everyday Earbuds are also equipped with Fast Charging: 10 minutes will get you over 1.5 hours of Playback.

	<25% Battery
	25% - 75% Battery
	>75% Battery
	LED Stays green

3. When placing or removing the earbuds in the capsule, the LED will blink Green.








4. A breathing Amber LED indicates that the earbuds are charging.





LED STATUS

CAPSULE LED

LED INDICATION	STATUS	MEANING
	Blinking Red LED	Capsule battery is less than 5%
	Solid Red LED	Capsule battery is less than 25%
	Solid Amber LED	Capsule battery is between 25% - 75% battery life
	Breathing Amber LED	Earbuds are charging in the capsule
	Solid Green LED	Capsule battery is greater than 75%

EARBUD LED

LED INDICATION	STATUS	MEANING
	Alternating Blue and Red Lights	Earbuds are in Pairing Mode
	Solid Blue LED	Earbuds are connected

FINDING THE BEST FIT

1. Place the earbuds into your ears with the hooks resting comfortably over your ears. Ensure the earbuds are placed slightly above your ear canal.




3. Rotate the earbuds gently back and forth as shown in the diagrams to achieve the best possible fit. This movement helps to find the most comfortable and secure position.



4. Move your head around to ensure the earbuds remain secure. They should stay in place without causing discomfort or needing constant adjustment.



MULTIPOINT



WHAT IS MULTIPOINT?

Multipoint allows you to connect your earbuds to up to two devices simultaneously, such as your smartphone, laptop, or tablet - the combinations are endless!. This means you can easily switch between devices without having to disconnect and reconnect each time. Once you have paired your Essential Open Earbuds with both devices, they will automatically switch to whichever device is playing audio. With Multipoint, you can connect your earbuds to both your phone and your laptop, allowing you to easily switch between your workout playlist and work calls without any interruptions.

HOW DO YOU SET UP MULTIPOINT?

To use this feature, make sure both devices are within the Bluetooth range and have Bluetooth enabled.

1. Pair the earbuds with your first device (e.g. your smartphone).
2. Disconnect the earbuds from your first device using the Bluetooth settings on the device. The earbuds will re-enter Pairing Mode.
3. Pair the earbuds with your second device (e.g. your laptop) via its Bluetooth settings.
4. Put the earbuds back into the charging case and close the lid to turn them off.
5. Remove the earbuds from the case.
6. The earbuds will now be able to connect to both of your devices when turned back on.

BLUETOOTH CONNECTION / SOUND INTERFERENCE:

- Ensure speaker is within 10 meters (33 feet) of connected Bluetooth device.
- Check the battery level: If the battery level of either the earbuds or your connected device is low, it can cause the connection to be weak or to drop.

CAPSULE WILL NOT CHARGE:

- Using the provided USB-C charging cable, make sure that the cable is firmly plugged into the charging case and USB-C power adapter.
- If using a wireless charging pad, ensure that the cable is firmly plugged into the charging pad and that the other end is correctly plugged into a power outlet.

EARBUDS WILL NOT CHARGE:

- Ensure the charging case is charged, indicated by LED on the front: should be an amber or green color.
- Confirm there is nothing blocking the earbuds from the connection to the case.
- Insert earbuds into the case, and confirm a blinking amber LED on the front of the case, which indicates that the earbuds are charging.

MULTIPOINT IS NOT WORKING:

- Confirm both earbuds are charged and that they are disconnected from any Bluetooth device.
- Confirm Earbuds are in pairing mode and reconnect devices to Bluetooth.

RESETTING YOUR EARBUDS:

- Delete “Raycon Essential Open Earbuds” from the bluetooth settings on your device, and place the earbuds back in its case.
- For a hard reset, simply place both earbuds inside the charging capsule, close the capsule lid and wait 5-10 seconds.

CLEANING INSTRUCTIONS:

EARBUDS:

- Use a soft, dry cloth to gently wipe the exterior of the earbuds. Avoid using any abrasive materials that could scratch the surface.

CHARGING CAPSULE:

- Use a soft, dry cloth or a slightly damp cloth and wipe the surface gently. Avoid using harsh chemicals, water, or excessive moisture, which can damage the electronic components.

SAFETY & WARRANTY

SAFETY GUIDELINES

- Be wary of any edges, uneven surfaces, and metal parts, including on accessories and product packaging, to prevent any possible injury or damage.
- Listen to music at proper volume to avoid damaging your hearing and earbuds.
- Do not store in high temperatures, such as in a hot vehicle or in direct sunlight.
- Do not expose the earbuds or any of its supplied parts to rain or other liquids for extended periods of time.
- Do not drop or cause undue impact to the earbuds.
- Do not modify, repair, or dismantle the product on your own.
- Do not use any diluent or volatile liquid to clean the product.
- Do not use the product in a hazardous location.
- Ensure all port covers are securely closed if exposing charging capsule to liquid.
- Do not expose the speaker to water while charging, as doing so may result in damage to the speaker or the power source.
- When cleaning this speaker, use a soft dry cloth. For more severe stains, dampen the cloth with water only. Anything else increases the chance of dissolving the paint or damaging the plastic.

SUPPORT

If your device is not functioning properly, please visit www.rayconglobal.com/support for customer support, and we will be more than happy to help you.

LIMITED WARRANTY

Your Essential Open Earbuds are covered by a limited warranty. Please visit our website at www.rayconglobal.com/warranty for more details.

PRODUCT SPECIFICATIONS

Model Number: RBO715
Bluetooth Pairing Name: Raycon Essential Open Earbuds
RDID: D715-25E-0325
Bluetooth Version: 6.0
Power Input: DC 5V/1A
Earbud Battery Capacity: 60mAh
Capsule Battery Capacity: 500mAh
Call / Play Time: About 8 hours
Charging Time: 1 hour
Total Play Time (including capsule): About 36 hours
Support Profiles: SBC, AAC
Sensitivity: 100 ± 3dB
Frequency Response Range: 10Hz-20kHz
Bluetooth Range: 45 feet
IP Rating: IPX5

COMPLIANCE & REGULATORY INFORMATION

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- The device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. Those limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit on a circuit different from that to which the receiver is connected.
- Consult the dealer on an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure statements. The device can be used in portable exposure condition without restriction.

IC WARNING

This device contains license-exempt transmitter(s)/receiver(s) that complies with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

RF EXPOSURE STATEMENT:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.