


SUPER CONSOLE X Use Manual



- ## 1. Product Information
- Mini size, retro design, palm size, can be put in the pocket, is the best choice for family, travel, party, corporate entertainment.
 - Equipped with upgraded S905M chip, more powerful than Rk3326, with a 64-bit 4-core CPU, 5-core Mali-450 graphics processor, and supports 4K@60fps video hard decoding and HDR processing.
 - Support connection to the network via LAN interface or wifi.
 - The heat dissipation hole design on the back of the machine makes the heat dissipation more even.
 - Equipped with two wireless controllers, you can play with friends and family at any time.
 - Support HDMI, supports 1080P / 720P high-definition output, can be connected to display screens, projectors, TVs and other equipment, big screen is clearer.
 - Open source system, suitable for DIY. For the specific method to downloading the game, please refer to the instructions or consult our customer service.
 - Product size: 10cm*10cm*2.2cm
 - Product weight: 100g

2. Safety Precautions

Do not store the machine in a dusty, humid, high temperature and strong magnetic environment. Please pay special attention when using in a swimming pool, bathroom and other water-rich environments (this product is not waterproof). When you carry the machine when you go out, such as participating in high-intensity sports such as running, climbing, etc., please fix the machine firmly on your body or backpack to avoid damage caused by falling from a height or squeezing heavy objects. When inserting or unplugging the SD card, please shut it down first, because the current is very large when it is inserted or unplugged, which will cause unpredictable damage to the machine. When the power adapter is fully charged, please do not touch the power video unit with wet hands to prevent electric shock. Some games of this product contain violent scenes, please be careful with children before using them. Parents are also requested to supervise their children and not to include for a long time.

3. System Startup and Shutdown

- (1) System Startup: press the power button to start the system
- (2) Shut Down: Press SELECT---->SHUTDOWN SYSTEM (software shutdown protection system, then cut off the power).





4. Basic Button Instructions

Function keys, the specific function depends on the simulator	Close key, must be BARRY 1, 1, R1, L2, R2, start select (hot key)
Coins in arcade simulator	SELECT
Enter the game from the title menu	START
Fast Forward (action)	Hot key+R2
Save State	Hot key+R1
Loading State	Hot key+L1
Status memory card slot +	Hot key+Arrow right
Status memory card slot -	Hot key+Arrow left
Increase the volume	Hot key+Arrow keys
Volume the volume	Hot key+Arrow down
Bring up the simulator menu	Hot key+Y
Reset the game	Hot key+A
Exit the Emulator	Five consecutive times Start+select


5. More Settings

- (1) Language Setting
- System Settings-->Language

START---->SYSTEM SETTINGS---->LANGUAGE



- (2) Handle Button Setting
- After the USB interface is connected to the handle, press the handle B (OK) button to enter the handle button setting.



- (3) WIFI Connection
- START---->NETWORK SETTINGS---->ENABLE WIFI, then select the wifi network as required and fill in the password;

