


Premier
NXT II GEN

**PADOUK XYLOPHONE,
3.0 OCTAVE**


PNG-OXP3.0

SETUP GUIDE


PARTS




A x1




B x1




C x1



D x1



E x1




F x1




G x4




STEP 1






STEP 2





STEP 3



STEP 4



STEP 5



Premier
NXT || GEN

*If you have any more questions about this product, please do not hesitate to contact the Gear4music
Customer Service Team on: +44 (0) 330 365 4444 or info@gear4music.com*

KETTLESTRING LANE | YORK | YO30 4XF | UNITED KINGDOM
LAHNSTRASSE 27 | 45478 MÜLHEIM AN DER RUHR | DEUTSCHLAND
WWW.GEAR4MUSIC.COM