



Original	Recharge
 Power	 Power
 TTX	 Text / Got o
 Fav	 Fav / Marker / PC
 Audi o	 Audi o / Lang 1 / I I
 Mut e	 Mut e / Di mmer
 Pl ay	 Pl ay / Sl ow
 Pause	 Pause / Step / Freeze
 <<	 << / Tune-
 >>	 >> / Tune+
 Red / SOS	 Red / Netflix / Search
 Green / Sous	 Green / APP / Repeat
 Green / Sous	 Sub title / EQ
 Yel low / Enreç	 Yel low / YouTube / Repeat
 Bl ue / Ti mer	 Bl ue / Pri ne Vi deo / Random
 Bl ue / Ti mer	 Sl eep / Ti mer
 Gui de	 Gui de / EPG / - / -
 Up	 Up

Original	Recharge
 I nf os	 I nf o / Angl e
 Left	 Left
 OK	 OK
 Ri ght	 Ri ght
 Menu	 Menu / Home
 Down	 Down
 Qui t	 Exi t / Cancel / Clear
 Vol +	 Vol +
 Rec	 Rec / Rec Mode
 CH+	 CH+ / Page+
 Vol -	 Vol -
 St op	 St op / Hol d
 CH-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4



MandisMandis