


nedis

Code book for Universal remote control

Suitable for 4 devices

TVRC2340BK



ned.is/tvrc2340bk



Brand	Type Code						
SAMSUNG	TV	0001	0002	0003	0004	0005	0006
		0007	0008	0009	0010	0199	0200
		0201	0203	0204	0207	0212	0242
		0251	0268	0286	0324	0339	0358
		0386	0411	0415	0443	0529	0559
		0649	0682	0760	0768	0954	0968
		0972	0973				
	SAT	0251	0262	0328	0351	0393	0399
		0420	0422	0459	0465	0635	0649
		0650	0678	0734	0961	1011	1014
		1042	1311	1373	1391	1425	1426
	DVD	1499					
		0200	0204	0598	0988	0993	0996
	TNT	0998	1041				
	VCR	0399	0422	0734	1373	1391	
LG	TV	0204	0207	0223	0251	0283	
		0011	0012	0013	0014	0015	0016
		0017	0018	0019	0020	0198	0199
		0200	0201	0202	0204	0206	0212
		0214	0215	0222	0231	0239	0244
		0251	0271	0272	0275	0287	0339
		0365	0386	0411	0471	0509	0515
	SAT	0530	0667	0712	0727		
		0202	0251	0449	1376	1381	1399
		0200	0204	0301	0458	0700	
		0202	1376	1381	1399		
	DVD	0204	0213	0251	0271	0303	
	TNT	0515					
	VCR						
	AUX						
SONY	TV	0042	0043	0044	0045	0046	0047
		0048	0049	0050	0199	0296	0336
		0356	0463	0476	0541	0591	0620
		0671	0768	0866	0983		
	SAT	0229	0262	1106			
		0391	0670	0773	0994	1170	1243
	DVD						
	PHILIPS	0021	0022	0023	0024	0025	0026
		0027	0200	0201	0205	0209	0212
		0221	0224	0238	0242	0244	0250
		0257	0258	0263	0271	0272	0273
		0274	0276	0281	0308	0311	0317
		0319	0333	0336	0344	0368	0570
PANASONIC	SAT	0205	0216	0229	0241	0245	0262
		0263	0279	0282	0308	0313	0326
		0328	0331	0332	0341	0350	0359
		0368	0382	0392	0431	0517	0557
	DVD	0570	0617	1372	1427	1496	
		0200	0266	0278	0306	0390	0391
		0640					
	TNT	0205	0263	0617	1372	1496	
		0213	0223	0261	0271		
	VCR	0028	0029	0030	0031	0032	0033
		0034	0035	0036	0037	0038	0039
		0040	0041	0051	0222	0271	0361
		0384	0519	0581	0582	0838	0984
1ONE	SAT	1039	1205	1324			
		0262	0420	0422	0561	0799	1102
		0582	0595	0897	0997	1231	
		0422					
	DVD	0271	0582				
	TNT	0211	0421	0421			
	VCR	0631	0874				
	@DIKON	0495	0648	1191	TNT	0495	
	@SAT	0312					
	@SKY	1080					
ABCOM	SAT	0400	1472	1473	1483	TNT	0400
	AB SAT	0718					
	ACCENT	0200	0203	0242	0318	0338	
		DVD	0200				
	ACCESS MEDIA	SAT	0262	0523	TNT	0523	
	ACCUPHASE	TV	0200	DVD	0200		
	ACEC(PHILIPS)	0200	0201	0205	0209	0212	0221
		0224	0229	0238	0242	0244	0250
		0257	0258	0263	0271	0272	0274
		0276	0281	0289	0311	0317	0319
ADL	SAT	0333	0336	0344	0368		
		0205	0229	0241	0245	0262	0263
		0313	0328	0331	0332	0341	0350
		0359	0368	0382	0392		
	DVD	0200	0266	0306	0390	0391	
	TNT	0205	0263	VCR	0223	0261	0271
	ACER	0723	1199	1265			
	ACOUSTIC SOLUTION	TV	0202	SAT	0202	TNT	0202
	ACTION	DVD	0534	0568			
ADB	TV	0263					
	SAT	0228	0263	0329	0464	0818	1362
	TNT	0228	0263	0818	1362		
	ADL	SAT	0312				
	ADMIRAL	TV	0207	0221	0233	0315	0389
			0457	VCR	0207	0402	

Brand	Type	Code					
ADYSON	TV	0201	0239	0481			
ADR	SAT	0714					
AEA	TV	0199	0200	DVD	0200		
AEGYR	SAT	0395			AFK	DVD	0645
AEG	TV	0202	0260		SAT	0202	
	DVD	0278	0483		TNT	0202	
AG	TV	0215			DVD	1242	
AGASHI	TV	0198	0199	0203	SAT	0299	
AGEF (BRUNS)	TV	0227	0221	0224	0227	0270	0297
		0370		SAT	0216	0451	0794
AIKO	TV	0199	0201	0407			
AGB (SABA)	TV	0202	0217	0221	0233	0255	0270
		0274	0284	0361	0372	0375	0398
		0401	0440	0466	0959		
	SAT	0202	0241	0245	0255	0369	0445
		0535	0690				
	DVD	0360	TNT	0202	VCR	0265	0284
AIM	TV	0199	0200	0220	0239	0264	0499
		0966	DVD	0200	0428	0719	0883
	VCR	0210	0295				
AIOSTAY	TV	0247					
AIRIS	SAT	0246	0337	0464	0492	0748	1309
	DVD	0534	0644	TNT	0246	0337	0748
AITECH	SAT	0228		TNT	0228		
AIWA	TV	0199	1344	SAT	0309	0956	
	DVD	0225	0773	1168	1209		
	VCR	0213	0309				
AKAI	TV	0094	0102	0198	0199	0200	0201
		0202	0220	0222	0224	0226	0248
		0256	0260	0308	0324	0325	0348
		0349	0357	0358	0376	0384	0388
		0456	0542	0621	0623	0715	0847
		0849	0850	0970	0984	1353	1576
	SAT	0202	0273	0282	0308	0309	0436
		0450	0523	0542	0822	1395	1436
		1437					
	DVD	0200	0278	0436	0483	0566	0641
		0644	0704	0720	0782	1173	
	TNT	0202	0523	0822	1395		
	VCR	0302	0309	0367			
AKARI	TV	1354					
AKI	TV	0198	0280	DVD	0534	0568	
AKIBA	TV	0199	0200	DVD	0200		
AKITO	TV	0199	0200	DVD	0200		
AKIRA	TV	0198	0199	0202	0203	0212	0214
		0215	0224	0226	0239	0242	0256
		0275	0290	0300	0330	0356	0377
		0426	0479	0580	0583	0584	0589
	SAT	0202	0492	DVD	0200		
	TNT	0202	VCR	0300			
AKITA (ORION)	TV	0300	0497	DVD	0301	0512	0707
	VCR	0223	0300				
AKTRON (TOSHIBA)	TV	0202	0215	0260	0305	0358	0407
		0456	0462	0480	0503	0524	0673
		0675	0729	SAT	0202	0241	0652
	DVD	0632	TNT	0202	VCR	0480	
AKURA	TV	0198	0199	0200	0202	0203	0338
		0621	1322	SAT	0202	DVD	0200
	TNT	0202	VCR	0302			
ALBATRON	TV	0857					
ALBIRAL	TV	0198	0199	0203	0217	0222	0232
		0264	0287	0562			
ALBRECHT	TV	0878			ALCO	DVD	0278
ALDES	SAT	0326	0395	0571	0789	DVD	0594
ALBA	TV	0198	0199	0202	0222	0226	0300
	SAT	0202	0211	0216	0249	0259	0309
		0326	0369	0434	0436	0438	0450
		0493	0555	0560	0571	0606	0656
		1433					
	DVD	0436	0594	0642	TNT	0202	0438
	VCR	0210	0218	0219	0300	0302	0309
ALHORI	TV	0201					
ALICE	SAT	0420	0422	0548	1060	TNT	0422
ALITEK	SAT	0269	0661	TNT	0269		
ALKOS (TOSHIBA)	TV	0202	0215	0260	0305	0358	0366
		0407	0456	0462	0480	0503	0524
		0673	0729				
	SAT	0202	0241	0652	DVD	0632	
	TNT	0202	VCR	0210	0480		
ALLORGAN	TV	0201	0250	0347			
ALLSAT	TV	0308	SAT	0273	0282	0308	0320
ALLSONIC	SAT	0326	ALLTECH	SAT	0505	0537	
ALL TEL	TV	0311	0471	0676	SAT	1052	
	DVD	0293	0596	0886	0990	1213	
ALLVISION	SAT	0343	TNT	0343			
ALPHA	TV	1187			ALTAI	SAT	0252
ALTEK	TV	0629	0861	0867	0872	0976	1254
	SAT	0739	DVD	0883	TNT	0739	

Brand	Type Code						
ALTUS	TV	0215					
AMBASSADOR	TV	0290	Amiko	SAT	0746	1476	
AMITONIKA	SAT	0211	AMPLIVISION TV	0201	0264		
AMPERE(ARCON)	SAT	0254	0459	0556	0612	0957	
	TNT	0254					
AMSTRAD	TV	0198	0199	0202	0203	0226	0232
		0234	0252	0257	0260	0280	0290
		0315	0330	0560	0590	0621	0726
		0763	0979				
	SAT	0202	0211	0234	0236	0246	0252
		0253	0262	0267	0279	0298	0304
		0307	0327	0329	0351	0364	0404
		0419	0459	0522	0617	0627	0655
		0684	1012				
	DVD	0225	0234	0236	0278	0293	0405
		0416	0533	0566	0694	0699	0701
		0702	0771	0774	0776	0779	0780
		0989	1000	1004	1006	0617	
	TNT	0202	0236	0246	0267	0419	0522
AMW	DVD	0301					
ANAM	TV	0199	0200	DVD	0200		
ANEX	TV	0198	0232	ANGLO	TV	0203	
ANITECH	TV	0199	0200	0203	0227	0230	0235
		0239	0481				
	SAT	0216	DVD	0200	VCR	0283	
ANIS	TV	0203	0297				
ANKARO	SAT	0252	0254	0292	0326	0364	0396
		0451	0488	TNT	0254		
ANDERSSON	TV	0202					
	SAT	0202	0553	TNT	0202	0553	
ANIKO	SAT	0553		TNT	0553		
ANSONIC	TV	0198	0202	0203	0227	0275	0286
		0297	0323	SAT	0202	0438	
	DVD	0278	0340	TNT	0202	0438	
ANTARES	SAT	0246	0380	1390	1394	DVD	0381
	TNT	0246	1390	1394			
ANTTRON	SAT	0245	0249				
ANVIMUR	TV	0234					
	SAT	0234	0236	0267	0399	0610	0677
	DVD	0234	0236				
	TNT	0234	0236	0267	0399		
AOC	TV	1284					
APEX	DVD	0405	0408	0902			
AQP (GRUNDIG)	TV	0271	0291	0294	0316	0349	0366
		0383	0384	0412	0462		
	SAT	0229	0241	0288	0359	0447	0587
		1018	1034	1035	DVD	0513	1007
	TNT	0288		VCR	0223	0271	0316
ARCAM	TV	0201		DVD	0887		
ARCELIK	TV	0206	0215	0275			
ARCON	SAT	0254	0409	0459	0556	0612	0957
	TNT	0254	0409				
ARGENTINA	TV	0716	0840	1336	1337		
ARIASAT	SAT	0246	0310	0343	0397	0400	1375
	TNT	0246	0310	0343	0397	0400	1375
ARION	TNT	0254		SAT	0254		
ARISTONA(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0289	0311	0317	0319	0333
		0336	0344	0368			
	SAT	0205	0229	0241	0245	0262	0263
		0313	0328	0331	0332	0341	0350
		0359	0368	0382	0392		
	DVD	0200	0266	0306	0390	0391	
	TNT	0205	0263	VCR	0223	0261	0271
ARIZA	SAT	0461		TNT	0461		
ARDEM	TV	0214	0215	0275	0297		
ARMSTRONG	SAT	0273	0299	0605			
ARNION	SAT	0495		TNT	0495		
ARPHONE (DESMET)	TV	0198	0199	0202	0206	0217	0235
		0258	0442	SAT	0202	TNT	0202
ARROX	SAT	0246		TNT	0246		
A.R. SYSTEM	TV	0198	0200	0202	0203	0264	0442
	SAT	0202	DVD	0200	TNT	0202	
ART-TECH	TV	0199	0230	0280			
ARTHUR MARTIN (SALORA)	TV	0198	0207	0212	0222	0231	0233
		0248	0325	0348	0357	0373	0386
		0478	0501	0588			
	SAT	0327	0417	0604	VCR	0207	0302
ASA	TV	0199	0247	0423	VCR	0213	
ASAHI	SAT	0246	0310	0409			
	TNT	0246	0310	0409			
AS-BERG	TV	0198	0199	0209	0227	0256	0318
ASCOMTEC	DVD	0416		ASHIN	SAT	0459	
ASORA	TV	0203		ASSCOM	SAT	0229	
AST	SAT	0327	0607	0608			
ASTEL	SAT	0614	1021				

Brand	Type	Code					
ASTHON (EMERSON)	TV	0198	0199	0201	0202	0206	0207
		0221	0222	0226	0227	0232	0235
		0243	0247	0251	0280	0286	0287
		0290	0297	0318	0333	0403	0412
		0415	0723		SAT	0202	0251
	TNT	0202			VCR	0251	0207
ASTON	SAT	0252	0320	0364	0916	0958	1098
ASTRA	TV	0201	0209	0220	0226	0239	0308
		0358	1020				
	SAT	0245	0252	0273	0282	0299	0308
		0327	0364	0486	0488	0659	
ASTRATEC	SAT	0259					
ASTRASAT	SAT	0246		TNT	0246		
ASTRELL	TV	0843	1058				
	SAT	0157	0192	0279	0424	0438	0491
		0492	0518	0547	0558	0574	0803
		0843	1055	1058	1144	1623	
ASTRO	TV	0626					
	SAT	0236	0267	0288	0313	0341	0395
		0430	0447	0475	0493	0638	0714
	DVD	0236		TNT	0236	0267	0288
ASTRO SOUND	TV	0206	0264				
ASTROVOX	SAT	0246			TNT	0246	
ASUKA	TV	0201	0203	0222	VCR	0213	
ATAKI	TV	0230			ATEC	TV	1202
ATLANTA	SAT	0269	0298	0304	0307	0337	0430
	TNT	0269	0337				
ATLANTEC	TV	0207	VCR	0207	0213		
ATLANTIC (FORMENTI)	TV	0198	0199	0201	0202	0203	0204
		0206	0207	0212	0214	0217	0220
		0231	0232	0235	0240	0242	0247
		0258	0277	0285	0339		
	SAT	0202	0292		DVD	0204	0225
	TNT	0202			VCR	0204	0207
						0210	
ATLANTIS	SAT	0249	1339		A TREND	DVD	0484
AUDIODYNAMICS	VCR	0303					
AUDIOSONIC	TV	0198	0199	0201	0203	0206	0215
		0217	0220	0227	0230	0248	0268
		0275	0280	0286	0287	0296	0297
		0314	0403	0511	0586		
	SAT	0436	DVD	0436	VCR	0210	
AUDIOLA	SAT	0269	0371	0438	0464	0738	0749
		0821	0823	1051			
	DVD	0390	0567	0597	0644	0698	0704
		0892	0896	0898	1000		
	TNT	0269	0371	0438	0738	0749	0821
		0823					
AUDIOLINE	SAT	0500					
AUDIOTON	TV	0201	0235	0287			
	SAT	0320		VCR	0303		
AUDIOVOX	TV	0716			AUNA	SAT	1134
AURIGA	SAT	0228	0241	0329	0354	0395	0409
		0552	TNT	0228	0354	0409	0552
AURORA	TV	0201	0220	0221			
AUSIND	TV	0247	0318	0406			
AUSIOSONIC	VCR	0213	0218	0219			
AUTOVOX	TV	0201	0202	0247	0250	0260	0318
		0347	0406	0424	0510	0766	0856
	SAT	0202	0211	0269	0371	0615	0748
		0749	1428				
	DVD	0225	0567		VCR	0213	
	TNT	0202	0269	0371	0748	0749	
AUVISIO	SAT	1635					
AVALON	SAT	0252	0364	AVerMedia	TV	1279	
AVION	SAT	0254	0472	TNT	0254		
AVIOUS	TV	0978		AUVISAT	TV	0258	
AWA	TV	0198	0199	0200	0201	0220	0296
		0455			DVD	0200	
AXIL	SAT	0211	0246	0269	0310	0337	0371
		0419	0421	0438	0439	0464	0555
		1059	1478	1410			
	TNT	0246	0269	0310	0337	0371	0419
		0421	0438				
AXIS	SAT	0259	0396	0292			
AXITRONIC	SAT	0211					
AXOSAT	TV	0808		SAT	0216	0808	
BAFF	SAT	0310		TNT	0310		
BAIRD	TV	0207	0316	0324	0378	0476	
	SAT	0378	VCR	0207	0210	0316	0378
BALMET	SAT	0246	0310	0354	0551	0648	0661
		1120	1121	1400	1415	1520	
	TNT	0246	0310	0354	0551		
BANG & OLUFSEN	TV	0221					
BARCO	TV	0221	0440	1347			
BARCOM	TV	0239					
BASIC LINE	TV	0198	0199	0202	0206	0215	0220
		0230	0243	0260	0275	0476	0502
	DVD	0225		VCR	0210	0218	0219

Brand	Type Code							
BASTIDE	TV	0201			BAUMATIC	TV	0232	
BAUR	TV	0198	0200	0209	0224	0231	0242	
		0248	0250	0289	0338	0366	0373	
		0384	0388	0456	0463	0480	0499	
		0503	0549	0591	0620	0671	0833	
	DVD	0200			VCR	0480		
BAZIN	TV	0201	0624					
BEAUMARK	TV	0251	SAT	0251	VCR	0251		
BEC	SAT	1149						
BEKO	TV	0198	0200	0204	0206	0214	0215	
		0275	0297	0379	0410	0524		
	SAT	0400			DVD	0200	0204	0225
	TNT	0400			VCR	0204		
BEKNTTEKNIK	TV	0286	0456	0524				
BELLAGIO	DVD	0301						
BELSON	TV	1263			SAT	1524		
BELSTAR	TV	0202						
BENCH	DVD	0237	0362					
BENJAMIN	SAT	0400	0418	1146	TNT	0400		
BENNET	TV	0199	0200			DVD	0200	
BEON	TV	0199	0200			DVD	0200	
BENQ	TV	1201						
BENSTEN	TV	0471	0676	0868	DVD	0596		
BEST	SAT	0292	0326					
BESTAR	TV	0199	0200	0235	0240	0286	0297	
	SAT	0254	DVD	0200	1157			
	TNT	0254	VCR	0210				
BEST BUY	SAT	0269	0371	0477	0735	0736	0749	
		1058	1293	1306				
	TNT	0269	0477	0749				
BETA	TV	0308			SAT	0273	0282	0308
BIAZET	TV	0198	0233			BIFONIC	TV	0201
BIG BEN	DVD	0670						
BIG SAT	SAT	0246			TNT	0246		
BIGSTON	TV	0220						
BINATONE	TV	0201			SAT	1024		
BLACK DIAMOND	TV	0200	0202	SAT	0211	0259		
	DVD	0200	0225	VCR	0367			
BLACK PANTHER	VCR	0210						
BLACK STRIP	TV	0407						
BLACKWAY	TV	0366			VCR	0218	0219	
BLACK WIDOW	SAT	0400			TNT	0400		
BLANK	SAT	1401						
BLAUPUNKT	TV	0271	0294	0296	0317	0366	0462	
		0582	0833	1325				
	SAT	0288	DVD	0582	TNT	0288		
	VCR	0223	0265	0271	0582			
BLAUSONIC	TV	0201						
BLOOM	TV	0202	0257	0629	0725	0858	0974	
	DVD	0699						
BLUE MEDIA	TV	1200						
BLUESKY	TV	0198	0199	0202	0214	0215	0243	
		0255	0258	0260	0275	0330	0349	
		0356	1289	1290				
	SAT	0304	0307	0309				
	DVD	0225	0278	0298	0408	0643		
	TNT	0255	VCR	0213	0218	0219	0309	
BLUESTAR	TV	0222	0728	SAT	0309	VCR	0309	
BLUETINUM	SAT	0342	0421	TNT	0342	0421		
BOMAN	DVD	0483	0901	BONDSTEC		TV	0287	
BOCA(AMSTRAD)	TV	0198	0199	0202	0203	0232	0234	
		0257	0260	0280	0290	0315	0330	
		0564	0590	0621	0726	0763	0979	
		SAT	0211	0234	0262	0293	0298	0299
	SAT	0304	0307	0329	0404	0419	0459	
		0488	0517	0627	0655	0684	1012	
		1029						
		TNT	0234	0419				
	DVD	0225	0234	0278	0405	0533	0566	
		0694	0701	0706	0771	0774	0776	
		0780	0894	0989	1004	1006		
BOOTS	TV	0201						
BOSE	TV	1689	1695					
	DVD	1174	1689	1690				
	AUX	1174	1689	1690	1691	1692	1693	
		1694	1696	1697	1698	1699		
BOSCH/BAUER	TV	0198	0235	0271	0966	VCR	0271	
BOSHMANN	SAT	0310		TNT		0310		
BOSTON	TV	0201						
	SAT	0211	0246	0298	0304	0307	0337	
		0438	0517	0555	0556			
	TNT	0246	0337	0438				
BOTECH	TV	1292			SAT	1122		
BOX	SAT	0929			BOXNEUF	SAT	1111	
BPL	TV	0199	0200	DVD	0200			
BQS	SAT	0253						
BRAIN WAVE	SAT	0293	0321	0322	0341	0363	0437	
		0500	0618	1033	1512			

Brand	Type	Code					
BRANDELECTRONIQUE (THOMSON)	TV	0206	0233	0247	0255	0270	0274
		0284	0294	0349	0372	0375	0379
		0398	0401	0440	0441	0466	0482
		0498					
	SAT	0216	0229	0241	0245	0255	0352
BRAUN	DVD	0369	0413	0446	1023		
		0237	0360	0468			
		0352	VCR	0265	0284		
BRAUN	TV	0201	0271	VCR	0271		
BRAVO	SAT	0409	0435	1138	1388	1397	
	TNT	0409	0435	1388	1397		
BRIGMTON	TV	0201	0264				
BRINKMANN	TV	0199	0200	DVD	0200		
BRIONVEGA	TV	0207	0221	0291	0315	0316	0402
		0457	0520	0563	0766	0856	1321
		1323					
	DVD	0520	VCR	0207	0265	0302	0316
BRITANNIA	TV	0201	0478	BROKLINE	TV	0851	
BROKSONIC	TV	0198	0852	1244			
BROTHER	TV	0202	0203				
BROWN	TV	0333					
BRUNS	TV	0221	0224	0227	0270	0297	0370
	SAT	0216	0451	0794			
BSB	TV	0308		SAT	0273	0282	0308
BSR	TV	0222	0239	0300	0365	0377	
	VCR	0300					
BT	SAT	0450					
BUSH	TV	0198	0202	0207	0231	0233	0243
		0259					
	SAT	0241	0369	0436	0560		
	DVD	0225	0436	0507	0567		
	VCR	0207	0210	0218	0219	0302	
BUT	DVD	0306	0773				
	VCR	0213	0218	0219	0223	0261	0265
		0283	0302				
BW	SAT	0500					
CADMOS (DESMET)	TV	0198	0199	0206	0217	0235	0442
		0851					
CALE	SAT	1295	1395	TNT	1395		
CALIFORNIA (FORMENTI)	TV	0198	0199	0201	0202	0203	0204
		0206	0207	0212	0214	0217	0220
		0231	0232	0235	0240	0242	0247
		0258	0277	0285	0339		
	SAT	0202	0292	DVD	0204	0225	
	TNT	0202		VCR	0204	0207	0210
CAMBRIDGE	SAT	0299	0447	0450			
CAMPER	TV	0199	0275	0297	0511		
CANAL+	SAT	0229	0332	1492	1700	1701	1704
		1705	1707				
CANAL DIGITAL	TV	0120	0420	1702	1703	1706	
CANAIS	TV	0238					
CANALERA	TV	1277	SAT	1091	1092		
CANALSANTE (SIDECE)	TV	0206					
CANDLE	TV	0515	AUX	0515			
CANDLE (LG)	TV	0198	0199	0200	0201	0202	0204
		0206	0212	0214	0215	0222	0231
		0239	0244	0251	0271	0272	0275
		0287	0339	0365	0386	0411	0471
		0509	0515	0530	0667	0712	0727
	SAT	0202	0251	0449	TNT	0202	
	DVD	0200	0204	0301	0458	0700	
	VCR	0204	0251	0271	0303	AUX	0515
	TV	0271	VCR	0271			
CANON	TV	0387					
CANTON	TV	0198	0203				
CAPSONIC	TV	0199	0200	DVD	0200		
CARAD	SAT	0354	0552	0663			
CARDMANIA	TNT	0354	0552				
CARENA	TV	0198	0200	DVD	0200		
CARREFOUR	TV	0199	0200	SAT	0267		
	DVD	0200	0617	TNT	0267	0617	
	VCR	0218	0219	0223	0261	0265	0283
		0302	0367				
CASCADE	TV	0199	0200	DVD	0200		
CARYONSE(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0289	0311	0317	0319	0333
		0336	0344	0368			
	SAT	0205	0229	0241	0245	0262	0263
	DVD	0313	0328	0331	0332	0341	0350
		0359	0368	0382	0392		
		0200	0266	0306	0390	0391	
	TNT	0205	0263	VCR	0223	0261	0271
CASEMA	SAT	0352	0752	TNT	0352	0752	
CASIO	TV	0200	0214	0508	DVD	0200	
CASONIO (OCEANIC)	TV	0207	0231	0233	0248	0285	0325
		0348	0355	0357	0361	0373	0374

Brand	Type Code						
CASONIO (OCEANIC)	TV	0387	0502	0579	VCR	0207	0223
	SAT	0229	0417	0418	0444		
CAT	TV	0769	1067	1283			
	DVD	0596	1177	1178			
CBM	TV	1260					
CCE	TV	0199	0200		DVD	0200	
CCI	DVD	0545					
CDV	TV	0726	1261	SAT	0419	1104	1504
	DVD	0408	0545	0596	0776	TNT	0419
CENTRUM	DVD	0225					
CENTURION	TV	0199	0200	DVD	0200		
CENTURY	TV	0221	0323	SAT	1043		
CERT	SAT	0327			CEY	TV	1343
CGE	TV	0198	0199	0204	0207	0222	0256
		0280	0318	0323	0376	0835	
	DVD	0204	VCR	0204	0207		
CGM	TV	0198	0202	0203	0204	0207	0222
		0230	0243	0286	0297		
	SAT	0202	DVD	0204	TNT	0202	
	VCR	0204	0207	0210	0213		
CGV	SAT	0236	0267	0310	1304		
	DVD	0236	0642	TNT	0236	0267	0310
CHANNEL MASTER	SAT	1126		CHAPARRAL	SAT	0907	
CHEROKEE	SAT	0353	0413	0414	0439	0609	
	DVD	0394					
CHESS	SAT	0475		TNT	0475		
CIE	TV	0199	0220	0290	0314		
	VCR	0218	0219				
CIHAN	TV	0206	0277				
CINEMA	TV	0202	SAT	0202	TNT	0202	
CITIZEN	TV	1064	SAT	0425	VCR	0213	
CITY COM	SAT	0310	0343	0380	0397	0425	0430
		0474	0485	0536	0557	0686	
	DVD	0381	0474	TNT	0310	0343	0397
CJ MULTIMEDIA	DVD	0597		CLARITRONIC	TV	0286	
CLARIVOX	TV	0200	0217	0221	0222	0264	0294
		0370	0374	0403	0508	DVD	0200
CLARKE - TECH	TV	1070	SAT	0418	1444		
CLATRONIC	TV	0200	0202				
	SAT	0202	0269	0321	0322	0452	1296
		1357					
	TNT	0202	0269	0452	1357		
	VCR	0218	0219	DVD	0200		
CLAYTON	TV	0199	0202	0206			
	SAT	0202	DVD	0225	TNT	0202	
CLEMENS CAMPUS (HUTH)	SAT	0298	0299	0326	0430	0451	0473
		0535	0544	0647	0709		
		0473	0535	0544	0647	0709	
CME	SAT	0241	0253	0313	0444	0448	0467
		0560	0561	0959			
CMR	SAT	0216	1125		CMX	SAT	1058
COBRA	SAT	0246	0252	0329	0342	0364	0396
		0430	0490	0522	0527	0551	0635
		0689	0692	0736	0825	0908	0914
		1058	1293	1406	1418	DVD	0293
	TNT	0246	0342	0490	0522	0551	0692
	DVD	0568					
COFADEL (THOMSON)	TV	0206	0233	0247	0255	0270	0274
		0284	0294	0349	0372	0375	0379
		0398	0401	0440	0441	0466	0482
		0498					
	SAT	0216	0228	0241	0245	0255	0352
		0369	0413	0446	0516		
	DVD	0237	0360	0468			
	TNT	0228	0352		VCR	0265	0284
COLORADO	SAT	0216					
COLOR MAT	TV	0221					
COLUMBIA	TV	0209					
COLUMBUS	SAT	0413	0414	0439	0609	1529	
	DVD	0394					
COMAG	SAT	0475	1033	1103		TNT	0475
COMET	TV	0199	0319	0330	1267		
	DVD	0534	0568				
COMPUTRON	TV	0199	0325	COMMLINK	SAT	0326	
COMSAT	TV	0234					
	SAT	0234	0236	0253	0267	0310	0445
		1076		DVD	0234	0236	
	TNT	0234	0236	0267	0310	1076	
COMTEC	SAT	0486					
COMWELL	SAT	0409	0612	TNT	0409		
CONAX	SAT	0409		TNT	0409		
CONCERTO (LG)	TV	0198	0199	0200	0201	0202	0204
		0206	0212	0214	0215	0222	0231
		0239	0244	0251	0271	0272	0275
		0287	0339	0365	0386	0411	0471
		0509	0515	0530	0667	0712	0727
	SAT	0202	0251	0449			
	TNT	0202					

Brand	Type	Code						
CONCERTO (LG)	DVD	0200	0204	0301	0458	0700		
	VCR	0204	0251	0271	0303	AUX	0515	
CONCORD	SAT	1031						
CONDOR	TV	0198	0199	0200	0202	0203	0204	
		0207	0230	0235	0256	0318	0503	
	SAT	0202	0292					
	DVD	0200	0204	TNT	0202			
	VCR	0204	0207	0210	0218	0219		
CONFORAMA	VCR	0218	0219	0223	0261	0265	0283	
		0302						
CONFORAMA (SONOLOR)	TV	0325		CONIC	TV	0239	0358	
CONNEXION	VCR	0261	0283					
CONNEXIONS SAT	SAT	0252			CONRAC	TV	0379	
CONRAD	TV	0202						
	SAT	0202	0343	0397	0550	0751		
	TNT	0202	0343	0397	0550	0751		
	TV	0200	0201	0203	0230	0300	0305	
CONTEC	SAT	0455						
		0393	DVD	0200	VCR	0300		
	TV	0206	0233	0247	0255	0270	0274	
		0284	0294	0349	0372	0375	0379	
		0398	0401	0440	0441	0466	0482	
	SAT	0498						
		0216	0228	0241	0245	0255	0352	
	DVD	0369	0413	0446	0468	0516		
		0237	0360					
CONTI M.	TV	0228	0352	VCR	0265	0284		
		0198						
CONTINENTAL	TV	0198	0232	0235	0349	SAT	0422	
	TNT	0422		DVD	0237	0362	0567	
COSAT	SAT	0432						
COSHIP	SAT	0246	0490	0908	TNT	0246	0490	
COSMEL	TV	0198	0199	0200	0403	DVD	0200	
COSMOS	TV	0199						
CPC	SAT	0327			CRC	TV	0209	
CROSLEY	TV	0221	0277	0318	0323			
CROWN	TV	0198	0200	0202	0214	0227	0232	
		0243	0256	0275	0286	0297	0318	
		0323	0427					
	SAT	0202	0211	0259	0299	0309	0436	
	DVD	0617						
		0200	0436	TNT	0202			
	VCR	0210	0218	0219	0309	0617		
	DVD	1233						
	TV	0199	0202	0209	0224	0453		
CRYPTO	SAT	0202	TNT	0202				
CRYSTAL	TV	0202						
CS ELECTRONICS	TV	0201	0287		CSN	SAT	1071	
CTC CLATRONIC	TV	0198	0199	0201	0203	0204	0206	
		0212	0215	0227	0230	0235	0256	
		0260	0318	0323				
	DVD	0204	0483	0507	VCR	0204		
	TV	0198	0199	0201	0202	0206	0207	
CXC (EMERSON)	TV	0221	0222	0227	0232	0235	0243	
		0247	0251	0280	0286	0287	0290	
		0297	0318	0333	0403	0412	0415	
	SAT	0723						
		0202	0251	DVD	0483	0507		
		0202		VCR	0207	0210	0251	
	DVD	0340						
		0484		CYFRA	PLUS	SAT	0229	
	TV	0201	0217	0222				
CYBERCOM	DVD	0340						
CYBERHOME	DVD	0484						
CYMATIC	TV	0201	0217	0222				
CYV	TV	0199	0200	DVD	0200			
DAEWOO	TV	0198	0199	0200	0201	0215	0220	
		0242	0268	0314	0324	0383	0433	
		0454	0528	0586	0623	0725		
	SAT	0216	0249	0259	0393	0611	0683	
	DVD	1383		TNT	1383			
		0200	0293	0301	0416	0428	0513	
		0641	0775	0778	0783	0784	0785	
	VCR	0210	0218	0219	0223	0295		
	TV	0268						
DAICHI	TV	0201						
DAINICHI	TV	0201						
DAK	SAT	0419		TNT	0419			
DALMAN	TV	0454			DALTON	DVD	0698	
DANSAL	TV	0199	0201	0239	0407			
	DVD	0293	0416					
DANSAT	SAT	0245						
DANTAX	TV	0202	0260		SAT	0202	0211	
	DVD	0533			TNT	0202		
DANYSTAR	SAT	1395			TNT	1395		
DARTY	SAT	0548	0737		DATCOM	SAT	1031	
DATRONIC (DAEWOO)	TV	0198	0199	0200	0201	0215	0216	
		0220	0242	0268	0314	0324	0383	
		0433	0454	0528	0623	0725		
	DVD	0200	0293	0301	0428	0513	0641	
	SAT	0775	0778	0783	0784	0785		
DAWA	TV	0249	0611	0683	VCR	0210	0295	
		0199			DAXIS	SAT	1301	

Brand	Type	Code					
DAYMATER (MAGNADYNE)	TV	0207	0221	0222	0227	0232	0314
DAYTEK	TV	0198	0716	0765			
	DVD	0293	0301	1001			
DAYTON	DVD	0301	0986				
DAYTONA	SAT	0298	0304	0307			
DAYTRON	TV	0199	0200	0850			
	DVD	0200		VCR	0210	0218	0219
DAYTRONIC (DAEWOO)	TV	0198	0199	0200	0201	0215	0220
		0242	0268	0314	0324	0383	0433
		0454	0528				
	SAT	0216	0249	0293	0611	0683	
	DVD	0200	0301	0428	0513	0641	0775
		0778	0783	0784	0785		
	VCR	0210	0295				
D-BOX	SAT	0467		DBOX-DF1	SAT	0560	
DCE	TV	0215		DDC	SAT	0249	0434
DEBOXX	DVD	1156					
DECCA	TV	0198	0200	0201	0209	0214	0324
		0338	0356	0442	0525	DVD	0200
DECCA.TATUNG	VCR	0261	0367				
DE GRAAF	TV	0202	0207	SAT	0202		
	TNT	0202		VCR	0261		
DELFA	SAT	0351		DELSAT	SAT	0430	
DELTA	SAT	0842		DELTON	TV	0215	
DELTALINE	SAT	0399	TNT	0399			
DELTASAT	SAT	0430		DEITRON	TV	0199	
DEMACOLOR	TV	0198	0207	DENKO	TV	0203	
DENON	DVD	0595	0888				
DENTAL (FORMENTI)	TV	0198	0199	0201	0202	0203	0204
		0206	0207	0212	0214	0217	0220
		0231	0232	0235	0240	0242	0247
		0258	0277	0285	0339		
	SAT	0202	0292	DVD	0204	0255	
	TNT	0202		VCR	0204	0207	0210
DENVER	TV	0202	0280				
	SAT	0202	1302	1380	TNT	0202	1380
	DVD	0428	0507	0720	0992		
DESAY	DVD	0643	1214				
DESMET	TV	0198	0199	0202	0206	0217	0235
		0258	0442				
	SAT	0202	TNT	0202			
DEUTSCH	VCR	0210		DEWO	TV	0230	
DHS (ASTRA)	TV	0201	0209	0220	0239	0358	0975
	SAT	0245	0486	0659	1019	1020	
DIADEM	TV	0402					
DIBOSS	TV	0576	0757				
DIAMOND	TV	0200	0220	0272	0573	0765	0845
DICRA	SAT	0269	0464	0477	0749		
	DVD	0545		TNT	0269	0477	0749
DIEVO	SAT	0354		TNT	0354		
DIGATRON	TV	0199	0200	DVD	0200		
DIGIAN	SAT	0418					
DIGICOM	SAT	0397		TNT	0397		
DIGIFUSION	SAT	0259	0931	DIGIFREE	SAT	0259	
DIGIFOX	SAT	0751		TNT	0751		
DIGIHOME	TV	0215	0379	SAT	0211	DVD	0225
DIGILINE	TV	0202	SAT	0202	TNT	0202	
DIGIMASTER	SAT	0254	0491		TNT	0254	0491
DIGIQUEST	SAT	0246	0269	0329	0351	0354	0397
		0399	0435	0472	0474	0542	0254
		0492	0495	0551	0552	0558	0572
		0735	0746	0748	0749	1026	1480
		1481	1482				
	DVD	0474	1240				
	TNT	0246	0254	0269	0354	0397	0399
		0435	0495	0551	0552	0748	0749
DIGITAL +	SAT	0446		DIGIT ALL	SAT	0635	
DIGISAT	SAT	0477	0551	0553	0558	0749	
	TNT	0477	0551	0553	0749		
DIGISKY	SAT	0246		TNT	0246		
DIGITAL	SAT	0211	0312	0335	0343	0400	0461
		0475	0536				
	TNT	0343	0400	0461	0475		
DIGITOR	TV	0198	0200	0214	DVD	0200	
DIGITRONIC	SAT	0254	0298	0304	0307	0460	0472
		0506	1013		TNT	0254	
DIGIX	SAT	0495			TNT	0495	
DIGIZAP	SAT	0259					
DIK	TV	0199	0200		DVD	0200	0340
DIKOM	TV	0234					
	SAT	0234	0558	1395	1398	1424	
	DVD	0234		TNT	0234	1395	1398
DIKON	TV	0874					
DINASTY	TV	0202	0220	SAT	0202	TNT	0202
DIPRO	TV	0228					
	SAT	0329	0354	0409	0551	0552	
	TNT	0354	0409	0551	0552		

Brand	Type	Code					
DISEQC	SAT	0298	0304	0307	0335	0527	
DISISTRAT	TV	0308		SAT	0273	0282	0308
DISTAR	TV	0198	0230	DISTRA	SAT		0353
DISTRATEL	SAT	0279	0298	0304	0307	0353	0494
		0518	0602	0603	0619	0653	0689
		0933	0934	1036		TNT	0619
DISTRISAT	SAT	0273		DIUNAMAI	SAT		1067
DIVIDO	DVD	0599	0600				
DIXI	TV	0199	0200	0370		DVD	0200
DK DIGITAL	DVD	0340		DMTECH	TV		0630
DMSIS	SAT	0400	0418	TNT	0400		
DNT	TV	0308					
	SAT	0252	0273	0282	0308	0364	
DOMEOS	TV	0198	0549				
DOMLAND (DUAL-TEC)	TV	0198	0199	0201	0202	0206	0212
		0214	0220	0222	0239	0243	0244
		0248	0250	0268	0272	0275	0287
		0289	0315	0323	0365	0376	0410
		0443	0453	0549			
	SAT	0202	DVD	0278	0340		
	TNT	0202	VCR	0210	0223		
DOMOH	TV	0198	0199	0232	VCR	0213	
DORIC	TV	0233					
DPM	SAT	1382	TNT	1382			
DRACON	DVD	0340		DRAGON BOX	SAT		0677
DRAKE	SAT	0312	0353	0487	0536	0820	0910
		0957					
	DVD	0394	TNT	0820			
DREAMBOX	SAT	0246	0648	1069	1136	1137	
	TNT	0246					
DSR	SAT	0236	0246	0254	0267	0400	
	DVD	0236					
	TNT	0236	0246	0254	0267	0400	
DTT	SAT	0540					
DTS	TV	0199	0244		Dualis	SAT	1038
DUAL	DVD	0278	0340	VCR	0223		
DUAL-TEC	TV	0212	0214	0220	0222	0239	0243
		0244	0248	0250	0268	0272	0275
		0287	0289	0290	0315	0323	0365
		0376	0410	0443	0453	0549	
DUMONT	TV	0198	0199	0207	0221	0227	0232
		0247	0256	0258	0277	0318	0423
	VCR	0207					
DUNAI	TV	0222					
DUNE	SAT	0421		TNT	0421		
DURABRAND	TV	0202	0215	0424			
	SAT	0202		TNT	0202		
DUX	TV	0200		DVD	0200		
DVB	TV	0234					
	SAT	0234	0236	0253	0269	0312	0543
		1087		DVD	0234	0236	
	TNT	0234	0236	0269	0543		
D-VISION	TV	0198	0200	0268	0433		
	SAT	0211		DVD	0200		
DVR01 / EH-M1	SAT	0815		TNT	0815		
DYNASAT	SAT	0249	0425	0521	0659		
DYNAMTC	TV	0256					
DYNATRON(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0289	0311	0317	0319	0333
		0336	0344	0368			
	SAT	0205	0229	0241	0245	0262	0263
		0313	0328	0331	0332	0341	0350
		0359	0368	0382	0392		
	DVD	0200	0266	0306	0390	0391	
	TNT	0205	0263	VCR	0223	0261	0271
EASY2	SAT	0574		TNT	0574		
EASY3	SAT	0547		TNT	0547		
EASYLIVING	TV	0629	0631	0861	0969	0971	1066
	SAT	1053	1438				
EASY-ONE	SAT	0312	0553	0753	TNT	0553	0753
E-BODA	DVD	1236		ECHOLITE	SAT		0312
ECHOSTAR	TV	0198	0201	0234			
	SAT	0216	0234	0236	0246	0253	0254
		0267	0329	0420	0422	0446	0448
		0627	0733	0790	0799	0843	0911
		0915	0921	0930	0959		
	DVD	0234	0236	0394			
	TNT	0234	0236	0246	0267	0422	
ECO LINE	TV	0198					
EDAN LINE	TV	0198	0202	0207	SAT	0202	
	TNT	0202	VCR	0207	0210		
EDENWOOD	TV	0090		EDISION	SAT		0435
EDISON	TV	0349					
EI	TV	0198	0204	0206	0248	0260	0286
	DVD	0204	VCR	0204			
EIF	SAT	0353					

Brand	Type	Code					
EINHELL	SAT	0249	0299	0327			
EL	TV	0629	0631	0969	0971	1066	
ELAP	TV	0234					
	SAT	0216	0234	0236	0253	0267	0335
		0461	0664		DVD	0234	0236
	TNT	0234	0236	0267	0461	0664	
ELBE	TV	0198	0201	0202	0206	0207	0212
		0214	0217	0222	0264	0258	0291
		0315	0330	0344	0346	0383	0389
		0402	0454	0457	0578	0665	0770
		0769	0951	0982			
	SAT	0202	0211	0269	0337		
	DVD	0904	0999	1008	1009	1010	
	TNT	0202	0269	0337			
	VCR	0207	0210	0213	0218	0219	0303
ELCIT (MAGNADYNE)	TV	0207	0217	0221	0222	0227	0232
		0277	0314	0426		VCR	0207
ELG	TV	0199	0200		DVD	0200	
ELEKTA	TV	0199	0203	0209	0220	0230	
	VCR	0210					
ELEKTRONIKA	TV	0286	0585				
ELEKTRONSKA IND.	TV	0206	0217				
ELEMIS	TV	0202	0206	0297			
	SAT	0202		TNT	0202		
ELIN	TV	0199	0201	0207	0231	0244	0248
		0325	0423				
	SAT	0417		VCR	0207	0283	
ELITE	TV	0199	0203	0235			
ELLEVISION	TV	0203	0674				
ELMAN	TV	0201	0217	0222	0227	0290	0593
ELSAY	TV	0198					
ELTA	TV	0199	0203	0240	0323		
	SAT	0249	0273	0292	0320	0436	
	VCR	0210		DVD	0293	0416	0436
ELLIES	SAT	0733	1143		ELLION	DVD	0545
ELSAT	SAT	0253	0404		EMANON	SAT	0249
EMATEC (OCEANIC)	TV	0207	0231	0233	0248	0285	0325
		0348	0357	0355	0361	0373	0374
		0387	0502	0579			
	SAT	0229	0417	0418	0444	0467	
	VCR	0207	0223				
E-MAX	DVD	0597					
EMCO (IMPERIAL)	TV	0198	0199	0202	0204	0207	0212
		0222	0240	0256	0258	0314	0317
		0318	0323	0376			
	SAT	0202	0369	DVD	0204		
	TNT	0202		VCR	0204	0207	
EMERSON	TV	0198	0199	0201	0202	0206	0207
		0221	0222	0227	0232	0235	0243
		0247	0251	0280	0286	0287	0290
		0297	0318	0333	0403	0412	0415
		0723	SAT	0202	0251		
	TNT	0202	VCR	0207	0251		
EMME ESSE	SAT	0228	0229	0292	0425	0444	0445
		0448	0496	0521	0556	0606	0659
		0827	1015	1027	1077	1078	1079
		1080	1379				
	DVD	0394	TNT	0228	1379		
E-MOTION	DVD	1001		EMTECH	SAT	0496	
ENGEL	TV	0206					
	SAT	0211	0246	0267	0269	0310	0337
		0371	0419	0437	0438	0464	0517
		0555	0650	0678	1410	1512	
	DVD	0234	0236				
	TNT	0234	0236	0246	0254	0267	0269
		0310	0337	0371	0419	0438	
ENIE	TV	0199					
ENZER	TV	0948	0955	DVD	0301		
EP SAT(PACE)	SAT	0229	0241	0245	0262	0414	0469
		0487	0561	0601	0614	0616	0654
		0708					
EQUATOR	SAT	0245		EROICA	TV	0239	
ERRES(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0289	0311	0317	0319	0333
		0336	0344	0368			
	SAT	0205	0229	0241	0245	0262	0263
		0313	0328	0331	0332	0341	0350
		0359	0368	0382	0392		
	DVD	0200	0266	0306	0390	0391	
	TNT	0205	0263	VCR	0223	0261	0271
ESC	TV	0198	0199	0200	0201	0297	
	DVD	0200	VCR	0210	0218	0219	
E-SPACE	SAT	0254	0421	0438	0555	0558	0797
		0825	1395				
	TNT	0254	0421	0438	1395		
ESTEL	TV	0206					

Brand	Type Code						
ETCO	TV	0308	SAT	0273	0282	0308	0617
	DVD	0306	TNT	0617			
ETRON	TV	0199	0721	0728	1346		
EULANDER(ELBE)	TV	0198	0201	0202	0206	0212	0214
		0217	0222	0258	0264	0291	0315
		0330	0344	0346	0383	0389	0402
		0454	0457	0578	0665	0770	0769
		0951	0982		SAT	0202	0337
	DVD	0903	0999	1008	1009	1010	
	TNT	0202	0337		VCR	0210	0303
	EUMIG	TV	0207	0235		VCR	0207
EURIELT	SAT	0279	0353	0653			
EUROCOM	TV	0206					
EURODEC	SAT	0924	0925	1028	1029		
EUROLINE	TV	0198	0263		SAT	0263	0617
	DVD	0992			TNT	0263	0617
EUROMAN	TV	0199	0201	0203	0297		
EUROPA	TV	0199	0200	0282	0308		
	SAT	0273	0308	0351	0487	0546	0659
		1019	1020		DVD	0200	0546
EUROPHON	TV	0201	0206	0217	0222	0227	0235
		0479					
	SAT	0343	0490		TNT	0343	0490
EUROPLUS	SAT	0609					
EUROSAT	SAT	0253	0254	0267	0299	0320	0472
		1028			TNT	0254	0267
EUROSKY	SAT	0211	0298	0299	0304	0307	0343
	TNT	0343					
EUROSTATUS	TV	0202	SAT	0202	TNT	0202	
EUROSTAR	SAT	0557	0717	EUROVISION	TV	0260	
EUTELSAT	SAT	0298	0304	0307			
EUTRA	SAT	0505	0687		EVELUX	TV	0453
EXCEL	TV	0199	0200	0207			
	DVD	0200		VCR	0207		
EXITV	SAT	0615					
EXPERT	TV	0244	0285	0374	DVD	0225	
EXQUISIT	TV	0199		DVD	0200		
FAIR VIDEO	VCR	0213					
FAIRMATE	SAT	0216	0269	0399	0435	0572	0610
		0710	0798	0819	1307		
	TNT	0269	0399	0819			
FAIT	SAT	0216	0252	0299	0425	0748	
	TNT	0748					
FAGOR	TV	0199	0240		FALCON	SAT	0414
FAMILY LIFE	TV	0199	0200	DVD	0200		
FELIX	TV	0198	0203				
FENNER	TV	0199	0220	0224	0230	0585	
	SAT	0211	0216	0236	0249	0259	0292
		0335	0450	0451	0487	0505	0539
		1116	TNT	0236	VCR	0210	
	DVD	0236	0405	0539	0566	0901	
FERGUSON(THORN)	TV	0199	0203	0207	0209	0255	0264
		0270	0282	0284	0375	0378	0525
		0531	0592	0593	0622		
	SAT	0241	0245	0255	0259	0288	0327
		0378	0404		TNT	0288	
	VCR	0207	0213	0218	0219	0265	0284
FIDELIS	TV	0201	0202	0358			
	SAT	0202			TNT	0202	
FIDELITY	TV	0199	0201	0239	0250	0338	0532
	SAT	0404	1023		DVD	0625	
	VCR	0283	0625				
FILMNET	TV	0308					
	SAT	0229	0273	0282	0308	0313	
FILSAI	TV	0201					
FINLANDIA	TV	0207	0231	VCR	0207		
FINLUX	TV	0198	0199	0202	0206	0207	0212
		0215	0224	0227	0247	0256	0271
		0277	0291	0316	0318	0324	0330
		0348	0357	0406	0423	0442	0479
		0501	0715				
	SAT	0202	0293	0417	0606	DVD	0225
		0207	0218	0219	0223	0261	0271
	VCR	0316				TNT	0202
	FIRST LINE	TV	0198	0199	0200	0201	0202
0209			0214	0215	0220	0222	0235
0264			0285	0323	0324	0330	0338
0376			0379	0402	0426	0427	0454
0502							
SAT	0202	0211	0617				
	DVD	0200	0225	0278	0545	0643	0696
	TNT	0202	0617				
	VCR	0213	0218	0219	0367		
FISHER	TV	0201	0207	0221	0250	0277	0286
		0289	0296	0305	0316	0370	0388
		0415	0423	0455	0476	0672	1040
	DVD	0695	0697		VCR	0207	0316
FLINT	TV	0199	0346		VCR	0223	

Brand	Type	Code					
FLORIDA	TV	0201					
FLYCOM	SAT	0246	0490		TNT	0246	0490
FM	SAT	0320	0432				
FMD	SAT	0211	0246		TNT	0246	
FNR	TV	0227					
FONESTAR	SAT	1056	1088				
FORCE	TV	1246	1247		SAT	1124	1528
FORGESTONE (THORN)	TV	0199	0203	0207	0209	0255	0264
		0270	0282	0375	0378	0525	0531
		0592	0593	0622			
	SAT	0241	0245	0254	0255	0259	0288
		0378	0404				
FORMENTI	TV	0254	0288	VCR	0207	0265	0378
		0198	0199	0201	0202	0203	0204
		0206	0207	0212	0214	0217	0220
	SAT	0231	0232	0235	0240	0242	0247
		0285	0290	0339			
FORTEC STAR	SAT	0202	0292	DVD	0204	0225	
		0204	0207	0210	0213	0218	0219
	VCR	0285		TNT	0202		
FORTEC STAR	SAT	0254	0329	0472	TNT	0254	
FORTRESS	TV	0221					
FOXTEL(AU)	SAT	0922			FRABA	TV	0198
FRACARRO	TV	0234					
	SAT	0211	0216	0228	0229	0234	0236
		0249	0253	0267	0310	0312	0321
		0322	0328	0329	0363	0395	0414
		0425	0429	0448	0469	0493	0506
		0602	0603	0718	0748	0929	1021
		1025	1030	1047	1407	1526	
	DVD	0234	0236	0533	1005		
	TNT	0228	0234	0236	0267	0310	0748
FRANCE TELECOM	TV	0308					
	SAT	0273	0282	0308	0313	0352	0550
		0548					
	TNT	0352	0550				
FREEBOX	SAT	0801	1193	1491	1493	1709	
FREECOM	TV	1712					
	SAT	0249	0449	0571	1713		
	DVD	0594	1570	1710	1711		
FREEONE	SAT	0253	0429				
FREESAT	SAT	0126	0249	0385	0487	0491	1144
		1308	1713	1715			
FREE WAVE	TV	0234	1708				
	SAT	0168	0234	0236	0253	0267	0335
		0496					
	DVD	0234	0236	TNT	0234	0236	0267
FRIAC	TV	0199	0200	0227	DVD	0200	
FRONTECH	TV	0222	0231	0239	0287	0323	0511
FTE MAXIMAL	SAT	0236	0253	0267	0320	0321	0322
		0393	0425	0432	0487	0505	0537
		0546	0556	0637	0718	0829	0917
		1033	1144				
	DVD	0236	0546		TNT	0236	0267
FUBA	TV	0234					
	SAT	0211	0234	0236	0249	0252	0253
		0267	0288	0292	0298	0304	0307
		0327	0353	0364	0437	0439	0445
		0450	0492	0493	0679	0685	0744
		0745	0820	0828	1027	1297	1300
		1303	1305	1359	1403	1404	1408
		1512					
	DVD	0234	0236	0394			
	TNT	0234	0236	0267	0288	0744	0820
FUJI	TV	0230	0542	FUJITECH	TV	0199	
FUJI ONKYO	SAT	0335	0434	0506	0743	0753	
	TNT	0743	0753				
FUJITSU	TV	0198	0199	0201	0202	0227	0239
		0244	0315	0347	0365	1065	1249
	SAT	0202		TNT	0202		
FUMEO	SAT	0365					
FUNAI	TV	0202	0203	0206	0215	0296	0424
		0531	0875				
	SAT	0202	DVD	0625			
	TNT	0202	VCR	0625			
FURICHI	TV	0573					
FUSION	TV	0215	0379		SAT	0259	0931
FUST	SAT	0326			FUTRONIC	TV	0203
FUTURE	TV	0199	0200	DVD	0200		
FUTURETECH	TV	0198	0199	0201	0202	0206	0207
		0221	0222	0227	0232	0235	0243
		0247	0251	0280	0286	0287	0723
		0290	0297	0318	0333	0403	0412
		0415					
	SAT	0202	0251		TNT	0202	
		0207	0210	0251			
GALA	TV	0239	0358				
GALACTEX	TV	0201	0203		GALANT	TV	0230

Brand	Type	Code					
GALAXI (FORMENTI)	TV	0198	0199	0201	0202	0203	0204
		0206	0207	0212	0214	0217	0231
		0232	0235	0240	0242	0247	0258
		0277	0285	0339			
	SAT	0202	0292	DVD	0204	0225	
GALAXY-GALAXIS	TNT	0202	VCR	0204	0207	0210	0213
	TV	0198	0201	0204	0214	0234	0256
	SAT	0323					
		0229	0234	0236	0253	0259	0267
		0320	0326	0351	0380	0396	0409
0432		0437	0465	0474	0491	0527	
GALWAY	DVD	0612	0691	0692	0742	0747	0795
		0819	1385	1386	1387	1512	
		0204	0234	0236	0381	0474	
		0234	0236	0267	0409	0491	0692
	TNT	0742	0747	0819	1385	1386	1387
GBC-GBS	VCR	0204	0213	0218	0219		
	VCR	0218	0219				
	TV	0199	0220	0222	0230	0277	0287
	SAT	0305	0314	0324	0630		
		0310	0397	0438	0553	1405	
0310		0397	0438	0553	1405		
GEANT-CASINO (OCEANIC)	VCR	0210	0218	0219			
	TV	0207	0231	0233	0248	0285	0325
	SAT	0348	0355	0357	0361	0373	0374
		0387	0502	0579			
		0229	0417	0418	0444	0467	
GEBER	VCR	0207	0223				
	TV	0248					
	TV	0198	0199	0201	0231	0324	0361
	SAT	0442	0761	0844	1252		
		0465					
GECCO	SAT	0465					
	TV	0217	0220	0222	0233	0277	0314
	VCR	0218	0219				
		0199	0201	0209	0220	0268	0305
		0397	1375	TNT	0397	VCR	0303
GELOSO	TV	0251	0255	0270	1269		
	SAT	0251	0255	VCR	0251	0283	
	TV	0220					
	TV	0199	0200		DVD	0200	
	TV	0200	0248	DVD	0200	VCR	0213
GENERAL	TV	0201	0202	0244	0347		
	SAT	0202		TNT	0202		
	TV	0311					
	SAT	0435	0485		GF	SAT	0396
	TV	0201	0209	0639		DVD	0639
GENERAL ELECTRIC	TV	0198	0209	0270	0384		
	VCR	0213	0218	0219	0223	0261	0265
		0283	0302	0367			
		SAT	0489	0826			
	GENERAL TECHNIC	SAT	0342	0826			
DVD		0237	0362		TNT	0342	
SAT		0335	0475	0489	TNT	0475	
TV		0199	0203	0531			
SAT		0299		GOLDBOX	SAT	0229	
GENEXXA	TV	0976	0703	DVD	0597		
	SAT	0342	0677	TNT	0342		
	SAT	0746		GOLDFUNK	TV	0398	
	TV	0201		GOLDLINE	TV	0346	
	SAT	0491		TNT	0491		
GENERAL CORPORATION	TV	0198	0199	0201	0202	0204	0206
		0212	0214	0215	0222	0231	0239
		0244	0251	0271	0272	0275	0287
		0339	0386	0411	0471	0509	0515
		0530	0667	0712	0727		
GERICOM	SAT	0202	0251	0353	0365	0449	0450
	DVD	0200	0204	0301	0458	0700	
	VCR	0204	0213	0251	0271	0303	
	TNT	0202		AUX	0515		
	TV	0198	0202	0243			
GE SER	SAT	0202		TNT	0202		
	TV	0230	SAT	0259	0523	TNT	0523
	TV	0198	0199	0201	0203	0207	0215
	VCR	0230	0412	0481			
		0207	0210				
GIANT	TV	0198	0199	0200	0201	0202	0203
		0214	0215	0220	0222	0243	0255
		0260	0268	0270	0273	0275	0282
		0308	0407	0433			
		SAT	0202	0211	0255	0259	0308
GITEM	DVD	0200	0225	0278	0645	0782	0891
	TNT	0202	0210				
	VCR	0218	0219	0223	0261	0295	
	TV	0198	0255	0260	0286	0415	0453
		0585	0965		SAT	0255	
GLOBAL	DVD	0597		GO.VIDEO	DVD	1154	
	TV	0203	0239				
	SAT	0681	GRADIENTE	SAT	0681	1043	

Brand	Type	Code					
GRAETZ (ITT)	TV	0198	0199	0202	0203	0207	
		0231	0233	0244	0247	0248	0250
		0256	0260	0285	0296	0347	0348
		0355	0361	0387	0388	0412	0423
		0478	0532				
	SAT	0202	0788	DVD	0225		
TNT	0202	VCR	0207	0261			
GRANADA	TV	0198	0199	0202	0203	0207	0231
		0233	0244	0248	0250	0256	0260
		0271	0285	0294	0296	0347	0348
		0355	0361	0387	0388	0412	0423
		0478	0532				
	SAT	0202	0241	0327	0654	TNT	0202
VCR	0207	0218	0219	0261	0271	0367	
GRANDE (FORMENTI)	TV	0198	0199	0201	0202	0203	0204
		0206	0207	0212	0214	0217	0220
		0231	0232	0235	0240	0242	0247
		0258	0285	0290	0339		
		0202	0292	DVD	0204	0225	
	TNT	0202	VCR	0204	0207	0210	
GRANDIN	TV	0198	0200	0202	0206	0212	0214
		0215	0230	0235	0268	0275	0285
		0311	0330	0346	0454	0528	0977
		0202	0211	0279	0309	0353	0602
		0603	0653				
	DVD	0200	0237	0362	0567	0699	0702
TNT	0202	0719	0781	0873			
VCR	0210	0213	0218	0219	0295	0309	
GRANPRIX	SAT	0343		TNT	0343		
GREAT WALL	TV	0203	0403				
GREENTECH	SAT	0310		TNT	0310		
GRENADIER	TV	0199	0206	0251	0562		
	SAT	0251		VCR	0210	0251	
GRUNDIG	TV	0263	0291	0294	0308	0349	0366
		0383	0384	0462			
	SAT	0216	0241	0259	0263	0271	0273
		0282	0288	0308	0309	0412	0447
	DVD	0587	1018	1034	1035		
		0513	1007				
TNT	0263	0288	VCR	0223	0271	0309	
GRONIC	TV	0201	0206	0222	0562		
GROTHUSEN	SAT	0249	0449				
G-SAT	SAT	0245					
GTT	TV	0198	0202	0230	0256	0280	
	SAT	0202		TNT	0202		
GTRONIC	TV	0198	0541		GUTTA	TV	0541
GVG	DVD	0293			HADOR	TV	0573
HAIER	TV	0268	0809		SAT	0809	1392
	DVD	0301			TNT	1392	
HAIS	DVD	0670			HALIFAX	TV	0203
HAMLET	DVD	0405	0706				
HAMMERSTEIN	TV	0201	0203	0721			
HAMPTON	TV	0201	0277				
HANNOVER	TV	0427		HANNSPREE	TV	0861	
HANSEATIC	TV	0198	0199	0201	0206	0215	0217
		0230	0232	0235	0240	0242	0248
		0250	0268	0280	0297	0300	0358
		0433					
		SAT	0404	0431	0685		
	VCR	0213	0223	0300	0303		
HANTAREX	TV	0198	0217	0227	0311	0862	
	SAT	1361	TNT	1361	VCR	0213	
HANTOR	SAT	0249					
HANURI (LA SAT)	SAT	0292	0380	0488	0605	0791	
	DVD	0381					
HARMAN KARDON	DVD	1215		VCR	0303	0367	
HARROW	TV	0090	0202				
	SAT	0202	TNT	0202			
HARWOOD	TV	0199	0200	DVD	0200		
HAUPPAGE	TV	0199	0200	DVD	0200		
HAVEG	TV	0316		VCR	0265	0316	
HB	TV	0202	0215	0234	0410	0530	0630
	SAT	0202	0211	0234	0236	0253	0399
	DVD	0452	0485	0610	1115		
		0234	0236	0237			
TNT	0202	0234	0236	0399	0452		
H&B	TV	0202		SAT	0202		
	DVD	0507	1003	TNT	0202		
HCM	TV	0199	0200	0201	0203	0222	0230
	DVD	0839					
	DVD	0200	0483				
HDD MEDIA PLAYER	DVD	1181					
HD-Z1	SAT	1045					
HE@D	SAT	0254	1127	1466	TNT	0254	
HEIRU	TV	0203	SAT	0288	TNT	0288	
HEDZON	TV	0199	0200		DVD	0200	
HENA	TV	0199					

Brand	Type	Code					
HELECTRONIC (FORMENTI)	TV	0198	0199	0201	0202	0203	0204
		0206	0207	0212	0214	0217	0220
		0231	0232	0235	0240	0242	0247
		0258	0277	0285	0339		
	SAT	0202	0292	DVD	0204	0225	
	TNT	0202		VCR	0204	0207	0210
HELIOCOM	SAT	0556					
HEMMERMANN	TV	0227	0250	0426	0479		
HEXA	TV	0206					
HIFIVOX (THOMSON)	TV	0206	0233	0247	0255	0270	0274
		0294	0349	0352	0372	0375	0379
		0398	0401	0440	0441	0466	0482
		0498					
	SAT	0216	0228	0229	0241	0245	0255
		0262	0369	0413	0446	0516	
	DVD	0237	0360	0468			
	TNT	0228	0352	VCR	0265		
HIGASHI	TV	0201					
HIGHIWA (KAISUI)	TV	0198	0201	0230	0346	0427	
HIGHLINE	TV	0199	0200	DVD	0200		
HILINE	TV	0198	0203				
HILLTECKS	DVD	0701					
HINARI	TV	0199	0203	0233	0239	0356	0370
		0412					
	SAT	0245	0249	0309			
	VCR	0218	0219	0309			
HIKONA (KAISUI)	TV	0198	0201	0230	0346	0427	
HIMAGE	DVD	0533					
HIRSCHMANN	TV	0234					
	SAT	0234	0236	0252	0253	0259	0267
		0288	0292	0310	0327	0328	0343
		0345	0364	0425	0445	0474	0475
		0486	0506	0521	0538	0636	0658
		0679					
	DVD	0234	0236	0474			
	TNT	0234	0236	0267	0288	0310	0343
		0345	0475				
HISAWA	TV	0198	0215	0346			
	SAT	0321	0322	0363			
HISENSE	TV	0200	0231	0471	1329	1531	1532
		1533	1534	1535	1536	1537	1538
		1539	1540	1541	1542	1543	1544
		1545	1546	1547	1548	1549	1550
		1551	1552	1555	1556	1557	1559
		1560	1562	1564	1565	1566	1567
		1568	1569				
	DVD	0200	0293	1553	1554	1558	1561
		1563					
HISHITO (TOSHIBA)	TV	0202	0215	0260	0305	0358	0366
		0407	0456	0462	0480	0503	0524
		0673	0675	0729			
	SAT	0202	0241	0652			
	DVD	0632	TNT	0202	VCR	0480	
HIT	TV	0221					
HITACHI	TV	0201	0202	0231	0233	0239	0242
		0251	0260	0268	0274	0305	0325
		0348	0357	0358	0361	0373	0398
		0401	0411	0433	0501	0588	0761
		0762	0835	0840	0844	1272	1319
		1320	1326	1328	1332	1335	1349
		1714					
	SAT	0202	0241	0251	0259	0417	
	DVD	0225	0362	0598	1216	1217	1313
	TNT	0202	VCR	0223	0251		
HITEKER	DVD	0408	0534	0568	0705	1218	
HITSU	TV	0199	0346				
HIVISION	SAT	0399	TNT	0399			
HOHER	TV	0202	0212	0215	0260	0311	0410
		0576					
	SAT	0202	0575	DVD	0225	0340	0646
	TNT	0202		VCR	0218	0219	
HOMECAST	SAT	0399	0572	0610	0710	0798	1105
		1123		TNT	0399		
HOME ELECTRONICS	TV	0863					
HOMETECH	SAT	0575	DVD	0646			
HORIZONT (PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0289	0311	0317	0319	0333
		0336	0344	0368			
	SAT	0205	0229	0262	0263	0313	0328
		0331	0332	0341	0350	0359	0368
		0392					
	DVD	0200	0266	0306	0390	0391	
	TNT	0205	0263	VCR	0223	0271	
HORNYPHON	TV	0199	0200		DVD	0200	
HOSHAI	TV	0202	0230	0243			
	SAT	0202	TNT	0202			

Brand	Type Code							
HOSPITALIERE	TV	0202						
	SAT	0202	TNT	0202				
HOT	SAT	1140						
HOTCHIP	SAT	0345	TNT	0345				
HOUSTON	SAT	0321	0322	0363	0634			
HOWELL	TV	0202	SAT	0202	TNT	0202		
HR	SAT	1057						
HUMAX	TV	0120	0121	0122	0123	0125	0126	
		0127	0132	0133	0141	0142	0157	
		0162	0166	0171				
	SAT	0119	0120	0121	0123	0126	0127	
		0128	0129	0130	0131	0134	0142	
		0144	0145	0147	0150	0151	0152	
		0154	0156	0161	0163	0165	0166	
		0171	0172	0173	0177	0179	0180	
		0182	0183	0186	0188	0193	0194	
		0195	0254	0259	0282	0312	0351	
		0397	0474	0741	0751	0912	1114	
		1117	1375					
	DVD	0157	0181	0474	AUX	0141		
	TNT	0397	0740	0741	0751	1375		
	SAT	0298	0299	0304	0307	0326	0380	
		0445	0451	0473	0535	0544	0556	
		0647	0709	0473	0535	0544	0647	
		0709			DVD	0381		
HYD	TV	0865	0978		DVD	0895	1183	
HYDRA	SAT	0253						
HYPER	TV	0198	0199	0201	0203	0206	0222	
		0230	0232	0239	0240	0280	0288	
		0837			VCR	0218	0219	
HYPSON	TV	0198	0202	0212	0215	0217	0243	
		0268	0275	0297	0330	0353	0755	
	SAT	0202	0309	TNT	0202			
	VCR	0213	0218	0219	0309			
HYRO	SAT	0551		TNT	0551			
HYUNDAI	TV	0202	0234	0383	0809	0877	1262	
		1278	1288					
	SAT	0202	0234	0400	0418	0430	0683	
		0809	0211	0920	1367	1377		
	DVD	0234	0293	0545	0704	0963	0987	
	TNT	0202	0234	0400	1367	1377		
IBERIA	TV	0199	0457					
IBEROSAT	SAT	1301		IBERVISAO	TV	0250		
I CAN	TV	0263						
	SAT	0228	0263	0329	0464	0807	0818	
		0828	1467					
	TNT	0228	0263	0818				
ICE	TV	0198	0200	0201	0203	0209	0323	
	SAT	0795		DVD	0200			
ICS	TV	0201	0203					
ICX INTERNATIONAL	SAT	0488	0796		IEG	TV	0201	
I JOY	SAT	0421	0452	0615	1299			
	TNT	0421	0452					
IKUSI	SAT	0824		TNT	0824			
ILLUSION sat	SAT	0691	0824	1031	TNT	0824		
IMC	TV	0499						
IMEX	SAT	0353	0395	0653				
IMPERIAL	TV	0198	0199	0202	0203	0204	0207	
		0212	0222	0240	0256	0258	0314	
		0318	0323	0376				
	SAT	0202	0369	1396	DVD	0204		
		0202	1396	VCR	0204	0207	0213	
	TNT	0201	0388					
INCOBE	TV	0201	0388	INDESIT	SAT	0953		
INDIANA	TV	0199		INGELEN	TV	0248		
INGERSOLL	TV	0199						
INNO HIT	TV	0199	0201	0202	0203	0204	0217	
		0227	0230	0232	0260	0268	0276	
		0277	0280	0324	0358	0386	0522	
	SAT	0202	0211					
		0204	0225	TNT	0202	0522		
	VCR	0204	0210	0218	0219	0283		
INNOVATION	TV	0199	0200	DVD	0200			
INTERBUY	TV	0200	0203	0287	0338	0481		
	DVD	0200						
INTERDISCOUNT	TV	0198	0270	0274	0372	0591		
	SAT	0617	DVD	0306	TNT	0617		
INTEREACTIVE	TV	0199	0200	0338	DVD	0200		
INTERECON	TV	0289						
INTERFUNK	TV	0198	0199	0200	0209	0224	0238	
		0248	0256	0272	0285	0294	0355	
		0361	0372	0831				
	DVD	0200						
INTERNAL	TV	0199	0200		DVD	0200		
INTERNATIONAL	SAT	0216	0488					
	VCR	0213	0218	0219	0295			
INTERSAT(JOHANSSON)	SAT	0321	0322					
INTERSTAR	SAT	0254	0434	0461	0677	TNT	0461	
INTERVISION	TV	0200	0201	0203	0209	0222	0227	

Brand	Type	Code					
INTERVISION	TV	0240	0268	0286	0339	0366	0380
		0481					
	SAT	0320	0538	DVD	0200	0381	
	VCR	0210	0213	0218	0219	0223	0265
		0303					
INTRON	TV	0203					
INTRONIC	SAT	1088					
INVES	TV	0094	0095	0110	0112	0113	
	SAT	0259					
INWAH	TV	0268					
IOTRONIC	SAT	0569					
IRRADIO	TV	0198	0199	0202	0203	0206	0207
		0215	0234	0239	0243	0247	0251
		0280	0287	0316	0358	0386	0406
		0410	0522	0530	0541	0576	0631
	SAT	0757	0767	0965			
		0202	0228	0234	0236	0251	0253
		0267	0335	0354	0421	0490	0544
		0575	0745	0797	0910	1048	1374
	DVD	0225	0234	0236	0237	0278	0293
		0360	0362	0416	0701	0781	0997
		1152	1163	1241			
	TNT	0202	0228	0234	0236	0267	0421
		0490	0522	1048	1374		
	VCR	0207	0213	0218	0219	0223	0234
		0251	0316				
ISKRA	TV	0201	0217	0222			
ISUKAI	TV	0199	0230				
ISV (JOHANSSON)	SAT	0321	0322				
ITALTEL	SAT	0262	0448				
ITC	TV	0198	0201	0206	SAT	0216	
ITD70(SAGEM)	SAT	0420					
ITS	TV	0198	0200	0201	0203		
	SAT	0321	0322	DVD	0200		
ITT	TV	0198	0199	0203	0207	0231	0233
		0244	0247	0248	0250	0256	0260
		0285	0294	0296	0316	0347	0348
		0355	0361	0387	0388	0412	0423
		0478	0532				
	SAT	0236	0253	0267	0309	0327	0371
		0399	0788				
	DVD	0225	0236				
	TNT	0236	0267	0371	0399		
	VCR	0207	0213	0218	0219	0223	0261
		0302	0309	0316			
ITV	TV	0200	0203	0220	0314		
	SAT	0216	0350	DVD	0200	VCR	0210
JAEGER	SAT	0335					
JEC (TOSHIBA)	TV	0202	0215	0260	0305	0358	0366
		0407	0456	0462	0480	0503	0524
		0673	0675				
	SAT	0202	0241	0652			
		DVD	0632	TNT	0202	VCR	0480
JEEMON	SAT	0320		JEEWON	SAT	0320	
JEPSEN	SAT	0409	0496	0612	0615	TNT	0409
JERROLD	SAT	0769		JET POINT	TV	0198	
JINN SONIC	VCR	0210					
JMB	TV	0199	0200	DVD	0200		
JOCEL	TV	0198	0240	DVD	0882		
JOHANSSON	SAT	0321	0322				
JOHNSON	TV	0201			JOK	SAT	0539
JPS	TV	0481			JQ	DVD	0225
JRC	TV	0240		JSR	SAT	0320	0432
JUBILEE	TV	0200	DVD	0200			
JUPITER	SAT	0321	0322	0363			
JVC	TV	0511	0520	0613	0866	1264	
	SAT	0359					
	DVD	0520	0881	VCR	0265	0613	
KAIDO	TV	0231					
KAISER	TV	0199	0230				
KAISUI	TV	0198	0230	0346	0427		
KAMAR	TV	0559					
KAMBROOK	TV	0201	0203	0206	0274		
KAMM	SAT	0380	0527	DVD	0381		
KAMOSONIC	TV	0201		SAT	1057		
KAMP (FORMENTI)	TV	0198	0199	0200	0202	0203	0204
		0206	0207	0212	0214	0217	0220
		0231	0232	0235	0240	0242	0247
		0258	0277	0285	0339		
	SAT	0202	0292	DVD	0204	0225	
		TNT	0202	VCR	0204	0207	0210
	SAT	0505					
KANARY	SAT	0505					
KANGSLEY (FORMENTI)	TV	0198	0199	0201	0202	0203	0204
		0206	0207	0212	0214	0217	0220
		0231	0232	0235	0240	0242	0247
	SAT	0202	0292	DVD	0204	0225	
		TNT	0202	VCR	0204	0207	0210
	SAT	0495		TNT	0495		
KAON MEDIA	SAT	0495		TNT	0495		

Brand	Type	Code					
KAOSHO(SAMSUNG)	TV	0199	0200	0201	0203	0204	0207
		0212	0242	0251	0268	0286	0324
		0339	0358	0386	0411	0415	0443
		0559	0649	0760	0768	0954	0968
	SAT	0973					
		0251	0262	0328	0351	0393	0459
		0465	0607	0608	0635	0649	0650
	DVD	0678	0734	0961	1011	1014	1042
		0200	0204	0595	0598	0988	0993
		0996	0998	1041			
	TNT	0734	VCR	0204	0207	0251	0283
KAPSCH (ITT)	TV	0198	0199	0202	0203	0207	0231
		0233	0244	0247	0248	0250	0256
		0260	0285	0294	0296	0347	0348
		0355	0361	0387	0388	0412	0423
	SAT	0478	0532				
		0202	0788				
	DVD	0225	TNT	0202	VCR	0207	
KARCHER	TV	0198	0199	0201	0230	0240	0264
		0268	0585		VCR	0283	
KATHREIN	TV	0199	0234	0308	0570	0626	
		0234	0236	0246	0253	0267	0273
	SAT	0282	0288	0308	0310	0313	0331
		0341	0342	0380	0393	0399	0425
		0437	0461	0474	0486	0536	0538
		0557	0570	0572	0686	0913	1022
		1340	1512				
		0234	0236	0381	0474		
	DVD	0234	0236	0246	0267	0288	0310
		0342	0399	0461			
	TNT	0234	0236	0246	0267	0288	0310
		0342	0399	0461			
KAWASHO (FORMENTI)	TV	0198	0199	0201	0202	0203	0204
		0206	0207	0212	0214	0217	0220
		0231	0232	0235	0240	0242	0247
		0258	0277	0285	0339		
	SAT	0202	0292	DVD	0204	0225	
		0202		VCR	0204	0207	0210
	TNT	0202					
KAYA	TV	0203					
KB ARISTOCRAT	TV	0248	0250				
KELCINATOR	TV	0355			KEN	TV	0333
KENDO	TV	0198	0202	0222	0227	0233	0255
		0291	0339	0346	0377	0402	
	SAT	0202	0255	TNT	0202	VCR	0302
KENNEDY	TV	0244	0277	0315	0347	0365	0389
		VCR	0302				
KENNEX	TV	0198	0202	0215	0243	0260	0268
		0424	0676				
	SAT	0202	0211	DVD	0225		
		0202	VCR	0210	0218	0219	0295
KENSTAR	TV	0198	0564				
KENWOOD	TV	0207			SAT	0229	
		DVD	0595	1219	1220	VCR	0207
KENYA	SAT	0854	KERION	TV	0199	0232	
KEY	DVD	0237	0362	0704			
KEYMAT	TV	0676	0754	0756	0759	0834	0836
		0841	0858	0859	1253	1285	1318
		1333	1334				
	SAT	0345	1053				
		DVD	0405	0566	0699	0991	TNT
							0345
KEYPLUG	DVD	0293	0416				
KEYSMART	TV	0410	KIC	TV	0201	0264	0559
KIMAY	TV	0203					
KINGDHOME	TV	0202		SAT	0202		
		DVD	0643	TNT	0202		
KIOTA	TV	0203	0721				
KIOWA	SAT	0236	DVD	0236	TNT	0236	
KISS	DVD	0301	0887	1068	VCR	1068	
KITON	TV	0199	0200	0202			
		SAT	0202	0211	DVD	0200	TNT
KITT	TV	0199	0201	0203			0202
KITTEN	TV	0199					
KIYOGIN	TV	0201	0217	0222	0264	0562	
KIZUKI	SAT	0364					
KLARMAX	TV	0198	0199	0212	0214	0220	0264
		0268	0291	0346	0389	0508	0578
KNEISSEL	VCR	0213	0218	0219			
KOBALTRONIC(NEWMAR)	TV	0201	0222	0562			
KODA	DVD	0507					
KOLSTER	TV	0199	0201	0203	0222	0227	0264
		0509	0562				
KONIG	TV	0235	0407	0570	0705	0868	1654
		1669	1675	1681			
	SAT	0189	0254	0342	0380	0421	0430
		0361	0435	0477	1101	1640	1664
	DVD	1634			TNT	0342	
KONG WAM (KAISUI)	TV	0198	0201	0230	0346	0427	
KONKA	TV	0198	0200	0427	0471	0846	0966
		1350			DVD	0200	
KONTAKT	TV	0349					

Brand	Type Code						
KORPEL	TV	0199	0200	DVD	0200		
KOSCOM	SAT	0236	0253	0267	0396	0409	1080
	DVD	0236	TNT	0236	0267	0409	
KOSMOS	TV	0199		DVD	0200		
	SAT	0253	0393	0445	0449	0538	
KOTRON	TV	0203	0206				
KPN	SAT	0399		TNT	0399		
KR	SAT	0505		KRAKING	TV	0206	
KREILING	SAT	0439	0666				
KRIESELMEYER	SAT	0288	0434	TNT	0288		
KRIESLER(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0289	0311	0317	0333	0368
	SAT	0205	0229	0241	0262	0263	0313
		0328	0331	0332	0336	0341	0344
		0350	0359	0368	0382	0392	
	DVD	0200	0266	0306	0390	0391	
		TNT	0205	0263	VCR	0223	0261 0271
	TV	0201	0206	VCR	0303		
KRONNE	SAT	0393					
KRONOS	SAT	0393					
KTD	SAT	0246		TNT	0246		
KTV	TV	1271					
KUBA ELECTRONIC	TV	0201	0206	0231	0250	0207	0271
	VCR	0207	0213	0271			
KUCCAI	TV	0243		KUNYA	VCR	0265	
KURO (SANYO)	TV	0201	0202	0204	0207	0260	0286
		0296	0305	0316	0324	0370	0388
		0415	0443	0455	0476	0565	0672
		0722		SAT	0202	0211	
	DVD	0204	0334	0695	0697		
		TNT	0202	VCR	0204	0207	0316
KYOTO	TV	0206	0442				
KYOSTAR	SAT	0211	0249	0253	0267	0304	0307
		0493	0506	0538	0546	0906	
	TNT	0267					
LABGEAR	SAT	0611					
LAEM SAT	SAT	0320	0432	LAMEX	SAT	0253	
LASAT	SAT	0292	0299	0321	0322	0343	0363
		0380	0395	0488	0605	0791	
	DVD	0381		TNT	0343		
LAUSON	SAT	0452	0492	0558	0743	0824	1054
		1061	1556	1647			
	TNT	0452	0743	0824	1054		
	DVD	1002	1638	AUX	1610	1618	
LAVIS	TV	0217	0248	0508			
LAZER	TV	0198	SAT	0312	DVD	1234	
LEADER	SAT	0353					
LEGEND	TV	0199	0201	0203	0234	0403	
		SAT	0216	0229	0234	0236	0252 0253
			0267	0422	0448	0627	0790 0799
			0911	0915	0921	0930	0959 1119
	DVD	0234	0236	0394			
		TNT	0234	0236	0267	0422	
	TV	0199	0200	DVD	0200		
LECSON	SAT	0211	0437	0540	1512		
LEMON	SAT	0312	0666				
LENCO	TV	0198	0199	0202	0203	0220	0227
		0239	0240	0248	0250		
	SAT	0202	0249	0327	0380	0431	0449
	DVD	0293	0381	0416	0428	0696	
	TNT	0202		VCR	0210	0218	0219
LENG	SAT	0322		LENNOX	SAT	0292	
LENOIR	TV	0198	0199	0201	0202	0203	0207
		0214	0220	0230	0232	0243	0275
		0280	0410	0426	0590	0596	0629
		0861	0969	0970	0971		
	SAT	0202	0399	0572	TNT	0202	0399
		DVD	0360	0696	0772	VCR	0207 0210
	SAT	0211	0439				
	TV	0199	0200	DVD	0200		
LENSON	SAT	0211	0439				
LES 3 SUISSSES	VCR	0213	0223	0261	0283	0302	
LEVIS AUSTRIA	TV	0199	0200	DVD	0200		
LEXIA	DVD	0237	0362				
LEXUS	TV	0198	0203	0256	0282	0308	
	SAT	0273	0308				
LEYCO	TV	0198	0203	0758	SAT	0450	
LIBERTY	SAT	1083					
LIFE	TV	0379	SAT	0743	TNT	0743	
LIFETEC	TV	0198	0199	0202	0203	0214	0215
		0220	0243	0268	0280	0319	
	SAT	0202	DVD	0340	TNT	0202	
LIFESAT	SAT	0431	0682	1017			
LG	TV	0011	0012	0013	0014	0015	0016
		0017	0018	0019	0020	0198	0199
		0200	0201	0202	0204	0206	0212
		0214	0215	0222	0231	0239	0244
		0251	0271	0272	0275	0287	0339

Brand	Type	Code					
LG	TV	0365	0386	0411	0471	0509	0515
		0530	0667	0712	0727		
	SAT	0202	0251	0449	1376	1381	1399
	DVD	0200	0204	0301	0458	0700	
	TNT	0202	1376	1381	1399		
	VCR	0204	0213	0251	0271	0303	
AUX		0515					
LIGHTSTAR (KAISUI)	TV	0198	0201	0230	0346	0427	
LIMIT	DVD	0237	0362				
LINE@TECH	SAT	0492	0736	0828	0829		
LINETECH	TV	0090	LITE - ON	DVD	0707	1224	
LLOYD'S	TV	0201	0203	0247	0294	0361	0559
		0721					
LME (PATH CINEMA)	TV	0201	0206	0217	0222	0235	0240
		0264	0374				
LOCATEL	TV	1194	1195	1196	1197	1198	
LODOS	SAT	0259					
LOEWE	TV	0205	0221	0242	0272	0338	0368
		0442	0499	0582	1291		
	SAT	0205	0368	0952	DVD	0306	0582
	TNT	0205			VCR	0213	0582
LOGIK	TV	0199	0243	0256			
		SAT	0259	VCR	0283		
LOONEY TUNES	DVD	1001					
LORENZEN	SAT	0299	0312	0313	0343	0400	0465
		0475	0491	0618	0666	0795	0949
	TNT	0343	0400	0475	0491		
LOVE (ELBE)	TV	0198	0201	0202	0206	0212	0214
		0217	0222	0258	0264	0291	0315
		0330	0344	0346	0383	0389	0402
		0454	0457	0578	0665	0769	0770
		0951	0982				
	SAT	0202	0337				
	DVD	0903	0999	1008	1009	1010	
	TNT	0202	0337	VCR	0210	0303	
	TV	0207	0231	0233	0248	0285	0325
		0348	0355	0357	0361	0373	0374
LTV (OCEANIC)	SAT	0387	0502	0579			
		0229	0417	0418	0444	0467	
		0207	0223				
LUMA	TV	0199	0200	0201	0202	0220	0233
		0244	0291	0315	0347	0365	0503
	SAT	0202					
	DVD	0200	TNT	0202	VCR	0218	0219
LUXMAN	DVD	0598					
LUMATRON	TV	0202	SAT	0202	TNT	0202	
LUPUS(ANKARO)	SAT	0292	0326	0451	0488		
LUXMAY	TV	0199	0200	0403	DVD	0200	
LUXOR	TV	0201	0202	0207	0212	0231	0233
		0248	0316	0325	0348	0357	0373
		0386	0387	0411	0417	0478	0501
		0532	0588	0730			
	SAT	0202	0327	0444	0467	0604	
	TNT	0202		VCR	0207	0261	0316
	SAT	1189					
LUXORIT	SAT	1189					
LUXTRONIC	TV	0202	SAT	0202	TNT	0202	
LYONNAISE CABLE	SAT	0352	0550		TNT	0352	0550
LYOTRON (LG)	TV	0198	0199	0201	0202	0204	0206
		0212	0214	0215	0222	0231	0239
		0244	0251	0271	0272	0275	0287
		0339	0365	0386	0411	0471	0509
		0515	0530	0667	0712	0727	
	SAT	0202	0251	0449		TNT	0202
	DVD	0200	0204	0301	0458	0700	
	VCR	0204	0251	0271	0303	AUX	0515
	SAT	0396					
L&S	SAT	0396					
L&SELECTRONIC	DVD	0699	0702				
L&SELEKTRONIK	TV	0215		MACROM	TV	0836	
MACAB	SAT	0321	0322	0352	0363	0422	0537
		0637	0787	0905			
	TNT	0352	0422				
MADISON	TV	0198	0200			DVD	0200
MAESTRO	SAT	0413	0414	0439	0609	DVD	0394
MAGAVOX(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0311	0317	0319	0333	0336
		0368					
	SAT	0205	0229	0241	0245	0262	0263
		0313	0328	0331	0332	0341	0344
		0350	0359	0368	0382	0392	
	DVD	0200	0266	0306	0390	0391	
	TNT	0205	0263	VCR	0223	0261	0271
MAGELLAN	SAT	0689		MAGIC SAT	SAT	0926	
MAGIKE	SAT	0536	1572				
MAGNADYNE	TV	0207	0217	0221	0222	0227	0232
		0277	0314	0426	VCR	0207	
MAGNASONIC	TV	0207			VCR	0207	

Brand	Type	Code						
MAGNAVOX	TV	0209	0224					
MAGNEX	TV	0198	0203	SAT	0216			
	DVD	0408	0428	0507	0642			
MAGNAFON	TV	0198	0201	0217	0222	0227	0232	
		0318	0406					
MAGNUM	TV	0256	0257	0275	0280	0665		
MAJESTIC	TV	0234	0590	0770				
	SAT	0234	0269	0337	0438	0464	0522	
		0555	0736	0738	0749	0821	0823	
	DVD	1051	1054					
		0234	0237	0360	0566	0567	0597	
		0644	0698	0892	0896	0898	0987	
		1002	1165	1237	1238			
	TNT	0234	0522	0269	0337	0438	0738	
		0749	0821	0823	1054			
MAKROSONIC	TV	1064	MALIGNE TV	SAT	0548	0737		
MANATA	SAT	0298	0304	0307	0353	0919		
MANDI	TV	0200		DVD	0200			
MANDOR	TV	0203						
MANESTH	TV	0198	0200	0201	0203	0224	0233	
		0235	0285	0407	DVD	0200		
MANHATTAN	TV	0114	0117	0199	0202	0243	1342	
	SAT	0202	0216	0241	0254	0320	0321	
		0322	0363	0395	0396	0418	0445	
		0450	0469	0472	0495	0513	0628	
		1190	1341	1495				
	DVD	0225		TNT	0202	0495		
MARANN	SAT	0321	0322	0363				
MARANTZ	TV	0199		SAT	0273			
	DVD	0306		VCR	0223	0261		
MARECH	TV	0199	0235					
MARK	TV	0199	0220	0297				
MARTA	VCR	0213						
MARVEL LOUIS	DVD	0597	0782	0963	1166			
MASCOM	TV	0198		SAT	0395			
MASCOT	TV	0323						
MASPRO	TV	0626		SAT	0216	0486	0505	
MASTERS	SAT	0249	0546	0557	0560	0636		
(MASTER SAT)	DVD	0306	0546	0888				
MASUDA	TV	0198	0199	0203	0377			
MATAV	SAT	0393						
MATCH ITALIA	TV	0198	0199	0203	VCR	0295		
MATSUI	TV	0198	0201	0202	0203	0207	0290	
		0297	0308	0314	0319	0349	0356	
		0366	0377	0580	0588	1330		
	SAT	0202	0259	0273	0282	0308	0309	
		0359	0450	1107				
	DVD	0278	0405	0408	TNT	0202		
	VCR	0207	0210	0213	0295	0309		
	TV	0201	0203					
MATSUKA	TV	0201	0203					
NAVEX	SAT	0321	0322	0363				
MAXAM	TV	0203			VCR	0208		
MAXDORF	TV	0203	0541					
MAXELL	TV	0217	0230	0239	SAT	1422	1434	
MAXIMAL	TV	0207			VCR	0207		
MAXIMUM	SAT	0269	0491		TNT	0269	0491	
MAXTRONIC	SAT	0474			DVD	0474		
MAXWELL	TV	0198	0217	0227				
MB LINE	TV	0203	MCE	TV	0199	0203	0674	
MCMICHAEL(PHILIPS)	TV	0200	0201	0205	0209	0212	0221	
		0224	0238	0242	0244	0250	0257	
		0258	0263	0271	0272	0274	0276	
		0281	0311	0317	0319	0333	0336	
	SAT	0344	0368					
		0205	0229	0241	0245	0262	0263	
		0313	0328	0331	0332	0341	0350	
	DVD	0359	0368	0382	0392			
	DVD	0200	0266	0306	0390	0391		
	TNT	0205	0263	VCR	0223	0261	0271	
M.D.C	TV	0280		MECOA	TV	0198		
MECOTEK	DVD	0293	0990	0995				
MEDIABOX	SAT	0229						
MEDIACOM	SAT	0246	0269	0335	0435	0522	1295	
		1430	1471					
	TNT	0246	0269	0522				
MEDIAMARKT	SAT	0299	MEDIAMASTER	SAT	0560			
MEDIAPRICE	SAT	0269	0279	0371	0547	0574	1054	
		1055						
	TNT	0269	0371	0547	0574	1054		
MEDIASAT	SAT	0229	0560					
MEDIASET	SAT	0228	0229	0329	0744	0807		
	TNT	0228	0744					
MEDIASONIC	TV	0198						
MEDIATOR	TV	0199	0200	DVD	0200			
MEDION	TV	0198	0200	0202	0243	0268	0280	
		0379	0424	0528	0864	0970		
	SAT	0202	0211	0309	0343	0396	0431	
	DVD	0200	0293	0340	0360	0643	0644	

Brand	Type Code						
MEDION	DVD	0694	TNT	0202	0343	VCR	0309
MEGASAT	TV	0308		TNT	0490		
	SAT	0273	0282	0308	0490		
MEGATRON	TV	0251	SAT	0251	VCR	0251	
MEGHA	TV	0199			SAT	0273	
MELBOX (CLARIVOX)	TV	0200	0217	0221	0222	0264	0294
		0370	0374	0403	DVD	0200	
MELECTRONIC	TV	0198	0199	0220	0242	0247	0263
		0268	0280	0291	0314	0325	0357
		0366	0423	0426	0499	0508	0509
	SAT	0263	0501	0604	0617		
	TNT	0263	0617		VCR	0213	0303
MELITA	SAT	0796	MELVOX	TV	0217	0248	
MEMOREX	TV	0203	0207	0316	VCR	0207	0316
MEMPHIS	TV	0201	0203	0403			
MERCURY	TV	0198	0201	0203	0209	0264	0559
MERRIT	TV	0248		METEOR	SAT	0211	
METRONIC	TV	0170	0120	0157	0570	0651	0688
		0809	1614				
	SAT	0424	0119	0120	0135	0168	0170
		0176	0189	0192	0211	0216	0236
		0249	0253	0254	0267	0269	0279
		0304	0307	0310	0331	0342	0353
		0354	0371	0385	0395	0399	0414
		0416	0419	0420	0422	0435	0438
		0461	0464	0469	0487	0491	0492
		0493	0494	0518	0522	0547	0526
		0557	0558	0570	0574	0602	0603
		0619	0651	0653	0688	0660	0669
		0693	0731	0736	0738	0741	0745
		0752	0802	0803	0804	0805	0806
		0809	0811	0815	0816	0826	0914
		0930	0933	0934	0935	0942	0962
		1036	1037	1038	1045	1046	1054
		1072	1073	1074	1075	1076	1082
		1083	1084	1108	1109	1110	1111
		1144	1449	1607	1608	1611	1613
		1614	1615	1616	1629	1636	1642
		1643	1656	1657	1658	1666	
	DVD	0157	0236	0936	1631	1658	
	TNT	0424	0236	0269	0310	0342	0371
		0354	0399	0419	0422	0435	0438
		0461	0491	0494	0522	0547	0574
		0619	0752	0802	0803	0806	0815
		0816	1054	1046	1075	1076	
	AUX	1630	1667				
METZ	TV	0202	0221	0243	0366	0384	0424
		0582	0626	0831	1039	1266	1270
		1327					
	SAT	0202	0288	DVD	0225	0582	
	TNT	0202	0288	VCR	0223	0582	
MGA	TV	0199	0203	0220	0242	0251	
	SAT	0251		VCR	0251	0367	
MGAON	TV	0203					
MG ITEX	SAT	0543	0553	TNT	0543	0553	
MICROMAXX	TV	0198	0200	0202	0291		
	SAT	0202	DVD	0200	TNT	0202	
MICROMEGA	DVD	0306		MICRON	TV	0201	
MICROSAT	SAT	0396	0797				
MICROSOFT	DVD	1212		MICROSONIC	TV	1040	
MICROTEK	TV	0198	0270	0541	0964	SAT	0278
MICROTECHNOLOGIE	SAT	0717					
MIGROS ELECTR	TV	0291	VCR	0265	0303		
MIKA	VCR	0213	MIKRO DIGITAL	SAT	0618		
MINATO	TV	0199	0200	DVD	0200		
MINERVA FRANCE	TV	0349					
MINERVA (GRUNDIG)	TV	0271	0291	0294	0349	0366	0383
		0412	0462				
		0229	0241	0288	0359	0447	0587
	SAT	1018	1034	1035	DVD	0513	1007
		0288			VCR	0223	0271
MINOKA	TV	0199	0200		DVD	0200	
MIRASAT	SAT	0310	TNT	0310	MISC	DVD	0278
MISTRAL (THORN)	TV	0199	0203	0207	0209	0255	0264
		0270	0282	0284	0288	0375	0378
		0525	0531	0592	0593	0622	
	SAT	0241	0245	0254	0255	0259	0378
		0404					
	TNT	0288	VCR	0207	0265	0284	0378
MITRONIC	TV	0239					
MITSUBISHI	TV	0202	0206	0220	0221	0242	0251
		0272	0296	0305	0356	0565	0639
		0674	0967	SAT	0202	0251	0288
	DVD	0225	0639	TNT	0202	0288	
	VCR	0223	0251	0283	0295	0367	
MITSUTI GENERAL	TV	0376	0578				
MIVAR	TV	0201	0217	0386	0832	1315	1316
MIVAR	TV	1331	1716				

Brand	Type	Code					
MKC	TV	0841	DVD	0237	0362	0990	
MNET	SAT	0842					
MOBILE TV	TV	0202	SAT	0202	TNT	0202	
MOLGAR	TV	0308	SAT	0273	0282	0308	
MOMITSU	DVD	0706					
MONTEREY	SAT	0413	0414	0439	0609	DVD	0394
MOSER	SAT	0288	TNT	0288			
MOTION (UHER)	TV	0199	0200	0227	0231	0235	0244
		0338	0347	0406		DVD	0200
MOTOROLA	SAT	0329					
MP MAN	SAT	0542	0743	TNT	0743		
MTC	TV	0222	0231	0286	0297	0338	0358
		0965					
MULTICHOICE	SAT	0228	0241	0587	0733	TNT	0228
MULTITECH	TV	0198	0199	0201	0202	0203	0206
		0215	0217	0220	0227	0248	0268
		0275	0286	0287	0296	0297	0373
		0403	0509	0511	0586		
	SAT	0202	0436	DVD	0436	TNT	0202
	VCR	0210	0213	0218	0219		
MULTISTANDARD	TV	0227					
MULTISTAR	SAT	0393	0447	0486	0791		
MURATO	SAT	0607	0608				
MURPHY	TV	0231	0361	0511			
	SAT	0369		DVD	0225		
MUSIKLAND	TV	0199	0200	DVD	0200		
MUSTAG	TV	0765	MUSTEK	DVD	0405	0991	
MVISION	SAT	0691	0710	1049	1443	TNT	1049
MWC	SAT	0288	TNT	0288			
MXONDA	DVD	0642	0781	MYPLAYER	DVD	0895	
MYRYAD	TV	0199	DVD	0200			
MYSAT	SAT	0216					
MYSKY	SAT	0601	0812	TNT	0812		
NAD	TV	0248	0250	0251			
	SAT	0251	DVD	0890	VCR	0251	
NAGOYA	TV	0206	0624				
NAGRAVISION	SAT	0741	0751	TNT	0741	0751	
NAIKO	TV	0199	DVD	0200			
NAKAMICHI	DVD	1223					
NAKAMURA	TV	0199	0200	DVD	0200		
NAONIS(SELECO)	TV	0198	0200	0212	0214	0224	0233
		0240	0244	0270	0291	0305	0315
		0317	0347	0355	0365	0389	0402
		0457	0510	0563	0577		
	SAT	0216	0249	0332	0448	0489	
	DVD	0200	0225	VCR	0210	0265	0295
NARITA	TV	0201	0203	0220	0251		
	SAT	0251	VCR	0251	0295		
NASSA NAGEL (ENGEL)	TV	0206	0508				
	SAT	0211	0229	0249	0337	0517	0555
		0650	0678	1016	1410	TNT	0337
NATIONAL	TV	0581	0838				
NAYKO	DVD	0293	0416				
NEAHAUSAT	SAT	0216					
NEC	TV	0199	0220	0264	0268	0296	0356
		0433	0519	0583	0584		
	SAT	1148		VCR	0303		
NECKERMANN	TV	0198	0199	0200	0204	0206	0207
		0209	0212	0214	0221	0224	0231
		0232	0233	0235	0256	0257	0268
		0272	0280	0291	0300	0314	0316
		0323	0338	0366	0373	0377	0384
		0443	0456	0463	0480	0499	0591
		0613	0620	0671	1251		
	SAT	0617	DVD	0200	0204	TNT	0617
	VCR	0204	0207	0210	0300	0302	0316
		0480					
NECOLA	VCR	0213					
NEDIS	TV	0221	0270	0294	0305	0323	0407
		0441	1245	1532	1633	1655	1660
		1661	1668	1671	1672	1673	1678
	SAT	0554	1639	AUX	1621		
NEI	TV	0198	0199	0202	0206	0214	0222
		0240	0403	SAT	0202	TNT	0202
NEOM	SAT	0269	0371	0693			
	TNT	0269	0371	0693			
NEOM NM400HD	SAT	0817					
NEOTION	SAT	0312	0335				
NEOVIA	TV	0311	0383	0530	0576	0757	0848
		0871	0877	1286	DVD	1169	1171
NESCO	TV	0287	0324	0402	0412		
NETA	SAT	0392	0909				
NETGEM	SAT	1044		TNT	1044		
NETSAT	TV	0199	0200	DVD	0200		
NETWORK	SAT	0245					
NEUFUNK	TV	0202	SAT	0202	1111	TNT	0202
NEUF TELECOM	SAT	0830	1312	1530			
NEUHAUS	SAT	0473					

Brand	Type	Code					
NEUSAT	SAT	0216	0321	0322	0363	0396	0461
	TNT	0461					
NEVELING	SAT	0434	0486				
NEVIR	TV	1570	1571	1573	1574	1575	1576
		1577	1578	1579	1580	1581	1582
		1585	1588	1590	1592	1594	1595
		1598	1601	1606			
	SAT	1523	1585	1589	1593	1596	1603
		1604					
	DVD	1164	1583	1584	1586	1587	1591
		1599	1600	1602	1605		
	AUX	1572	1574	1575	1588	1590	1597
NEW GOLDVISION (SONOKO)	TV	0198	0199	0201	0203	0207	0215
		0230	0481	VCR	0207	0210	
NEWMAR	TV	0201	0222	0562			
NEWORLD (KAISUI)	TV	0198	0201	0230	0346	0427	
NEWSTAR	SAT	0310		TNT	0310		
NEWTECH	TV	0198	0201	0270			
NEWTON	SAT	0252	0364	NEWTRON	DVD		0293
NEW WAVE	SAT	0342	0460	0732	0962	TNT	0342
NEXIUS	TV	0198	0330	0860	DVD	0225	
NEXPRO	SAT	0746		NEXTIER	TV		1280
NEXT WAVE	SAT	0430	0460	0489	0536	0544	0635
		0962	1089				
NICAMAGIC (FORMENTI)	TV	0198	0199	0201	0202	0203	0204
		0206	0207	0212	0214	0217	0220
		0231	0232	0235	0240	0242	0247
		0258	0277	0285	0339		
	SAT	0202	0292	DVD	0204	0225	
	TNT	0202		VCR	0204	0207	0210
NIKENNY	DVD	0533	1005				
NIKKAI	TV	0199	0201	0239	0275	0411	
	VCR	0213	0218	0219			
NIKKEI	TV	0198	0202	0203	0212	0243	0330
		0629	0865	0870	0978		
	SAT	0202	0693	1360			
	TNT	0202	0693	1112	VCR	0213	
NIKKO	TV	0199	0251				
	SAT	0251	0605	1112	VCR	0251	
NINBUS	SAT	0432					
NOBLEX	TV	0220	0296	0305	0455	0565	
	SAT	0854					
NOBLIKO	TV	0201	0247	0318	0406		
NODA	SAT	0494	0518				
NOGAMATIC (THOMSON)	TV	0206	0233	0247	0255	0270	0274
		0284	0294	0349	0372	0375	0379
		0398	0401	0440	0441	0466	0482
		0498					
	SAT	0216	0228	0241	0245	0255	0352
		0369	0413	0446	0516		
	DVD	0237	0360	0468			
	TNT	0228	0352	VCR	0265	0284	
NOKIA	TV	0198	0202	0203	0207	0248	0260
		0316	0325	0348	0357	0387	0423
		0715	0730				
	SAT	0202	0211	0229	0236	0241	0253
		0267	0269	0298	0304	0307	0309
		0327	0353	0371	0399	0444	0467
		0560	0604	0788	0937	1053	1133
		1440					
	DVD	0225	0236	0428			
	TNT	0202	0236	0269	0371	0399	
	VCR	0207	0210	0218	0219	0261	0267
		0295	0302	0309	0316		
NOOS	SAT	0352	0422	0446	0548	0752	1062
	TNT	0352	0422	0752			
NORDING	TV	0227	0318				
NORDLAND	TV	0206					
NORDMENDE	TV	0200	0212	0215	0230	0233	0260
		0270	0274	0277	0284	0330	0355
		0372	0375	0379	0398	0401	0410
		0440	0482	0529	0861	1314	
	SAT	0211	0249	0309	0369	0395	0434
		0459	0572	0610	0710	0798	1429
	DVD	0200	0340	0599	0600	0900	
	VCR	0265	0284	0309			
NORDTON(SELECO)	TV	0198	0200	0212	0214	0224	0233
		0240	0244	0270	0291	0305	0315
		0317	0347	0355	0365	0389	0402
		0457	0510	0563	0577		
	SAT	0216	0249	0332	0448	0489	
	DVD	0200	0225				
	VCR	0210	0265	0283	0295	0302	
NORFOLK	TV	0624					
MORGANS	SAT	0298	0299	0304	0307	0380	0459
		0488	0517	0647		DVD	0381
NORKABEL	SAT	0327					
NORMEREL	TV	0200		DVD	0200		

Brand	Type Code							
NORM N	TV	0198						
NORTEK	TV	0198	0243	0275				
	DVD	0301	0902	1179				
NORTON	TV	0230			NORDWAY	TV	0376	
NORWAY	TV	0286	0376					
NOT ONLY TV	SAT	0477	0543	0736	1306			
	TNT	0477	0543					
NOVA	TV	0239		SAT	0587	0764		
NOVAK	TV	0199	0200	DVD	0200			
NOVATRONIC	TV	0198	0199	0203	0220	0239	0268	
	SAT	0326						
NOVIS	SAT	0321	0322	0363				
NPG	SAT	0735		NTC	SAT	0326	0445	
NTECH	SAT	0492	1310					
NUCLEAR (PRANDONI)	TV	0200	0202	0209	0217	0227	0231	
		0233	0243	0277	0406	0453		
	SAT	0202	DVD	0200	0484	TNT	0202	
NUMERICABLE	SAT	0229	0352	0550	TNT	0352	0550	
NU-TEC	DVD	0278						
NYKOJ	DVD	0599	0600					
NYKOS	DVD	0599	0600					
OCEANIC	TV	0054	0062	0063	0068	0069	0207	
		0231	0233	0248	0285	0316	0325	
		0348	0355	0357	0361	0373	0374	
		0387	0502	0579				
	SAT	0229	0327	0400	0417	0418	0444	
	TNT	0467	0537					
		0400	VCR	0207	0223	0261	0316	
OCTAGON	SAT	0249						
OCTAL	TV	0201	SAT	0422	0618	TNT	0422	
OCTAN(PHILIPS)	TV	0200	0201	0205	0212	0221	0224	
		0238	0242	0244	0250	0257	0258	
		0263	0271	0272	0274	0276	0281	
		0311	0317	0319	0333	0336	0344	
	SAT	0368						
		0205	0229	0241	0245	0262	0263	
		0313	0328	0331	0332	0341	0350	
	DVD	0359	0368	0382	0392			
		0200	0266	0306	0390	0391		
		0205	0263	VCR	0223	0261	0271	
ODEON (AGASHI)	TV	0198	0199	0203	SAT	0299		
OEC ELECTRONIC	TV	0239	0867					
OFFEL	SAT	0326	0628					
O GENERAL	TV	0296						
OK	TV	0058	0090	0092	0094	0095	0097	
		0098	0101	0104	0106	0108	0111	
OKANO	TV	0199	0204		SAT	0299	0393	
	DVD	0204	VCR	0204	0218	0219		
OLIDATA	TV	0857	DVD	0408				
OLIVETTI	TV	0967						
OLMAL (ALBIRAL)	TV	0198	0199	0203	0217	0222	0232	
		0264	0287	0562				
OLYMPIA	TV	0260						
OLYMPIC	TV	0230	SAT	0292	0326	0451		
	VCR	0261						
OLYMPUS	SAT	0216	DVD	0394				
OLYMUS	TV	0271	VCR	0271				
OMEGA	TV	0203						
ONCEAS	TV	0201	0314		ONDIAL	SAT	0307	
ON DIGITAL	SAT	0350	0561	0652				
ONDIOLA	TV	0198			ONIDA	TV	0209	
ONKYO	DVD	1175	1221	1222				
ONWA	TV	0203	0227					
OPENBOX	SAT	0254	0409	0747	1308			
	TNT	0409	0747					
OPENTEL	SAT	0485						
OPERA	TV	0199	0200	DVD	0200			
OPTEX	TV	0157	0234	0843	1058			
		SAT	0119	0135	0148	0168	0170	0176
	SAT	0189	0211	0216	0234	0236	0246	
		0253	0254	0267	0310	0320	0321	
		0322	0335	0342	0353	0363	0396	
		0394	0414	0429	0437	0439	0452	
		0460	0465	0492	0514	0522	0537	
		0542	0558	0569	0612	0648	0653	
		0661	0666	0680	0711	0712	0732	
		0753	0829	0843	0941	0946	1076	
		1058	1089	1144	1147	1304	1307	
		1384	1400	1409	1411	1412	1413	
		1414	1416	1449	1458	1459	1460	
		1461	1462	1506	1507	1508	1509	
		1510	1511	1512	1514	1515	1516	
		1517	1518	1519	1520	1608	1609	
		1612	1615	1619	1637	1646	1652	
		1679						
	DVD	0234	0236	0394				
	TNT	0234	0236	0246	0267	0310	0342	
		0452	0753	0946				

Brand	Type Code							
OPTIBOX	SAT	0747	1304	TNT	0747			
OPTICUM	SAT	0236	0337	0418	0489	0400	0615	
		0710	0739	0746	0747	0753	0824	
		0829	1446	DVD	0236			
	TNT	0236	0337	0400	0739	0747	0753	
		0824						
OPTIMA	SAT	0445		OPTONICA	VCR	0261		
OPTUS(AU)	SAT	0922						
ORANGE	SAT	0420	0548	0737	0752	1192	1718	
	TNT	0752	1111					
ORAVA	TV	0198	0199	0206	0214	0221	0273	
	SAT	0313						
ORBISAT	TV	0201	SAT	0216				
ORBIT	TV	0199	SAT	0216	0607	0608	0657	
ORBITECH	TV	0570						
	SAT	0216	0249	0331	0447	0570	0685	
		0714						
ORDA	SAT	0680						
ORION	TV	0198	0199	0200	0202	0203	0212	
		0214	0215	0224	0234	0239	0275	
		0290	0300	0330	0356	0377	0426	
		0479	0497	0504	0529	0580	0583	
		0584	0589	0724				
	SAT	0202	0234	0309				
	DVD	0200	0234	0301	0512	0707		
	TNT	0202	0234	VCR	0223	0300	0309	
	TV	0198	0199	0206	0209	0274	0580	
		0624	1345					
ORITRON	DVD	0360		ORMENTI	TV	0258		
ORLINE	TV	0199	0200	DVD	0200			
ORMOND	TV	0114	0117	0199	0202	0243		
	SAT	0202		TNT	0202			
OR - ON	TV	0230		ORSOWE	TV	0217		
OSAKA (SHORAI)	TV	0300		VCR	0300			
OSAKI	TV	0199	0201	0202	0300			
	SAT	0202	TNT	0202	VCR	0213	0300	
OSAT	SAT	1023		OSIO	TV	0199	0386	
OSUME	TV	0200		DVD	0200			
OTAKE	TV	0300	0377	VCR	0300			
OTF	TV	0209	0222					
OTHER LINE	TV	0198	0201	0217	0240			
	SAT	0211	0352	0420	0436	0574	0801	
		0817	0932	0939	0940	0941	0942	
		1044	1071	1085				
	DVD	0436	TNT	0352	0574	0939	1044	
	OTTO VERSAND	TV	0198	0199	0200	0201	0206	0209
			0214	0224	0231	0235	0240	0248
0250			0257	0268	0270	0272	0287	
0300			0305	0338	0358	0366	0373	
0377			0384	0456	0463	0479	0499	
0504			0519	0549	0578	0581	0591	
0620		0761	0762	0879	0984			
SAT	0685		DVD	0200				
VCR	0210	0223	0300	0303				
OVP	TV	0198	0199	OXFORD	SAT	0450		
PACE	TV	0234						
	SAT	0229	0234	0236	0241	0245	0262	
		0267	0414	0469	0470	0487	0493	
		0505	0561	0558	0601	0614	0616	
		0654	0708	0797	0825	1395		
		0234	0236	0267	DVD	0234	0236	
	TNT	0234	0236	0267	DVD	0234	0236	
PACIFIC	TV	0199		SAT	0460	0537	0689	
	DVD	0340	0880					
PACKARD BELL	DVD	0340						
PAEL	TV	0201	0294	0406				
PALCOM	SAT	0335	0540	0664	1095			
	DVD	0278	0394	TNT	0664			
PALLADIUM	TV	0198	0199	0204	0207	0214	0221	
		0224	0231	0233	0235	0263	0268	
		0291	0338	0384	0463			
	SAT	0249	0263	DVD	0204	TNT	0263	
	VCR	0204	0207	0213	0283	0302	0303	
	SAT	0447	0658	DVD	0394			
	TV	0201	0203	0209	0239			
PANAMA	TV	0198	0199	0200	0201	0203	0323	
	DVD	0200						
PANASAT	SAT	0420	0422	0587	0790	0799		
	TNT	0422						
PANASONIC	TV	0028	0029	0030	0031	0032	0033	
		0034	0035	0036	0037	0038	0039	
		0040	0041	0051	0222	0271	0361	
		0384	0519	0581	0582	0838	0984	
		1039	1205	1324				
	SAT	0262	0420	0422	0561	0799	1102	
	DVD	0582	0595	0897	0997	1231		
	TNT	0422		VCR	0271	0582		
	TV	0198	0203	0232	0291	0319	0481	
		0201	0230	0716	0765	0853	1040	
PANAVISION	TV	0198	0203	0232	0291	0319	0481	
PANAVOX	TV	0201	0230	0716	0765	0853	1040	

Brand	Type	Code					
PANA VOX	TV	1245	1258	1259			
	DVD	0534	0893	1153			
	VCR	0210	0218	0219			
PANDA	TV	0581	SAT	0327	0396	0404	0655
PANORAMA	TV	0201	0319	0481	VCR	0210	0213
PANORAMIC	TV	0372					
PATH CINEMA	TV	0201	0206	0217	0222	0235	0240
		0264	0374				
PATHE CINEMA	VCR	0367					
PATH MARCONI (THOMSON)	TV	0206	0233	0247	0255	0270	0274
		0284	0294	0349	0372	0375	0379
		0398	0401	0440	0441	0466	0482
		0498					
	SAT	0216	0228	0241	0245	0255	0352
		0369	0413	0446	0516		
	DVD	0237	0360	0468			
	TNT	0228	VCR	0265	0284		
PATRICK	SAT	0553			TNT	0553	
PATRIOT	SAT	0298	0304	0307	0450		
PCM	TV	0198	0232	0235	VCR	0213	
PEACOCK	TV	0201	0209				
PEARL	SAT	1379	1448	1449	1450	1451	1452
		1453	1454	1455	1456	TNT	1379
PEEKTON	SAT	0575	1060	1441	1442	DVD	0646
PEONY	TV	0639	0674	DVD	0639		
PERDIO	TV	0199		PERFEKT	TV	0199	
PERSHIN	TV	0294	0374				
PHASE	DVD	0293	0416				
PHILARMONIC	TV	0201	0314				
PHILBIX (DESMET)	TV	0198	0199	0202	0206	0217	0235
		0258	0442	SAT	0202	TNT	0202
PHILCO	TV	0198	0199	0204	0207	0221	0222
		0240	0256	0277	0296	0323	0376
		0314	0318	0508	0716	0853	
	DVD	0204	VCR	0204	0207	0283	0303
PHILEX	DVD	0306	0963				
PHILIPS	TV	0021	0022	0023	0024	0025	0026
		0027	0200	0201	0205	0209	0212
		0221	0224	0238	0242	0244	0250
		0257	0258	0263	0271	0272	0273
		0274	0276	0281	0308	0311	0317
		0319	0333	0336	0344	0368	0570
	SAT	0205	0216	0229	0241	0245	0262
		0263	0279	0282	0308	0313	0326
		0328	0331	0332	0341	0350	0359
		0368	0382	0392	0431	0517	0557
		0570	0617	1372	1427	1496	
	DVD	0200	0266	0278	0306	0390	0391
		0640					
	TNT	0205	0263	0617	1372	1496	
	VCR	0213	0223	0261	0271		
PHILIPS (F)(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0311	0317	0319	0333	0336
		0344	0368				
	SAT	0205	0229	0241	0245	0262	0263
		0313	0328	0331	0332	0341	0350
		0359	0368	0382	0392		
	DVD	0200	0278	0306	0390	0391	0640
	TNT	0205	0263	VCR	0223	0261	0271
PHILO	DVD	0644	1002				
PHOENIX	TV	0198	0202	0207	0209	0235	0277
	SAT	0202	0245	0299			
	DVD	0225		TNT	0202		
	VCR	0207	0210	0213	0218	0219	
PHONAR	DVD	0705	0750	0771			
PHONOLA(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0311	0317	0319	0333	0336
		0344	0368				
	SAT	0205	0229	0241	0245	0262	0263
		0313	0328	0331	0332	0341	0350
		0359	0368	0382	0392		
	DVD	0200	0266	0306	0390	0391	
	TNT	0205	0263				
	VCR	0223	0261	0271			
PHONOTREND	SAT	0320	0326	0351	0445	0764	0787
	DVD	0428	0507				
PIONEER	TV	0209	0212	0248	0274	0401	1093
	SAT	0229	0938	1090	1431		
	DVD	0293	0416	1094	1229	1494	
	VCR	0223					
PIXX	SAT	0569	1032				
PK SAT	SAT	0288	0292	0328	0425	0475	0485
(HIRSCHMANN)		0538	0636	0658			
	TNT	0288	0475				

Brand	Type Code						
PLANET	SAT	0329					
PLANTRON	TV	0199	0203				
PLASMATECH	TV	0311	0862				
PLATINIUM	TV	0760	PLAYDOR TV 0203				
PLAYSONIC	TV	0199	0201	0207	0221	0264	
	VCR	0207					
PMB	SAT	0216	0228	0236	0253	0267	0399
		0429	0437	0540	0682	1017	1512
	DVD	0236	TNT 0228 0236 0399				
POLARIS	SAT	0252	0364				
POLLIN	SAT	0343	TNT 0343				
POLYTRON(KATHREIN)	TV	0199	0626				
	SAT	0331	0341	0393	0486	0536	0538
		0686	1022				
POLSAT	SAT	0618					
POP	TV	0203	0401				
PORTLAND	TV	0220	0268	0280	0497	0611	
	VCR	0210	0218	0219	0295		
POWERPOINT	TV	0199	0200	DVD 0200			
POWER SKY	SAT	0254					
PRANDONI	TV	0200	0202	0209	0217	0227	0231
		0233	0243	0277	0406		
		0202					
	DVD	0200	0484	TNT 0202			
PRECISION	TV	0201	0239				
PREDKI	SAT	0321	0322	0363	0469		
PREISNER	SAT	0252	0298	0304	0307	0364	0473
		0488					
PREMIER	TV	0203	0368	0846			
	SAT	0326	0368	0445	0467		
PRIMA	TV	0201	0203	0239	0481		
PRINCE (PRANDONI)	TV	0200	0202	0209	0217	0227	0231
		0233	0243	0277	0406	0453	
		0202					
	DVD	0200	0484	TNT 0202			
PRINCESS	TV	0239	0330				
PRINSTON	TV	0275					
PRINZ	TV	0300					
	SAT	0300	DVD 0340				
PROBASIC	SAT	0342	0419	0452	0552		
	TNT	0342	0419	0452	0552		
PROCYON(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0311	0317	0319	0333	0336
		0344	0368				
	SAT	0205	0229	0241	0245	0262	0263
		0313	0331	0332	0341	0350	0359
		0368	0382	0392			
	DVD	0200	0266	0306	0390	0391	
	TNT	0205	0263				
VCR	0223	0261	0271				
PRODVX	DVD	1186					
PRODX	SAT	0709					
PROFEX	TV	0206	0240	0248	0318	0376	0511
PROFESSOR	TV	0209					
PROFILO	TV	0198	0199	0217			
PROFILINE	TV	0202	SAT	0202	0211	TNT	0202
PROFITRONIC	TV	0198	0200	0227			
	DVD	0200	VCR	0283			
PROLINE	TV	0199	0200	0202	0206	0212	0258
		0291	0324	0433	0504		
	SAT	0202		DVD	0200	0360	0408
	TNT	0202		VCR	0218	0219	0295
PROMAX (PACE)	SAT	0229	0241	0245	0262	0414	0469
		0487	0561	0601	0614	0616	0654
		0708					
PROSAT	SAT	0236	0312	0326	0369		
	DVD	0236	0394	TNT	0236		
PROSCO	VCR	0213	0218	0219	0295		
PROSONIC	TV	0198	0234	0280			
	SAT	0234	0617				
	DVD	0234	TNT 0234 0617				
PROTEC	SAT	0537					
PROTECH	TV	0198	0199	0201	0203	0206	0232
		0243	0256	0263	0280	0297	1250
	SAT	0263	0461	0537	0617	0656	
	VCR	0223	TNT	0263	0461	0617	
PROTEK	SAT	0342	0461	0537	0918		
PROTON	TV	0251	SAT	0251	VCR	0251	
PROVISION	TV	0198	0199	0200	0203	0214	0220
		0808					
	SAT	0395	0628	0808	DVD	0200	
PROVISAT	SAT	0571	0656	DVD	0594		
PVISION	TV	0630					
PYE(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276

Brand	Type	Code					
PYE(PHILIPS)	TV	0281	0311	0317	0319	0333	0336
		0344	0368				
	SAT	0205	0229	0241	0245	0262	0263
		0313	0328	0331	0332	0341	0350
	DVD	0359	0368	0382	0392		
PYGMY	TV	0200	0266	0306	0390	0391	
		TNT	0205	0263	VCR	0223	0261
QONIX	DVD	0645					
QUADRAL	TV	0256	SAT	0249	0326	0434	0473
QUADRIGA	TV	0357					
QUADRO	TV	0202	0256	0260	0424	0726	0845
		0948	0955	1273	1274	1275	1276
	SAT	0202	0211	0342	0460		
QUALI-TV	SAT	0345		QUALCRAFT	TV	0239	
QUARTZ	TV	0207		VCR	0207		
QUASAR	TV	0217	0227	0239	0247	0264	0290
		0311	0318	0406	VCR	0213	
QUEENFIDELITY (DAEWOO)	TV	0198	0199	0200	0201	0215	0220
		0242	0268	0314	0324	0383	0433
		0454	0528	0586	0623	0725	
		0216	0249	0611	0683		
	DVD	0200	0293	0301	0428	0513	0641
	VCR	0775	0778	0783	0784	0785	
		0210	0295				
	TV	0198	0199	0200	0201	0202	0203
QUELLE	TV	0206	0207	0209	0214	0224	0227
		0231	0232	0239	0243	0247	0248
		0250	0256	0257	0270	0271	0272
		0285	0286	0287	0290	0291	0294
		0296	0300	0305	0315	0324	0325
		0336	0338	0347	0348	0356	0357
		0358	0366	0376	0377	0384	0386
		0388	0398	0406	0415	0423	0424
		0441	0443	0453	0455	0456	0463
		0497	0501	0503	0504	0510	0519
		0549	0581	0585	0591	0613	0620
		0671	0715	0762	0983		
	SAT	0202	0288	0380	0393	0404	
	DVD	0200	0278	0381	TNT	0202	0288
	VCR	0207	0213	0223	0271	0300	0303
		0613					
QUESTAR	TV	0296	0305	QVISION	SAT	0691	
RADIALVA	TV	0198	0200	0220			
	DVD	0200		VCR	0213	0261	
RADIOLA(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0311	0317	0319	0333	0336
		0344	0368				
	SAT	0205	0229	0241	0245	0262	0263
		0313	0328	0331	0332	0341	0350
		0359	0368	0382	0392		
	DVD	0200	0266	0306	0390	0391	
	TNT	0205	0263	VCR	0223	0261	0271
	TV	0198	0206	0207	0217	0221	0227
RADIOMARELLI	VCR	0232	0256	0277	0314	0426	
		0207	0213				
RADIONETTE	TV	0285	0361	0423	VCR	0213	
RADIOSHACK	TV	0199	0200	0251			
	SAT	0251	DVD	0200	VCR	0251	
RADIOSTAINER	DVD	0301	0306	0632	0773		
RADIOTONE	TV	0198	0199	0200	0203	0204	0280
		0297	0319	0665	0953		
	DVD	0200	0204		VCR	0204	
RADIX	SAT	0252	0364	0460	0518		
RAFAL	VCR	0213					
RAINBOW(PACE)	SAT	0229	0241	0245	0262	0414	0469
		0487	0493	0505	0561	0601	0614
		0616	0654	0708			
RAITE	DVD	0301		RANK ARENA	TV	0455	
RANK / RBM	TV	0206	0240	0291	0361	0511	
	DVD	0225					
RCA	TV	0251	0255	0270	1269		
	SAT	0251	0255		VCR	0251	0283
RCS	SAT	0913			RE	SAT	0320
REALISTIC	TV	0207	0251	0271			
	SAT	0251	VCR	0207	0251	0261	0271
REBOX	SAT	0236	0253	0496		DVD	0236
REC	SAT	0634					
RECOR	TV	0198	0199	0200	0242	0256	0338
	DVD	0200					
REDBELL	SAT	1358			TNT	1358	
REDDER	TV	0264	0305	0578			
REDIFFUSION	TV	0233	0248		SAT	0617	
	DVD	0306	TNT	0617	VCR	0223	
REDO	TV	0220	SAT	0353	VCR	0210	
REDPOINT	TV	0349					

Brand	Type	Code					
RED STAR	TV	0199	SAT	0292			
	DVD	0293	0416	0483			
REFLEX	TV	0198	0199	0200	0202	0232	0243
	SAT	0202	0617	DVD	0200		
RELISYS	TV	0311					
RENDER	TV	0410	0528	0564	0676	0834	0868
		1256					
	SAT	0269	1498	TNT	0269		
REOC	DVD	0237	0362	0512			
REVOX	TV	0198	0200	0338		DVD	0200
REVOY	DVD	0428					
REX	VCR	0213	0218	0219	0223	0265	0283
		0302					
REX(SELECO)	TV	0198	0200	0212	0214	0224	0233
		0240	0244	0270	0291	0305	0315
		0317	0347	0355	0365	0389	0402
		0457	0510	0563	0577		
	SAT	0216	0249	0332	0448	0489	
	DVD	0200	0225				
	VCR	0210	0265	0283	0295	0302	
RFT(BRUNS)	TV	0221	0224	0227	0270	0370	
	SAT	0216	0326	0327	0396	0451	0460
		0794					
RICHMOND	DVD	1182			RIMAX	DVD	0416
RICONH	TV	0199	0200	DVD	0200		
RITAR	SAT	0216	0312	0327	0399	0572	0605
	TNT	0399					
RITZ	TV	0206					
R. LINE	TV	0199	0200	DVD	0200		
RM 2000	TV	0198	0202	0232	0243	0424	
	SAT	0202	0617	TNT	0202	0617	
ROADSTAR	TV	0198	0202	0212	0215	0224	0234
		0243	0260	0275	0379	0410	0454
		0564	0590	0631	1317		
	SAT	0202	0211	0216	0229	0234	0236
		0253	0254	0267	0309	0429	0436
		0717					
	DVD	0200	0225	0234	0236	0405	0428
		0436	0595	0645	0694	0696	0704
		0772	0782	0885	0889	0891	1151
	TNT	0202	0234	0236			
		0210	0213	0218	0219	0223	0283
		0295	0309				
ROBERTS	TV	0412					
ROBOTRON ELECTR	TV	0221	0370		ROCH	SAT	0353
RODEX	TV	0199	0200	DVD	0200		
ROMSAT	SAT	0249			ROSNER	TV	0201
ROTEL	DVD	0881			ROVER	SAT	0211
ROWA	TV	0198	0201	0203			
ROWSONIC	TV	0201					
ROYAL	TV	0198	0201	0203	0230	0256	0427
		0839	1351				
	TV	0198	0199	0202	0203	0220	0227
		0239	0240	0248	0250		
RUEFACH (LENCO)	SAT	0202	0249	0431			
	DVD	0293	0428	TNT	0202	VCR	0210
RUNCO	TV	0722					
RUKOPIR	TV	0199	0200	DVD	0200		
SAB	SAT	0409	0612	TNT	0409		
SABA	TV	0199	0202	0215	0217	0233	0255
		0263	0270	0274	0284	0361	0372
		0375	0398	0401	0440	0441	0466
		0959					
	SAT	0202	0241	0245	0255	0263	0279
		0327	0369	0380	0395	0445	0535
		0539	0571	0656	0690		
	DVD	0360	0381	0468	0594		
	TNT	0202	0263				
	VCR	0218	0219	0265	0284		
SABC	SAT	1142					
SABRE(PACE)	SAT	0229	0241	0245	0262	0414	0469
		0487	0561	0601	0614	0616	0654
		0708					
SAGEM	TV	0346	0368	1287			
	SAT	0229	0352	0368	0420	0422	0490
		0548	0550	0733	0752	0905	0924
		0925	0940	1028	1046	1298	1364
		1492					
	TNT	0352	0422	0490	0550	0752	1046
		1364					
SAGEMCOM	SAT	1298	1310		SAINEL	TV	0206
SAISHO	TV	0201	0203	0220	0231	0264	0290
		0356	0377	0504			
SAIVOD	TV	0198	0199	0200	0202		
	SAT	0202	0269	0337			
	DVD	0200	0340				
	TNT	0202	0269	0337			
SAKAI	TV	0201					

Brand	Type Code						
SAKIO	TV	0203	0220				
SALORA	TV	0198	0207	0212	0222	0231	0233
		0248	0316	0325	0348	0357	0373
		0386	0387	0411	0478	0501	0588
		0730					
	SAT VCR	0327 0207 0367	0417 0218	0604 0219	0261	0302	0316
SAMBERS	TV	0217 0766	0227	0239	0264	0318	0406
	DVD	0598	VCR	0213			
SAMPO	TV	0209					
SAMSAT	SAT	0485	1475				
SAMSUNG	TV	0001	0002	0003	0004	0005	0006
		0007	0008	0009	0010	0199	0200
		0201	0203	0204	0207	0212	0242
		0251	0268	0286	0324	0339	0358
		0386	0411	0415	0443	0529	0559
	SAT	0649	0682	0760	0768	0954	0968
		0972	0973				
		0251	0262	0328	0351	0393	0399
		0420	0422	0459	0465	0635	0649
		0650	0678	0734	0961	1011	1014
	DVD	1042	1311	1373	1391	1425	1426
		1499					
		0200	0204	0598	0988	0993	0996
		0998	1041				
		0399	0422	0734	1373	1391	
	TNT VCR	0204 0207	0223	0251	0283		
SAMY	DVD	1211					
SAND	TV	0212					
SANDOR (OCEANIC)	TV	0207	0231	0233	0248	0285	0325
		0348	0355	0357	0361	0373	0374
		0387	0502	0579			
	SAT	0229	0417	0418	0444		
	VCR	0207	0223				
SANDRA COLOR	TV	0201	0217				
SANSUI	TV	0198	0199	0200	0203	0214	0215
		0230	0234	0260	0296	0564	1248
	SAT	0234	0617	1050			
	DVD	0200	0234	0237	0293	0640	0642
		0645	0719	0772	0774	0884	0985
		0893	1158	1206			
	TNT	0234	0617	1050		VCR	0367
SANWA (SANYO)	TV	0201	0202	0204	0207	0221	0260
		0286	0296	0305	0316	0324	0370
		0388	0415	0443	0455	0476	0565
		0672	0722				
	SAT	0202	0211	DVD	0204	0695	0697
SANYO	TNT	0202		VCR	0204	0207	0316
	TV	0201	0202	0204	0207	0221	0260
		0286	0296	0305	0316	0324	0370
		0388	0415	0443	0455	0565	0672
		0722					
	SAT	0202	0211				
	DVD	0204	0334	0695	0697		
	TNT	0202		VCR	0204	0207	0316
SAR	TV	0199	0201	0231			
SAITO (OCEANIC)	TV	0207	0231	0233	0248	0285	0325
		0348	0355	0357	0361	0373	0374
		0387	0502	0579			
	SAT	0229	0417	0418	0444		
	VCR	0207	0223				
SAT	SAT	0607	0608	0684			
SAT+	TV	0234					
	SAT	0211	0234	0236	0253	0267	0335
		0400	0418	0429	0448	0540	1015
	DVD	0234	0236				
	TNT	0234	0236	0267	0400		
SAT FORD	SAT	0634					
SAT ITALIA(WISI)	SAT	0252	0288	0447	0539	0606	0633
		0637	0657	0690	0713	0786	0792
		0793	0800	1338			
SAT MASTER	SAT	0451	0634	1521			
SATRONIC	SAT	0323					
SAT PARTNER	TV	0308					
	SAT	0273	0282	0308	0321	0322	0449
SATCOM	SAT	0249	0634				
SATEC	SAT	0245					
SATELLITE	SAT	0658					
SATECO	SAT	0249	0320	0431			
SATUM (URANYA)	TV	0198	0199	0204	0207	0217	0220
		0235	0247				
	DVD	0204		VCR	0204	0207	
SAT-URNE	SAT	0310		TNT	0310		
SAVANA	VCR	0213					
SAVE	TV	0199	0200	DVD	0200		
SAVILLE(ORION)	TV	0198	0199	0200	0202	0203	0212

Brand	Type	Code					
SAVILLE(ORION)	TV	0214	0215	0224	0239	0275	0290
		0300	0330	0356	0377	0426	0479
		0497	0504	0529	0580	0583	0584
		0589	0724				
	SAT	0202					
	DVD	0200	0301	0512	0707		
	TNT	0202		VCR	0223	0300	
SBR(PHILIPS)	TV	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0311	0317	0319	0333	0336
		0344	0368				
	SAT	0205	0229	0241	0245	0262	0263
		0313	0328	0331	0332	0341	0350
		0359	0368	0382	0392		
	DVD	0200	0266	0306	0390	0391	
	TNT	0205	0263	VCR	0223	0261	0271
SCANMAGIC	DVD	0405		SCANSONIC	DVD	0225	
SCHAUB LORENZ	TV	0198	0199	0202	0203	0204	0207
		0215	0220	0230	0232	0233	0234
		0240	0243	0248	0256	0280	0285
		0316	0325	0348	0355	0357	0361
		0373	0387	0410	0499	0530	0564
	SAT	0630	0809	0860			
		0202	0216	0234	0327	0337	0417
	DVD	0452	0467	0496	0610	0809	
		0204	0225	0234	0237	0306	
	TNT	0202	0234	0337	0452		
SCHNEIDER	TV	0204	0207	0213	0218	0219	0295
		0302	0316				
	SAT	0198	0199	0200	0201	0202	0206
		0209	0212	0222	0224	0227	0232
		0233	0238	0239	0243	0244	0250
		0256	0260	0268	0275	0277	0287
		0308	0315	0376	0425	0453	0576
	DVD	0549	0728	0754	0756	0759	0767
		1282					
	VCR	0202	0216	0273	0282	0299	0308
		0309	0429	0431	0517	0557	0633
SCHNEIDER (F) (PHILIPS)	TV	0200	0225	0278	0340	0360	0640
		0884	0886	0900		TNT	0202
		0213	0218	0219	0223	0295	0309
		0367					
	SAT	0200	0201	0205	0209	0212	0221
		0224	0238	0242	0244	0250	0257
		0258	0263	0271	0272	0274	0276
		0281	0311	0317	0319	0333	0344
		0368					
SCHWAIGER	TV	0205	0229	0241	0245	0262	0263
		0313	0328	0331	0332	0341	0350
		0359	0368	0382	0392		
	DVD	0200	0266	0306	0390	0391	0640
		0205	0263	VCR	0223	0261	0271
	SAT	0120	0196	1058	1532	1676	1680
		1682	1683	1684	1685	1686	1687
		1688					
		0120	0128	0135	0139	0148	0149
		0158	0164	0171	0176	0179	0189
SCIENTIFIC (SCIENTIFIC ATLANTA)	TV	0191	0196	0245	0246	0254	0259
		0279	0312	0343	0351	0430	0431
		0435	0472	0473	0475	0485	0492
		0495	0500	0517	0518	0569	0648
		0686	0710	0714	0732	0747	0810
	SAT	0943	0944	0945	0946	0947	0950
		1032	1058	1086	1128	1129	1130
		1131	1462	1463	1464	1485	1488
		1489	1617	1622	1628	1653	1658
		1659	1662	1674	1677		
SCOTLAND (FORMENTI)	TV	0512	1658				
		0246	0343	0475	0495	0943	0944
		0945	0946	0947	1086	0944	
	DVD	1486	1487				
		0237	0362				
	SAT	0198	0199	0201	0202	0203	0204
		0206	0207	0212	0214	0217	0220
		0231	0232	0235	0240	0242	0247
		0258	0285	0290	0339		
		0202	0292				
SCOTT	TV	0204	0225				
		0202	VCR	0204	0207	0210	
		0207					
	SAT	0232					
		0412					
	DVD	0251	DVD	0408	0567	0889	1172
		0207	0251				
		0207					
SEARCH	TV	0207					
		0232					
		0235					
		0251					
		0280					
	SAT	0333					
		0412					
		0251	DVD	0408	0567	0889	1172
		0207	0251				
		0207					
SEARS (SANYO)	TV	0207					
		0232					
		0235					
		0251					
		0280					
	SAT	0333					
		0412					
		0251	DVD	0408	0567	0889	1172
		0207	0251				
		0207					
SEARS (SANYO)	TV	0207					
		0232					
		0235					
		0251					
		0280					
	SAT	0333					
		0412					
		0251	DVD	0408	0567	0889	1172
		0207	0251				
		0207					

Brand	Type	Code					
SEARS (SANYO)	TV	0388	0415	0443	0455	0476	0565
		0672	0722				
		SAT 0202	0211	DVD 0316	0204	0695	0697
	VCR	0204	0207				
SEAWAY	TV	0202	SAT 0202	VCR	0218	0219	
SECTOR	SAT	0451					
SEDEA	TV	0170	0688	0843			
		SAT 0135	0164	0170	0189	0191	0249
		0254	0298	0304	0307	0321	0348
		0361	0425	0434	0438	0460	0464
		0465	0472	0492	0506	0514	0522
		0542	0554	0558	0614	0680	0688
		0731	0810	0829	0843	0944	0959
		1013	1059	1462	1477	1608	1609
		1620	1624	1625	1632	1641	1648
		1649	1650	1651	1652	1663	1665
		1670			DVD 0936		
SEDIP (PATH CINEMA)	TV	0201	0206	0217	0222	0235	0240
		0264	0374				
SEELTECH	SAT	0337	0575	DVD 0364	0646	TNT 1024	0337
SEEMAN	SAT	0252	0299				
SEELVER	TV	0199	0200	0202			
	SAT	0202	DVD 0200	TNT 0202			
SEG	TV	0198	0199	0201	0202	0203	0206
		0209	0214	0222	0227	0232	0234
		0239	0240	0243	0260	0268	0316
		0318	0323	0370	0387	0424	0431
		SAT 0202	0211	0234	0249	0253	0267
		0292	0321	0322	0335	0342	0419
		0438	0617	0717			
		DVD 0225	0234	0237	0301	0484	0986
		TNT 0202	0234	0267	0342	0419	0438
		0617					
		VCR 0218	0219	0295	0316		
SEIGA (MITSUBISHI)	TV	0202	0206	0220	0221	0242	0251
		0272	0296	0305	0356	0565	0639
		0674	0967				
		SAT 0202	0251	0288			
		DVD 0225	0639	TNT 0295	0202	0288	
		VCR 0223	0251	0295	0367		
SEIKO	TV	0220		DVD 0225			
SEI (SINUDYNE)	TV	0200	0202	0212	0214	0221	0224
		0227	0232	0250	0277	0290	0291
		0300	0330	0315	0426	0478	0479
		0497	0520	0529	0662	0755	0876
		0974					
		SAT 0202	0956				
		DVD 0200	0507	0520	0702		
		TNT 0202	VCR 0223	0300			
		SAT 0575	DVD 0642	0646			
SEITECH	SAT	0575	DVD 0642	0646			
SELECO	TV	0198	0200	0212	0214	0224	0233
		0240	0244	0270	0291	0305	0315
		0317	0347	0355	0365	0389	0402
		0457	0510	0563	0577		
		SAT 0211	0216	0249	0332	0448	0489
		DVD 0200	0225				
		VCR 0210	0213	0218	0219	0223	0265
		0283	0295	0302			
SELECT	TV	0202	SAT 0202	TNT 0202			
SEMP	TV	0456		SENDAY	TV	0198	
SENTRA	TV	0407	0524	VCR 0213			
SENYU	SAT	0350	0425				
SEPTIMO	SAT	0279	0602	0603	0689	0731	0811
		1037	1038				
SERINO	TV	0346					
SERVIMAT	TV	0234					
		SAT 0216	0234	0236	0253	0267	0399
		0429	0437	0438	0540	0610	0664
		1512		DVD 0234	0236		
		TNT 0234	0236	0267	0399	0438	0664
SERVISAT	SAT	0211	0335	0353	0380	DVD 0381	
SET	TV	0199	0240				
SETONE	SAT	0236	0253	0269	0543	0553	0753
		1419					
		TNT 0236	0269	0543	0553	0753	
		DVD 0236					
SETRON	VCR	0213					
SHADOW	SAT	0551		TNT 0551			
SHANGAI	DVD	0408					
SHARK	SAT	0409		TNT 0409			
SHARP	TV	0051	0057	0104	0201	0296	0305
		0662	0879	1255	1257	1352	1717
		SAT 1500	1503				
		DVD 0225	0512	0904	0997	1207	1228
		1235		VCR 0261			
SHINELCO	SAT	0269	0354	0477	0522	0558	0693
		0739	0749	1050	1051	1395	
		TNT 0269	0354	0477	0522	0693	0739

Brand	Type	Code						
SHINELCO	TNT	0749	1050	1395				
SHINTOSHI	TV	0199	0200	DVD	0200			
SHIVAKI	TV	0199	0200	0206	0213	DVD	0200	
SHIWAN (KAISUI)	TV	0198	0201	0230	0346	0427		
SHNIED	TV	0203						
ShOP+	SAT	0492			SHORAI	SAT	0300	
SHOV	TV	0199	0201	0203				
SIAREM	TV	0217	0221	0227	0277			
SICANTIC(LUXOR)	TV	0201	0207	0212	0231	0233	0248	
		0325	0348	0357	0373	0386	0387	
		0478	0501	0532	0588	0730		
	SAT	0327	0411	0417	0444	0467	0604	
	VCR	0207						
SICE	TV	0384			SIDEC	TV	0206	
SIEL	TV	0206						
SIEMENS	TV	0198	0207	0239	0316	0366	0384	
		0455						
	SAT	0288	0312	0523	0919	1024		
	TNT	0288	0523					
	VCR	0207	0213	0223	0265	0316		
SIERA	TV	0199	0200	DVD	0200			
SIESTA	TV	0286	0297					
SIGMATEK	DVD	0293	0534	0568	1155			
SILVA	TV	0199	0201	0203	0209	0239	0296	
		0376						
	SAT	0449	VCR	0213	0303			
SILVER	TV	0199	0200	0203	0207	0296		
	DVD	0200	0301		VCR	0207	0210	
SILVERCREST	SAT	0211	0638	1525				
SIMATEC (ORION)	TV	0199	0202	0203	0212	0214	0215	
		0224	0239	0275	0290	0300	0330	
		0356	0377	0426	0479	0497	0504	
		0529	0580	0583	0584	0589	0724	
	SAT	0202	DVD	0301	0512	0707		
	TNT	0202	VCR	0223	0300			
SIMTEL	TV	0203	0230					
SINGER	TV	0198	0199	0200	0201	0207	0217	
		0221	0227	0277	0280	0314	0389	
	DVD	0849						
		0200	0985	VCR	0207	0218	0219	
SINOTECH	TV	0203	0256	0541	0589			
SINUDYNE	TV	0200	0202	0212	0214	0221	0224	
		0227	0232	0250	0277	0290	0291	
		0300	0315	0330	0377	0426	0478	
		0479	0497	0520	0529	0617	0662	
		0755	0876	0974				
	SAT	0202	0309	0956				
	DVD	0200	0507	0520	0702			
	TNT	0202		VCR	0223	0300	0309	
SIREL	TV	0217						
SKANTIC(LUXOR)	TV	0201	0207	0212	0231	0233	0248	
		0325	0348	0357	0373	0386	0387	
		0411	0501	0532	0588	0730		
	SAT	0327	0417	0444	0467	0604		
	VCR	0207						
SKARDIN	TV	0234		SAT	0234	0236	0267	
	DVD	0234	0236	TNT	0234	0236	0267	
SKAY	TV	0199	0200	0230	DVD	0200		
SKR	SAT	0216						
SKT	SAT	0343	1087	TNT	0343			
SKY	TV	0120	0127	0136	0138	0140	0146	
		0167	0169	0178				
		0119	0120	0124	0127	0131	0135	
		0137	0139	0143	0148	0149	0153	
		0154	0155	0158	0159	0160	0164	
	SAT	0168	0170	0174	0175	0176	0184	
		0185	0187	0189	0190	0191	0192	
		0196	0197	0262	0813	0814	1369	
		1370						
SKY BIRO	SAT	0320	0432	SKYBOX	SAT	1308		
SKY BRASIL	SAT	0228	1043	TNT	0228			
SKY ENGLAND	SAT	0262		SKY IRELAND	SAT	0262		
SKY ITALIA	SAT	0262	0601	0616				
SKY LINE	TV	0201	0275		SAT	0216	0960	
SKY MASTER	SAT	0216	0253	0312	0326	0335	0429	
		0430	0431	0527	0535	0636	0789	
		0535	0789					
SKYMASTER	TV	0234						
	SAT	0234	0236	0267	0312	0429	0430	
		0431	0436	0437	0636	1512		
	DVD	0234	0236	0237	0362	0405	0436	
	TNT	0234	0236	0267				
SKYMAX	SAT	0273		SKY MEDIA	TV	0861		
SKY NEWZEALAND	SAT	0681	1081	1099	1141			
SKYPLUS	TV	0234						
	SAT	0234	0236	0253	0267	0335	0343	
		0400	0465	0490				
	DVD	0234	0236					

Brand	Type	Code					
SKYPLUS	TNT	0234 0465	0236	0267	0343	0490	0400
SKYVISION(HUTH)	SAT	0298 0544	0299 0647	0326 0709	0451	0473	0535
	TNT	0473	0535	0544	0647	0709	
SL	SAT	0298	0304	0307			
SLAVA	TV	0201					
SLIDING	TV	0311 0759	0454 0871	0528 0977	0576 0980	0754 0981	0756
	DVD	0781					
SMARAGD	TV	0349					
SMART	TV	0234					
	SAT	0234 0310 1423	0236 0335	0267 0485	0298 0517	0304 0816	0307 1113
	DVD	0234	0236				
	TNT	0234	0236	0267	0310	0816	
SM ELECTRONICS	TV	0234					
	SAT	0216	0234	0237	0253	0267	0436
	DVD	0234	0362	0405	0436		
	TNT	0234	0267				
SMR (MAXWELL)	TV	0198	0217	0227			
SOLAVOX	TV	0207	0248	0285	0411	0532	0728
	VCR	0207					
SOLARIS	SAT	0397	0474				
	DVD	0474	TNT	0397			
SOMBER (CLARIVOX)	TV	0200 0370	0217 0374	0221 0403	0222 0508	0264	0294
	DVD	0200					
	TV	0198					
SONICX	TV	0198	0200				
SONIKO	DVD	0200	0483				
SONITRON	TV	0201	0207	0221	0388	VCR	0207
SONNECLAIR	TV	0199	0200	DVD	0200		
SONOKO	TV	0198 0230	0199 0316	0201 0481	0203	0207	0215
	VCR	0207	0210	0218	0219	0316	
SONOLOR	TV	0207	0248	0316	0325		
	VCR	0207	0261	0316			
SONORO (AGASHI)	TV	0198	0199	0203		SAT	0299
SONSTIGE	SAT	0666					
SONTEC	TV	0199	0232	0286	0287		
	VCR	0210	0213	0218	0219		
SONY	TV	0042 0048 0356 0671	0043 0049 0463 0768	0044 0050 0476 0866	0045 0199 0541 0983	0046 0296 0591	0047 0336 0620
	SAT	0229	0262	1106			
	DVD	0391	0670	0773	0994	1170	1243
	SAT	0461		TNT	0461		
	TV	0198 0275	0202 0280	0203 0621	0212 SAT	0215 0202	0257
	TV	0251	SAT	0251	VCR	0251	
SOUND DESIGN	TV	0251	SAT	0251	VCR	0251	
SOUNDMASTER	DVD	0237					
SOUNDVISION	TV	0199	0227				
SOUNDWAVE	TV	0199	0203	0256			
SOUNDZONE	SAT	0309	VCR	0309			
SOUTHERN CROSS	TV	0509					
SOWTECH	TV	0286		SPARKLE	TV	0199	
SPECTRA	TV	0198	0203	0220			
SPECTRUM	TV	0251	SAT	0251	VCR	0251	
SPORT GENEXXA (FORMENTI)	TV	0198 0206 0231	0199 0207 0232	0201 0212 0235	0202 0214 0240	0203 0217 0242	0204 0220 0247
	TV	0258	0285	0290	0339		
	SAT	0202	0292	DVD	0204	0225	
SR	TNT	0202		VCR	0204	0207	
	SAT	0299					
SSANGYONG (SAMSUNG)	TV	0199 0212 0339 0559 0968	0200 0242 0358 0649 0972	0201 0251 0386 0682 0973	0203 0268 0411 0760	0204 0286 0415 0768	0207 0324 0443 0954
	SAT	0251 0465 0961	0262 0635 1011	0328 0649 1014	0351 0650 1042	0393 0678	0459 0734
	DVD	0200 0998	0204 1041	0598	0988	0993	0996
	TNT	0734	VCR	0204	0207	0251	0283
	TV	0203 0875	0206 DVD	0215 0625	0296 VCR	0424 0625	0531
	SAT	0627					
	TV	0198	0201	0230	0346	0427	
	TV	0199	0201	0209	0235	0314	
STAB	SAT	0627					
STAG (KAISUI)	TV	0198	0201	0230	0346	0427	
STANDARD	TV	0199	0201	0209	0235	0314	
	DVD	0340	0720		VCR	0218	0219
STABO	SAT	0648					
STAR	TV	0198	SAT	0743	1057	TNT	0743

Brand	Type	Code						
STARBOX	SAT	0246	TNT	0246				
STAR CLUSTER	DVD	0237	0362					
STARCOM	SAT	0353	0439	0661	0753	0935	1413	
		1506						
	TNT	0753	0935					
STAR DIJITAL	SAT	0420	0422	TNT	0422			
STARK	SAT	0246		TNT	0246			
STARLAND	SAT	0216	0682	0687	0950	1017		
STARLINE	TV	0198						
STARLITE	TV	0203	0280					
STARLUX	TV	0199	0201					
STARMEDIA	DVD	0534	0568	STARRING	SAT	0363		
STAR SAT	SAT	0216	0246	0254	0679	0825		
	TNT	0246						
START	TV	0199						
STAR TRACK	SAT	0254	0472					
STASSFURT (BRUNS)	TV	0221	0224	0227	0270	0297	0370	
	SAT	0216	0451	0794				
STELLA(CONNEXIONS)	SAT	0252		STENWAY	TV	0230		
STERLING	TV	0200	0202	SAT	0202			
	DVD	0200		TNT	0202			
STERN(SELECO)	TV	0198	0200	0212	0214	0224	0233	
		0240	0244	0270	0291	0305	0315	
		0317	0347	0355	0365	0389	0402	
		0457	0510	0563	0577			
	SAT	0211	0216	0249	0332	0448	0489	
	DVD	0200	0225					
	VCR	0218	0219	0265	0283	0295	0302	
STRATO	TV	0199	0200	0203	DVD	0200		
STREAM	SAT	0262	0448					
STRONG	TV	0234	0808	0878				
	SAT	0211	0228	0229	0234	0236	0246	
		0249	0253	0259	0267	0269	0299	
		0329	0335	0371	0395	0400	0418	
		0425	0429	0434	0474	0492	0493	
		0506	0536	0550	0602	0603	0607	
		0608	0614	0628	0663	0664	0808	
		0923	0960	1021	1025	1027	1047	
		1059	1085	1135	1389	1407	1435	
		1479						
	DVD	0234	0236	0394	0474	0533	1005	
	TNT	0228	0234	0236	0246	0267	0269	
		0371	0400	0550	0664	1047	1389	
STT SONIG	TV	0209			STV	TV	0248	
STVI	TV	0201	0206		SAT	0229	0353	
STYX	SAT	0460	0732	1416	1417			
SUCCESS	SAT	0342			TNT	0342		
SUNIC LINE	TV	0199						
SUNKAI	TV	0198	0199	0202	0300	0346	0349	
		0377						
	SAT	0202	0602	0603	DVD	0293	0416	
	TNT	0202	VCR	0218	0219	0300	0367	
SUNMOONSTAR	SAT	0228	0587	TNT	0228			
SUNNY	SAT	0495		TNT	0495			
SUNSTAR	TV	0198	0202	0203	0232			
	SAT	0202	0292	0298	0304	0307	0393	
	TNT	0202						
SUNSTECH	SAT	0253	0269	0337	0371	0464	0522	
		0615	0821					
	DVD	0340	0703	0735	0994			
	TNT	0269	0337	0371	0522	0821		
SUNWATT	TV	0209						
SUNWOOD	TV	0199			DVD	0483	0720	
SUPERJACK	SAT	1132		SUPERLA	TV	0206	0217	
SUPERSONIC	TV	0198	0203	0242	VCR	0302		
SUPERTECH	TV	0198	0199	0280	0376	0758		
SUPERTONE	TV	0201	0206	0217	0222	0235	0240	
(PATHCINEMA)		0264	0374					
SUPRA	TV	0201	0203	0220	0239	0251		
	SAT	0251						
	VCR	0213	0218	0219	0251	0283		
SUPRATECH	DVD	0899						
SUPREME	TV	0247	0314	SWISSTEC	TV	0861		
SYLVANIA	DVD	0625	VCR	0302	0625			
SYNN	DVD	0237	0362					
SYSTEC	SAT	0298	0304	0307	0312	0321	0322	
		0363	0638	0660	0928			
SYTEL (DESMET)	TV	0198	0199	0202	0206	0217	0235	
		0258	0442	SAT	0202	TNT	0202	
SYCLINE	TV	0201			SYDNEY	TV	0201	
SYMPHONIC	VCR	0302			SYNCRO	SAT	0430	
SYSLINE	TV	0199	0200	DVD	0200			
SYVO	SAT	0326			TADISTAR	TV	0256	
TAEYOUNG	SAT	0249	0395		TAGASHI	SAT	0299	
TAHNON	SAT	0494	0518	TNT	0494			
TAISHO	TV	0206						
TAKARA	TV	0202			SAT	0202		
	DVD	0696			TNT	0202		

Brand	Type	Code						
TALENT	TV	0230						
TALITA (CLARIVOX)	TV	0200	0217	0221	0222	0264	0294	
		0370	0374	0403	0508	DVD	0200	
TAMASHI	TV	0852						
TANDBERG	TV	0221	0291	0300	0315	0372	0398	
		0402	0442	1039				
	SAT	0952		VCR	0300			
TANDY	TV	0201	0207	0231	0233	VCR	0207	
TANGENT	DVD	1180			TANTEC	DVD	0394	
TARGA	DVD	1159						
TASHIKO	TV	0233		VCR	0261			
TASTER	TV	0203	0209					
TATUNG	TV	0198	0199	0201	0270	0324	0338	
		0356	0442	0525				
	SAT	0288		DVD	0293	0416		
	TNT	0288		VCR	0261	0367		
TAUTO	TV	0214						
TBOSTON	SAT	0246	0310	0337	0438	0464	0555	
		0650	0663	1069				
TCL	TV	0058	0080	0081	0082	0083	0084	
		0085	0086	0869				
TCM	TV	0268			TDA	TV	0215	
TD DESIGN	TV	0338						
TD SYSTEMS	TV	0057	0090	0091	0093	0095	0094	
		0096	0099	0100	0102	0103	0105	
		0107	0109					
TEAC / TEAK	TV	0202	0767	0209	0214	0242	0250	
		0272	0315	0767	0869	1061		
	SAT	0202	0236	0419				
	DVD	0236	0278	0513	0890	1184	1185	
		1208		TNT	0202	0236	0419	
TEAM	TV	0230						
TEC	TV	0316		VCR	0218	0219	0316	
TEC (DUAL)	TV	0198	0199	0201	0202	0206	0212	
		0214	0220	0222	0239	0243	0244	
		0248	0250	0268	0272	0275	0287	
		0290	0315	0323	0365	0372	0376	
		0410	0443	0453	0549	0885		
	SAT	0202		DVD	0278	0340		
	TNT	0202		VCR	0210			
TECHLINE	TV	0198	0200	0202	0227	0243	0424	
	SAT	0202	DVD	0200	TNT	0202		
TECHNEMA (FORMENTI)	TV	0199	0201	0202	0203	0204	0206	
		0207	0212	0214	0217	0220	0231	
		0232	0235	0240	0242	0247	0258	
		0285	0290	0339				
	SAT	0202	0292	DVD	0204	0225		
	TNT	0202	VCR	0204	0207	0210	0367	
TECHNIBOX	SAT	0313						
TECHNICAL	TV	0070	0090	0114	0202	TNT	0202	
	SAT	0202	0211	DVD	0237	0340	0362	
TECHNICS	TV	0271	0519	0581				
	DVD	0595		VCR	0271			
TECHNIKA	SAT	0452		TNT	0452			
TECHNILAND	TV	0209						
TECHNISAT	TV	0198	0214	0224	0308	0330	0570	
	SAT	0252	0273	0282	0308	0328	0331	
		0351	0364	0431	0447	0570	0617	
		0658	0685	0714	0949	1100		
	TNT	0617						
TECHNISSON	TV	0215						
TECHNOL	TV	0199	0201	0203	0220	0338		
TECHNOSAT	SAT	0320	0430	0432	0797			
TECHNOSONIC	SAT	0500		TECHNOWELT	SAT	0279		
TECHONMATE	SAT	0485	1015					
TECHWOOD	TV	0067	0090	0114	0202	0260	0308	
	SAT	0202	0211	0259	0273	0282	0308	
	DVD	0225		TNT	0202			
TECNIMAGEN	TV	0212	0344					
TECNISON	TV	0201						
TECO (AMSTRAD)	TV	0198	0199	0202	0203	0232	0234	
		0257	0260	0280	0290	0315	0330	
		0564	0590	0621	0726	0979		
	SAT	0202	0234	0262	0298	0299	0329	
		0404	0419	0459	0627	0655	0684	
		0763	1012					
	DVD	0225	0234	0278	0405	0533	0566	
		0694	0701	0706	0771	0774	0776	
		0777	0780	0894	0989	1000	1004	
		1006		TNT	0202	0234	0419	
TECSAT	SAT	0216		TECSOFT	TV	0269		
TECSONIC	TV	1281						
TEDELEX	TV	0198	0201	0206	0209	0403	0847	
		0869						
	DVD	0237	0599	0600	0719	0987	1160	
	VCR	0210	0303					
TEINEL,SA	TV	0222						
TEK	TV	0964			TEKA	TV	0964	

Brand	Type	Code					
TEKNANT	TV	0199	0230	TEKNIKA	TV	0509	
TEKVIS	VCR	0213		TELE+	SAT	0229	
TELE2BOX	SAT	0830					
TELEAVIA (THOMSON)	TV	0206	0233	0247	0255	0270	0274
		0284	0294	0349	0372	0375	0379
		0398	0401	0440	0441	0466	0482
		0498					
	SAT	0216	0228	0241	0245	0255	0352
		0369	0413	0446	0516		
	DVD	0360	0468				
		TNT	0228	0352	VCR	0265	0284
TELECHROM	TV	0199	0230				
TELECIEL	SAT	0516	0556				
TELECO	SAT	0313	0435	0739	TNT	0739	
TELECOM	SAT	0320	0432	0926	1060		
TELECOR	TV	0199	0200	DVD	0200		
TELEFUNKEN	TV	0055	0056	0057	0059	0064	0065
		0066	0090	0115	0114	0116	0199
		0200	0202	0255	0270	0274	0275
		0284	0372	0375	0378	0398	0401
		0441	0592	0767	0848	0948	0953
		0955	1348				
	SAT	0202	0249	0255	0369	0378	1356
		1365	1366	1371	1402		
	DVD	0200	0278	0772	0750	0880	1161
		1162	1232				
	TNT	0202	1356	1365	1366		
	VCR	0265	0284	0378	1371		
TELEFUSION	TV	0199	0200		DVD	0200	
TELEGAZI	TV	0199	0200	0248	0250	DVD	0200
TELEKA	SAT	0236	0252	0267	0299	0364	0393
		0396	0445	0459	0493	0538	0657
	DVD	0236	TNT	0236	0267		
TELEKTRON	TV	0227		TELEMANN	SAT	0569	
TELEMASTER	TV	0199	SAT	0395	0628		
TELEMAX	SAT	0605	0628				
TELEMEISTER	TV	0200		DVD	0200		
TELEPOINT	TV	0198		VCR	0295		
TELERENT	TV	0271	0338	VCR	0213	0271	
TELESERVICE	SAT	0229					
TELESONIC	TV	0199	0573				
TELESTAR	TV	0198	0203	0209	0256	0297	0319
		0570					
	SAT	0309	0312	0331	0335	0431	
	VCR	0309					
TELESYSTEM	TV	0202	0234	0410	0620	0754	0756
		0759	0809	0873			
		0202	0211	0229	0234	0236	0253
		0267	0335	0343	0345	0400	0425
		0429	0431	0437	0492	0527	0540
	SAT	0552	0558	0664	0744	0745	0807
		0809	0828	1297	1300	1303	1305
		1403	1404	1408	1420	1421	1469
		1497	1512	DVD	0234	0236	
		0202	0234	0236	0267	0343	0345
TELETECH	TV	0198	0200	0202	0243	0323	
		SAT	0202	0527	DVD	0200	TNT 0202
	SAT	0201	0231	0244	0296	0347	0365
TELETON	TV	0201	0231	0244	0296	0347	0365
TELEVES	SAT	0298	0304	0307	0312	0460	0475
		0496	0569	0571	0638	0647	0928
	DVD	1056	1057	1076	1188	1309	
		0475	0594	TNT	1076		
TELEVIEW	TV	0199	0200	DVD	0200		
TELEVIDEON	TV	0207		VCR	0207		
TELEWIRE	SAT	0269	0320	0432	0485	0636	0687
		1025	1061	1307			
TELEXA	TV	0227					
TELSEY	SAT	0269	0464	0552	0807	0928	1468
TELKOM	SAT	0211	0253	TELRA	TV	0199	
TEMAL	SAT	0216	0273				
TEMCO (SHORAI)	TV	0300		VCR	0300		
TEMPEST	TV	0199	0200	0201	DVD	0200	
TENSAI	TV	0198	0199	0200	0201	0202	0206
		0209	0220	0222	0224	0227	0232
		0235	0243	0268	0300	0314	0423
	SAT	0202	0436	DVD	0200	0436	0566
	TNT	0202		VCR	0213	0300	
TENNESSEE	TV	0198	0200	DVD	0200		
TESLA(TESLASLOW)	TV	0198	0200	0206	0209	0221	0264
		SAT	0617	DVD	0200	TNT	0617
TETHYS	SAT	0310	TNT	0310			
TETRAN	TV	0206	0235				
TEVION	TV	0198	0199	0202	0215	0268	
		SAT	0202	0236	0253	0267	0429
	DVD	0236	0360	0436			0436
		TNT	0202	0236	0267		
TEXET	TV	0201		TFT	TV	1268	

Brand	Type	Code					
THES	TV	0234	0976	1204			
	SAT	0234	0826	1378	1393	1501	
	DVD	0234	0780	1167			
	TNT	0234	1378	1393	1501		
THINK XTRA	DVD	0293					
THOMSON	TV	0058	0059	0071	0072	0073	0074
		0075	0076	0077	0078	0079	0086
		0087	0088	0089	0206	0233	0247
		0255	0270	0274	0284	0294	0349
		0372	0375	0379	0398	0401	0466
		0482	0498				
	SAT	0216	0229	0241	0245	0255	0279
		0352	0369	0380	0413	0420	0422
		0446	0492	0516	0550	0567	0737
		1059	1062				
	DVD	0237	0360	0362	0381	0468	
	TNT	0352	0422	0550			
	VCR	0218	0219	0265	0284		
THOMSON (AR-CEN-CIEL)	TV	0205	0233	0247	0255	0270	0274
		0284	0294	0349	0372	0375	0379
		0398	0401	0440	0441	0466	0482
		0498					
	SAT	0216	0228	0241	0245	0255	0352
		0369	0413	0446	0516	0801	
	DVD	0237	0360	0468			
	TNT	0228	0352	VCR	0265	0284	
THORENS	SAT	0369	0918	0537			
THORN(FERGUSON)	TV	0199	0203	0207	0209	0255	0264
		0270	0284	0308	0316	0375	0378
		0525	0531	0592	0593	0622	
	SAT	0241	0245	0254	0255	0259	0273
		0282	0288	0308	0327	0378	0404
		0486	0655		TNT	0288	
	VCR	0207	0213	0218	0219	0265	0284
		0316	0378	0367			
THUNDERMAX	TV	0308					
	SAT	0229	0252	0273	0282	0308	0364
		0444	0546	0958	1026	1030	
	DVD	0394	0546				
TIME	TV	0410	0630	0870	DVD	0545	
TIVU BOX	SAT	0741	1522		TNT	0741	
T-LOGIC	SAT	0542					
TM	SAT	0342	TNT	0342			
TMK	TV	0251	0290				
	SAT	0251	VCR	0251			
TMX	SAT	0229	0465	0958	1026	1030	0465
TM ELECTRON	TV	1581					
	SAT	0435	0492	0558	0735	1556	1627
		1645			DVD	1644	
TOBISHI	TV	0201	0203	0300	VCR	0300	
TOBO	TV	0203					
TOKAI	TV	0198	0200	0202	0203	0240	0308
	SAT	0202	0273	0282	0308		
	DVD	0200	0293	0301	0416	0483	0484
		0720	0986	1003			
	TNT	0202	VCR	0213			
TOKIWA (TOKAI/TOKAO)	TV	0198	0200	0202	0203	0240	
	SAT	0202	TNT	0202			
	DVD	0200	0301	0484	0719	1003	
TOKO (KATHREIN)	TV	0199	0626				
	SAT	0288	0313	0331	0341	0393	0486
		0536	0538	0572	0686	1022	
	TNT	0288					
TOKYO	TV	0230	0407				
TOMASHI (KAISUI)	TV	0198	0201	0230	0346	0427	
TOMITA	TV	0201					
TONBURY	SAT	0460	1097				
TONEBURST	SAT	0279					
TONNA	TV	0308					
	SAT	0216	0273	0279	0282	0308	0320
		0335	0437	0680	0687	1029	1512
TOPFIELD	SAT	0465	0491	0679	0692	0795	0827
		1363	1401	1406			
	TNT	0491	0692	1363			
TOPSAT	SAT	0246		TNT	0246		
TOPSHOW	TV	0203					
TOP VISION	TV	0199	0206	0240			
TORRE (THOMSON)	TV	0206	0233	0247	0255	0270	0274
		0284	0294	0316	0349	0372	0375
		0379	0398	0401	0482	0498	
	SAT	0216	0228	0229	0241	0245	0255
		0352	0369	0413	0446	0516	
	DVD	0237	0360	0468	0514		
	TNT	0228	0352				
	VCR	0265	0284	0316			
TOSHIBA	TV	0202	0215	0260	0305	0358	0366
		0407	0456	0462	0480	0503	0524
		0673	0675	0729			

Brand	Type Code						
TOSHIBA	SAT	0202	0241	0652	1049	DVD	0632
	TNT	0202	1049	1502	VCR	0283	0480
TOTOSI	DVD	0513					
TOWADA	TV	0206	0227				
TPROGRESS	DVD	0484					
TPS	SAT	0420	0422	0548	0733	0737	0830
		1096		TNT	0422		
TRANS CONTINENTS	TV	0198	0199	0202	0212	0243	0311
		0330	0344	0454	0755	0863	0980
		0981					
	SAT	0202		TNT	0202		
	DVD	0301	0340	0484	0534	0568	0596
		0643	0698				
TRANSONIC	TV	0199	0203	0272	0319	VCR	0302
TREVI	TV	0206	0230	0296	0590	0631	0977
	SAT	0269	0337	0371	0436	0452	0464
		0522	0615	0823	1056	1057	1295
		1296	1395	1439			
	DVD	0278	0340	0360	0436		
	TNT	0269	0337	0371	0452	0522	0823
		1395					
TRIAD	TV	0199	0200	0264			
	SAT	0216	0449	0607	0608	0657	0713
	DVD	0200					
TRIASAT(WISI)	SAT	0216	0252	0288	0447	0539	0606
		0637	0690	0713	0786	0792	0793
		0800		TNT	0288		
TRIAx	SAT	0211	0252	0298	0304	0307	0310
		0364	0399	0447	0518	0544	0611
		0658	0679	0927	1061		
	TNT	0310	0399				
TRIDENT	TV	0201	SAT	0246	TNT	0246	
TRILEC	SAT	0436	DVD	0436			
TRILUX	TV	1063					
TRISTAR	TV	0209	0256				
TRIUMPH	TV	0199	0200	0290	DVD	0200	
TSOSHI (KAISUI)	TV	0198	0201	0230	0346	0427	
TSVISION	SAT	1432					
TTR	TV	0864					
TVD	TV	0202	SAT	0202	TNT	0202	
TUCSON	TV	0090	0114				
TV CABO	SAT	0474	0618	DVD	0474		
TV HOME	SAT	0752	0949	TNT	0752		
TV STAR	TV	0511		SAT	1302	1474	
TWINNER	SAT	0216	0298	0304	0307	0312	0353
		0540	0764	0787			
TWINSAT	SAT	0413	0414	0439	0609		
	DVD	0394					
UHER	TV	0199	0200	0227	0231	0235	0244
		0338	0347	0406			
	DVD	0200		VCR	0213		
ULTRALINE	DVD	0408					
ULTRAVISION	TV	0264	0388				
ULTRAVOX	TV	0198	0199	0201	0207	0214	0220
		0221	0227	0232	0277	0287	0320
		0761		SAT	0351	0432	0952
	VCR	0207	0210	0218	0219		
UNDERWOOD	TV	0859					
UNIDEN	SAT	0396	0790	1145			
UNITED	TV	0202	0214	0215	0234	0260	0275
		0286	0410	0471	0477		
	SAT	0202	0211	0234	0309	0354	0464
		0738	0749	0827	1355	1384	1402
		1445					
	DVD	0225	0234	0237	0278	0362	0428
		0477	0483	0885	0992	0640	0645
	TNT	0202	0234	0337	0354	0738	0749
		1355	1384				
	VCR	0210	0218	0219	0309		
UNIC RADIO	TV	0201	0217	0222	0240	0286	
UNIMOR	TV	0198	0244	0286	0297		
UNISAT	SAT	0299	0923				
UNITOR	SAT	0321	0322	0363			
UNITRONIC	DVD	0512		UNIVERS	SAT	0917	
UNIVERSUM (QUELLE)	TV	0198	0199	0200	0201	0202	0203
		0206	0207	0209	0214	0224	0227
		0231	0232	0239	0243	0247	0248
		0250	0256	0257	0270	0271	0272
		0285	0286	0287	0290	0291	0294
		0296	0300	0305	0315	0324	0325
		0336	0338	0347	0348	0356	0357
		0358	0366	0376	0377	0384	0386
		0388	0398	0406	0415	0423	0424
		0441	0443	0453	0455	0456	0463
		0497	0501	0503	0504	0510	0519
		0549	0581	0585	0591	0613	0620
		0671	0715	0762	0983		
	SAT	0202	0288	0380	0393	0404	

Brand	Type	Code						
UNIVERSUM (QUELLE)	DVD	0200	0278	0381				
	TNT	0202	0288					
	VCR	0207	0213	0223	0271	0283	0300	
		0303	0613					
UNIVOX	TV	0200	0221	0222	0248	0264		
	DVD	0200						
UNK	TV	0198	0202	0206	0215	0217	0324	
	SAT	0202	DVD	0994	0995	TNT	0202	
UNITECH	SAT	0309		VCR	0309			
UPC	SAT	0548	1062					
URANIA (SAMBERS)	TV	0217	0227	0239	0264	0318	0406	
		0766		DVD	0598			
URANYA	TV	0198	0199	0204	0207	0217	0220	
		0235						
	DVD	0204		VCR	0204	0207	0213	
UTAX	TV	0201						
UTEK	SAT	0421		TNT	0421			
VANGUARD	TV	0201	0231					
VARIOSAT(WISI)	SAT	0216	0252	0288	0447	0539	0606	
		0633	0637	0690	0713	0786	0792	
		0793	0800	TNT	0288			
VECTOR RESEARCH	VCR	0303						
VEDIO - TECH	DVD	0703			VETA	SAT	0909	
VENTANA	TV	0202	SAT	0202	0273	TNT	0202	
VENTURER	DVD	0278		VERSATEL	SAT	1311		
VESTEL	TV	0051	0052	0053	0060	0061	0198	
		0199	0202	0206	0231	0232	0238	
		0243	0260	0263	0323	0376	0424	
	SAT	0202	0211	0263	0342	0419	0617	
	DVD	0225	0301					
	TNT	0202	0263	0342	0419	0617		
VEXA	TV	0199	0201	0230				
	VCR	0210	0218	0219	0295			
VIA	SAT	0352	0446	0843	TNT	0352		
VICEROY	TV	0201	0203	0239	0721			
VICTOR	VCR	0265						
VIDAR	TV	0207	VCR	0207				
VIDECON	TV	0209						
VIDEO ELECTR. CLUB	TV	0207	VCR	0207				
VIDEO LINK	SAT	0659						
VIDEOLOGIC	TV	0201	0203					
VIDEOMAC	TV	0201	0203		VIDEON	TV	0198	
VIDEOSAT	TV	0287	0323					
VIDEOSYSTEM	TV	0198	0200		DVD	0200		
VIDEOTON	TV	0200	0201	0202	0209	0222	0240	
		0243	0250	0256	0260	0624	0274	
		0314	0373	0388				
	SAT	0202	0211					
	DVD	0200	0225	0405	TNT	0202		
VIDESON	TV	0206						
VIDION	TV	0207						
	VCR	0207	0210	0218	0219	0295		
VIDIKRON	TV	0227	0235	0565				
VIDITAL	TV	0203		VCR	0210			
VIETA	DVD	0991		VISA ELECTR.	SAT	0938		
VISIOLA (PATH CINEMA)	TV	0201	0206	0217	0222	0235	0240	
		0264	0374					
VISIONIC	SAT	0254	0304	0434	0638	0810	0906	
		1013						
VISION MAGIC	TV	0528						
VISIONNET	SAT	0691		VISIONREX	TV	0217		
VISIOPACE	TV	0308		SAT	0273	0282	0308	
VISIOSAT	TV	1203						
	SAT	0216	0246	0252	0298	0310	0320	
		0321	0322	0363	0439	0469	0506	
		0539	0569	0638	0687	0916	0950	
		1032		TNT	0246	0310		
VISTAR	TV	0325	0502					
VISTA (THORN)	TV	0199	0203	0207	0209	0255	0264	
		0270	0284	0375	0378	0525	0531	
		0592	0593	0622				
	SAT	0241	0245	0254	0255	0259	0282	
		0288	0378	0404				
	VCR	0207	0265	0284	0288	0378		
VISION 2000	TV	0198	0200	0203	DVD	0200		
VORTEC	TV	0199	0200	0471				
	SAT	0216	0249	0328	0351	0459	0927	
	DVD	0200						
VOXSON	TV	0203	0221	0233	0247			
VTECH	SAT	0216	0449	0539	0557	0633	0657	
VTREK	DVD	1225		WAGNER	VCR	0285		
WAITEC	DVD	0360	0405					
WALKIE	TV	0244	0291					
WALKVISION	TV	0202	SAT	0202	TNT	0202		
WALTHAM	TV	0090	0117	0114				
WALTHAM (VIDEOTON)	TV	0200	0201	0209	0222	0240	0243	
		0250	0256	0260	0624	0274	0314	
		0373	0388		SAT	0202		

Brand	Type	Code					
WALTHAM (VIDEOTON)	DVD	0200	0225	0405	TNT	0202	
WATSON	TV	0198	0199	0202	0203	0209	0232
		0233	0235	0243	0268	0277	0290
		0319	0424	0832			
	SAT	0202	TNT	0202	VCR	0223	
WATT RADIO	TV	0199	0201	0204	0227	0277	0286
		0314	0316	0376	DVD	0204	
	VCR	0204	0210	0218	0219	0316	
WEBER	TV	0203	0272	0287			
WEGENER	SAT	0380		DVD	0381		
WEGAVOX	TV	0198	0200	0202	0203	0209	0214
		0243	0256	0275	0323	0453	
	SAT	0202	DVD	0200	TNT	0202	
WEGA VISION	TV	0221	0296	0356			
WELA	SAT	0473			WELKIN	SAT	0332
WELLFUND	TV	0230					
WELLINGTON	TV	0090	0114	0202			
	SAT	0202	TNT	0202			
WELLTECH	TV	0215					
WELTBlich	TV	0198	0199	0200	0232	0235	0280
		0758	DVD	0200	VCR	0210	
WELTBlick	VCR	0213	0218	0219			
WESDER	DVD	0428					
WESTON	TV	0200	0230	0240	DVD	0200	
WEST POINT	VCR	0283					
WESTWOOD	TV	0090	0114	0200	0202	0212	0573
	SAT	0202	0211	DVD	0200	TNT	0202
WHARFEDALE	TV	0200	0212	0573	DVD	0200	0985
WHITE WESTINGHOUSE	TV	0198	0199	0201	0203	0204	0206
		0207	0214	0222	0227	0230	0231
		0232	0235	0240	0244	0247	0256
		0277	0291	0318	0347	0415	
	DVD	0204	VCR	0204	0207	0210	
WHITE WESTINGHOUSE	TV	0207					
	VCR	0207	0213	0218	0219	0303	
WILSON	TV	0202			SAT	0202	
	DVD	0237	0340	0362	TNT	0202	
WINBOX	TV	0234					
	SAT	0234	0236	0253	0663	0745	
	DVD	0234	0236		TNT	0234	0236
WINERSAT	SAT	0321	0363	0469	0920		
WINDSOR	TV	0090	0114	0117	0199	0202	0243
	SAT	0202	0211	DVD	0225	TNT	0202
WINDSTAR (THORN)	TV	0199	0203	0207	0209	0255	0264
		0270	0284	0375	0378	0525	0531
WINDSTAR (THORN)	TV	0592	0593				
	SAT	0241	0245	0254	0255	0259	0282
		0288	0378	0404			
	TNT	0288		VCR	0207	0265	0378
WINDY SAM	TV	0200		DVD	0200		
WINSTON	TV	0199	0202	0230			
	SAT	0202		TNT	0202		
WINTERNITZ	TV	0220	0243	0837	SAT	0404	0655
WISI	SAT	0216	0252	0288	0343	0364	0380
		0447	0473	0539	0606	0633	0637
		0657	0690	0713	0786	0792	0793
		0800	DVD	0381	TNT	0288	0343
WISIORBIT	SAT	0473					
WITTENBERG	SAT	0245	0684				
WORLDSAT	SAT	0211	0228	0279	0298	0304	0307
		0413	0414	0449	0450	0609	0764
		0787	DVD	0394	TNT	0228	
WIZZ	SAT	1118					
WMM NETSTATION	DVD	0882	1226	1227			
WOORISAT	SAT	0395					
WORLDVIEW	TV	0198	0209				
WORLD TECH	TV	0199			WOV	TV	0383
WOXTER	SAT	0337	0371	0419			
	DVD	0646	0899	1176			
	TNT	0337	0371	0419			
XCELLENT	TV	0199	0280	0573			
XCOM	SAT	0414	0718		XENA	TV	0374
XIAOMI	AUX	0118					
XL - ELETTRONICA	DVD	0596		XONUM	DVD	0237	0362
XYNYCS	TV	0198			VCR	0210	
XORO	SAT	0342	DVD	1210	TNT	0342	
XRIPTON	TV	0198	0200	0256	0280	DVD	0200
XSAT	SAT	0279	0414	0718			
XTREME	SAT	0495		TNT	0495		
YAKUMO	DVD	0599	0600				
YAMAHA	SAT	0939		DVD	0306	0595	
	TNT	0939		VCR	0303		
YAMADA	SAT	0269	0371				
	DVD	0301	0599	0600	TNT	0269	0371
YAMISHI	TV	0200	0230	DVD	0200		
	VCR	0213	0218	0219			
YAMAKAWA	DVD	0301	1230				
YEOMAN	SAT	1368		TNT	1368		

Brand	Type Code							
YES	SAT	0681						
YOCAN	TV	0200		DVD	0200			
YOKO	TV	0198	0200	0203	0206	0220	0239	
		0240	0287	0372	0388	0511	0524	
		0585						
	DVD	0200	VCR	0213				
YON(PHILIPS)	SAT	0328		YOSHITA	TV	0199		
YOTAKA	TV	0199		YUKAI	DVD	0405		
YUMATU	TV	0203	0256					
	SAT	0400	0489	TNT	0400			
ZAMPA	TV	0233		ZANELA	TV	0662		
ZAPMASTER	SAT	0343		TNT	0343			
ZAPP	TV	0202	0263					
	SAT	0202	0211	0246	0263	0397	0399	
		0409	0490	0491	0617	0742		
	TNT	0202	0246	0263	0397	0399	0409	
		0490	0491	0617	0742			
ZANUSSI (SELECO)	TV	0198	0200	0212	0214	0224	0233	
		0240	0244	0270	0291	0305	0315	
		0317	0347	0355	0365	0389	0402	
		0457	0510	0563	0577			
	SAT	0216	0249	0332	0448	0489		
	DVD	0200	0225					
	VCR	0210	0265	0283	0295	0302		
ZEM	TV	0202	0263					
	SAT	0202	0246	0254	0263	0310	0397	
		0400	0491	0617	0742			
	TNT	0202	0246	0263	0310	0397	0400	
		0491	0617	0742				
ZEHNDER	TV	0234						
	SAT	0211	0234	0236	0292	0310	0312	
		0321	0322	0341	0363	0380	0393	
		0395	0439	0465	0485	0569	0686	
		0688	1061					
	DVD	0234	0236	0381				
	TNT	0234	0236	0310				
ZEPHYR	VCR	0210		ZINWELL	SAT	1150		
ZODIAC	TV	0234						
	SAT	0234	0236	0246	0249	0253	0254	
		0267	0310	0335	0354	0364	0396	
		0409	0421	0429	0451	0452	0472	
		0490	0493	0527	0551	0571	0656	
		0744	0745	1048	1057	1139		
	DVD	0234	0236	0594				
	TNT	0236	0246	0267	0310	0354	0409	
		0421	0452	0490	0551	0744	1048	
ZOPPAS (SELECO)	TV	0198	0200	0212	0214	0224	0233	
		0240	0244	0270	0291	0305	0315	
		0317	0347	0355	0365	0389	0402	
		0457	0510	0563	0577	DVD	0200	
ZOTA	TV	0308	SAT	0273	0282	0308		
ZWERNASE	SAT	0299						

