

ARTECK™

User Manual

Arteck HB030B Bluetooth® Keyboard



RoHS CE FC 204-620131

Warranty Claim: support@arteck.com

Welcome

Thank you for choosing this Arteck HB030B wireless keyboard. To ensure optimum performance and safety, please read these instructions carefully before operating this product. It is strongly recommended you keep the manual for future reference.

Statement

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by ARTECK is under license. Other trademarks and trade names are those of their respective owners.

"Windows" is a trademarks of Microsoft Corporation in the United States and/or other countries.

"Android" is a trademark of Google Inc.

Product Specifications

1. Standard Micro USB interface
2. Operating distance up to 10 meters
3. Modulation system: GFSK
4. Operation voltage: 3.0-4.2V
5. Operating current: <2.5mA
6. Standby current: <0.3mA
7. Sleep current: <40uA
8. Charge current: ≥ 200mA
9. Standby time: >200 days
10. Charge time: <2 hours
11. Lithium battery capacity: 500mA
12. Uninterrupted working time: >90 hours

1

- 13 Lithium battery specification: 3.8*20*35mm
14. Keying force: 60±10g
15. Keying life: 3 million strokes
16. Operating temperature: -10 - +55°

Package Contents:

Arteck HB030B Wireless Keyboard *1
Micro USB charging cable *1
User manual *1

Getting Started Guide

1. Button



On/Off Slide Switch: Slide switch ON or OFF to control the device power turn on or turn off.



Bluetooth Connect Button: The ON/OFF switch is already in the ON position, Press on the [Connect] button, the keyboard is now ready to be connected to your device.

2. Status Light



CAPS Status Light: Press on the [Caps Lock] button, the Caps Lock function will be on, and the Caps Lock Staus will be illuminated. Sometimes the light will not be on but function is valid for some Android system.



Bluetooth Status Light: Press on the [Connect] button, the [Status] light will be blink blue, indicator light will stay on until the keyboard connect with your device.



Charge Light: Turn on red when charging, become solid green when fully charged.



Battery Status Light: Slide the power button on. The blue light will illuminate for 4 seconds and then turn off to save power. Your keyboard is still on. The power light will be blinking at low battery.

2

3. Function Keys

	Virtual Keyboard		Select All		Copy
	Paste		Android/Windows Mail		Search
	Switching Language		Previous Track		Play / Pause
	Next Track		Volume down		Volume up
Fn+	Sleep / Wake	Fn+	Light On / Enhanced Light / Light Off	Fn+	Switch Backlit Colors
Fn+	Switch Backlit Colors	Fn+	Move the cursor to the top	Fn+	Move the cursor to the bottom
Fn+	Move the cursor to the beginning	Fn+	Move the cursor to the end		

iOS System

⌘+A	Select All	⌘+C	Copy	⌘+V	Paste
⌘+X	Cut	control+spacebar	Switching Language		

Android System / Windows System

Ctrl+A	Select All	Ctrl+C	Copy	Ctrl+V	Paste
Ctrl+X	Cut	control+spacebar	Switching Language		

Note: In Windows system, press F1-F12 to have F1-F12 function, press Fn+F1 to F12, the function will be the function showed on the icon. For example, Fn+F1 (Virtual Keyboard), Fn+F2 (Select All), Fn+F3 (Copy), Fn+F4 (Paste), Fn+F5 (Mail), Fn+F6 (Search), Fn+F7 (Switch Language), Fn+F8 (Previous Track), Fn+F9 (Play/Pause), Fn+F10 (Next Track), Fn+F11 (Volume Down), Fn+F12 (Volume Up).

Steps of Pairing the Keyboard with Your Device

- Step 1: On the keyboard, slide the power button on. The blue power light will illuminate for 4 seconds and then turn off to save power. Your keyboard is still on.
- Step 2: Press the [Connect] button, the status indicator will be blinking blue.
- Step 3: On your device, select: Setting - Bluetooth - On.
- Step 4: Your device will display "Bluetooth 3.0 keyboard" as an available device.
- Step 5: Select "bluetooth 3.0 keyboard" on your device, the keyboard is paired to your device now.
- Step 6: Press Fn+Q if your device is iOS; press Fn+W if your device is Anroid; press Fn+E if your device is Windows.

3

Notice:

If you didn't finish the step 6, some Windows system might cannot use F1-F12 properly. In this situation, you need to press Fn+e if your system is windows. If you are not able to connect the keyboard to your device, or if you have any problem or questions using the keyboard, please kindly contact with support@arteck.com for assistance. We will solve your issue with 100% satisfactory solution.

Fn+Function Keys Notice

Provide shortcuts to useful functions, first press and hold the Fn Key; second, press the function key you want to use.

Backlight with Colorful Keyboard Guide

1. Press the Fn+ [] light key one time to turn on the backlit, press the second time to enhance the backlit, press the third time to turn off the backlit.
2. Press Fn+ []+PgUp or press Fn+ []+PgDn to switch the backlit colors. This keyboard has 7 colors available to choose.

Charge the Battery

Turn on the Bluetooth keyboard.
The Power indicator light (blue) will illuminate for 4 seconds and then turn off to save power. Your keyboard is still on.
If the power indicator light keep blinking, it means the battery is low, you need to charge the keyboard with below steps:

1. Plug the Micro USB charging cable into the keyboard.
2. Plug the USB plug on a computer or USB power adaptor.
3. Charge for 1-3 hours, or until the charge light become solid green.

⚠ Caution:

1. When not in use for a prolonged period, it is recommended that you turn off the keyboard to lengthen battery life.
2. When the power status light flash, it is recommended that charging the keyboard not less than 2 hours.

Energy-saving Sleep Mode

Keyboard's long life battery lasts for several months of normal use. The keyboard will go into sleep mode if left on and not being used; press any key and wait a second or two to bring it out of sleep mode.

4

⚠ Safety Caution

1. Make sure the item away from sharp objects.
2. Do not place heavy object on the keyboard.
3. Away from microwave items.
4. Do not force or distorted the keyboard.
5. Keep away from oil, chemical or other organic liquid.

Cleaning

Clean the keyboard with water, alcohol or alcohol based disinfectant.

Troubleshooting

1. Make sure the keyboard is on (slide switch in "ON" position).
2. Make sure the keyboard is in operating distance (within 10 meters).
3. Ensure the battery storage has power.
4. Make sure the Bluetooth in tablet / PC / smartphone is on.
5. Ensure wireless keyboard have already match with bluetooth.

♻ Disposal of Waste Batteries

Insert screwdriver between plastic top and metal case at keyboard top or bottom and pry up plastic top and remove it completely. This action destroys keyboard separate battery from circuit board, it is your responsible to hand this over to an applicable collection and recycling will help to conserve natural resources and prevent potential negative consequences for human health and the environment due to the possible presence of hazardous in batteries and electrical and electronic equipment.

Warranty

Our company provides customers with a warranty of **24 months** from the date of purchase.

Contact Us

For any inquires or comments concerning our products, please send an email to support@arteck.com, and we will respond to you as soon as possible. If there is any quality-related issue with the product, you may request a replacement or refund by submitting a request to support@arteck.com.

5

Willkommen

Vielen Dank, dass Sie sich für diese schnurlose Arteck HB030B Tastatur entschieden haben. Um die bestmögliche Leistung und Sicherheit zu gewährleisten, lesen Sie sich bitte diese Anweisungen sorgfältig durch, bevor Sie dieses Produkt benutzen. Es ist ausdrücklich empfohlen, dass Sie dieses Benutzerhandbuch für zukünftige Referenzzwecke behalten.

Stellungnahme

Die Bluetooth-Wortmarke und Logos sind registrierte Handelsmarken und das Eigentum von Bluetooth SIG, Inc. Jede Nutzung dieser Marken durch ARTECK ist lizenziert. Andere Handelsmarken und Handelsnamen gehören Ihren jeweiligen Inhabern.

"Windows" ist eine Handelsmarke der Microsoft Corporation in den USA und/oder anderen Ländern.

"Android" ist eine Handelsmarke von Google Inc.

Produktspezifikationen

1. Standard Micro-USB-Interface
 2. Betriebsdistanz bis zu 10 Meter
 3. Modulationssystem: GFSK
 4. Betriebsspannung: 3.0-4.2V
 5. Betriebsstrom: <2.5mA
 6. Standby-Strom: <0.3mA
 7. Strom im Ruhezustand: <40uA
 8. Ladestrom: ≥ 200mA
 9. Standby-Zeit: >200 Tage
 10. Ladezeit: <2 Stunden
 11. Lithium-Batteriekapazität: 500mA
 12. Ununterbrochene Betriebszeit: >90 Stunden
 13. Lithiumbatterie-Spezifikationen: 3.8*20*35mm
 14. Tastungskraft: 60±10g
 15. Umgebungstemperatur: -10 - +55°
- Paketinhalte:**
Schnurlose Arteck HB030B Tastatur *1
Micro-USB Ladekabel *1
Benutzerhandbuch *1

6

Anleitung: Erste Schritte

1. Schalter



On-/Off-Schieberegler: Schieben Sie den Regler auf ON oder OFF, um das Gerät ein- oder auszuschalten.



Bluetooth-Verbindungsschalter: Der On-/Off-Schalter befindet sich bereits in der Position "ON"; drücke Sie den [Connect]-Schalter und die Tastatur wird bereit sein, mit Ihrem Gerät verbunden zu werden.



CAPS-Statusleuchte: Drücken Sie die [Feststelltaste] und die Caps-Lock-Funktion wird eingeschaltet; die CAPS-Statusleuchte wird dabei aufleuchten. Manchmal wird das Licht nicht leuchten, aber die Funktion ist gültig für einige Android-Systeme.



Bluetooth-Statusleuchte: Drücken Sie den [Connect]-Schalter und die [Status]-Leuchte wird blau blinken, die Leuchtanzeige wird an bleiben, bis die Tastatur sich mit Ihrem Gerät verbindet.



Ladeleuchte (Rot): Wird beim Aufladen eingeschaltet, wird bei voller Aufladung ausgeschaltet.



Batterie-Ladestatusleuchte: Schieben Sie den On-/Off-Regler auf "on". Die blaue Leuchte wird für 4 Sekunden aufleuchten und dann ausgeschaltet, um Strom zu sparen. Ihre Tastatur ist noch immer eingeschaltet. Die Stromleuchte wird bei niedriger Aufladung anfangen zu blinken.

3. Funktionstasten

	Virtuelle Tastatu		Alt	Alles auswählen		Kopieren
	Einfügen		Mail			Suche
	Sprache ändern		Vorheriger Track			Play/Pause
	Nächster Track		Lautstärke senken			Lautstärke erhöhen
Fn+	Lichtschalter/verstärken	Fn+	Lichtschalter/verstärken	Fn+		Lichtschalter/verstärken
Fn+	die Farben der	Fn+	auswählen	Fn+		die Farben der
Fn+	wechsleln	Fn+	die cursor in die	Fn+		wechsleln
Fn+	die cursor nach unten	Fn+	die cursor an die spitze	Fn+		die cursor nach unten
Fn+	die cursor an den anfang	Fn+	die cursor an das ende	Fn+		die cursor nach unten