



Original	Substituto	Original	Substituto
	Power		Power
	Viera Tools		Smart / List
	Tv Input		TV/ Radio /
	AV Input		AV / Input / RDS
	Menu		Menu / Home
	Text		Text / Got o
	[≡] / STTL		Sub title / EQ
	Gui de		Gui de / EPG / - / - -
	i		I n f o / Angl e
	X/ Exi t		Exi t / Cancel / Clear
	Up		Up
	Lef t		Lef t
	OK		OK
	Ri ght		Ri ght
	Opt i on		Set up / OPT /
	Down		Down
	Back/ Ret urn		Back / Ret urn

Original	Substituto	Original	Substituto
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yel low		Yellow / YouTube / Repeat
	Bl ue		Bl ue / Pri me Vi deo / Random
	Vol +		Vol +
	[+] / Aspect		Pi ct ure / For nat
	CH+		CH+ / Page+
	Vol -		Vol -
	Mute		Mute / Di mmer
	CH-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7



