

HOW TO CONNECT TWO SPEAKERS(TWS)

You can pair two speakers to create wireless stereo sound.


Long-press the Power Button to turn on both speakers.

Step 2:

Double-tap the Pause Button of one speaker until you hear an alarming sound, then you will hear a prompt tone again, indicating the two speakers are paired successfully. At that time, the blue light of one speaker stays on, and the other speaker flashes fast. (Note: Do not turn on your phone's Bluetooth function before the pairing is successful.)

Step 3:

Turn on your device's Bluetooth and choose "DB N7A", it will automatically connect to one of the speakers. At that time, the blue light of both speakers stays on. When the pairing is completed, you can enjoy wireless stereo sound from both speakers.







- 1.Long press to turn on the Bluetooth speaker.
- 2. Plug one end of the cable into your device's headphone jack and insert the other end into the speaker. The blue light of the speaker stays on
- 3. You can start playing music. Note: When the audio cable is plugged into the speaker, the Bluetooth function will not be available.

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

WARNING

1. Must seal the charging port when not charging to prevent water from entering!!

2. Please fully charge the speaker before use 3. No Bluetooth connection for 15 minutes will be

IMPORTANT SAFETY INFORMATION

1. Environment and temperature

Operating temperature should be between 0°C to 40 °C/ 32°F To 104°F.
Keep away from extreme temperature environments (such as high temperature fire, direct sunlight or extremely cold environment) to avoid battery

Do not approach heat sources (such as stoves, engines and other heating equipment).

2. Use and maintenance (wrong model may cause explosion risk).

Do not use corrosive detergents/oils to wipe the Keep away from water or humid environments (such as rainy days) when charging to prevent electric

CHARGING

Fully dry off the speaker and the USB port before

The battery may go to sleep or die if it doesn't charge/discharge for a long time. Please charge and discharge it at least one time per month.

NOTICE

This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Follow local rules and never dispose of the product and rechargeable batteries with normal household waste. Correct disposal of obl products and rechargeable batteries helps prevent negative consequences for the environment and human health.

正面



尺寸: 100*300mm

材质: 105克铜版纸正反面彩色印刷, 折页