










Dell 34 Plus USB-Cモニター
S3425DW































Dell Display and Peripheral Manager
[Dell.com/support/ddpm](https://dell.com/support/ddpm)



[Dell.com/support/S3425DW](https://dell.com/support/S3425DW)