


HAUGA



Design and Quality
IKEA of Sweden



English

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.

ALWAYS secure this furniture to the wall using tip-over restraints.

To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on top of this product.
- Never let children climb or hang on drawers, doors, or shelves.

עברית

אזהרה

נפילת הרהיט עלולה לגרום לפגיעה גופנית חמורה או קטלנית.

יש לקבע את הרהיט לקיר באמצעות אבזרי הקיבוע המצורפים.




על-מנת למזער את סכנת הפגיעה הגופנית או המוות מנפילת רהיטים:




- מקמו את הפריטים הכבדים ביותר במגירה התחתונה.
- הימנעו מלהניח טלוויזיות או פריטים כבדים אחרים על מוצר זה.
- אין לאפשר לילדים לטפס על המגירות, הדלתות או המדפים.











1




101345

14x




146113

4x




139434
139456

14x




139435
139457

14x




151706
151708

18x




151705
151707

18x




153548
158568

2x



10040039
10051022

4x




10050827

2x



113434

4x




10042365
10044438
10070213

4x



11


2




22x




8x




2x




2x




3x



4x




1x




4x







326949




1




2




3




4




5




6




7




8




9



10




11





12

18x




13


14x




14




18x






15





16








18








www.IKEA.com/secure-it



www.IKEA.cn/secure-it

20







English

The screw(s) and plug(s) supplied can be used with most solid (A) and hollow (B) walls. For solid wood (C) use the screw(s) without plug(s). If you are uncertain, seek professional advice.


עברית

הבורג(ים) והדיבל(ים) המצורפים מתאימים לרוב סוגי הקירות המוצקים (A) והקירות החלולים (B). לקירות עץ (C) השתמשו בבורג (ים) ללא דיבל(ים). במידה ואינכם בטוחים, יש להתייעץ עם איש מקצוע.







22












23




24











27





28


















33








35



36





English


Wipe clean with a cloth damped in a mild cleaner.

Wipe dry with a clean cloth.

עברית

נקו בעזרת מטלית וחומר ניקוי נוזלי.

נגבו לייבוש בעזרת מטלית רכה.



36-1

