


Trouble Shooting

If any functional abnormality is encountered, unplug the unit from the mains socket and reconnect it again. Replace your mobile device on the unit.

1. The LED indicator flash in red.
 - a) Mobile device is not placed in a correct position.
 - b) Placing any metal or other item with electric field may cause short circuit, such as credit card, key, memory card, etc.
 - c) The charging system is malfunction.



Specifications

Power Supplies	Input: 5V \equiv 2A or 9V \equiv 2A Output: max. 10W
Charging Distance	3 mm (max.)
Frequency Band(s)	106.81 – 175.56 kHz
Max. Radio Frequency Power Transmitted	22 dBuA/m @3m distance
Dimension (L x W x H)	86 x 86 x 8.2 mm
Net Weight	72 g

Features and specifications are subject to change without prior notice.



Declaration of Conformity (RED)

Hereby, DSG Retail Ltd. declares that the radio equipment type [GP10WC20] is in compliance with Directive 2014/53/EU.
The full text of the EU declaration of conformity is available at the following internet address:
<https://www.teamknowhow.com/>
Click on **SEARCH** and enter the model number.

Goji

10W Qi Wireless Charging Pad with Mains Charger

Instruction Manual

GP10WC20




Thank you for purchasing your new product.

We recommend that you spend some time reading this instruction manual in order that you fully understand all the operational features it offers. You will also find some hints and tips to help you resolve any issues.


Read all the safety instructions carefully before use and keep this instruction manual for future reference.

Product Overview




Charging Your Digital Devices

1. Connect the USB charging cable to the product.
2. Connect the other end of the USB charging cable to a powered USB device.




3. Place your mobile device on the top of the product. Ensure it is on the right position/direction.



This product only supports mobile device with Qi feature.

4. Both Qi sensors must overlap.



Status	Charging indicator
Charging	Light up in green
Fully charged	Light off
Error	Flash in red

