

CRAZY LONG 24-MONTH WARRANTY

For warranty service, contact myweego.com/support.

DO NOT return product to your retailer.

WHAT THIS WARRANTY COVERS: PARIS CORPORATION ("Paris") sells its products with the intent that they are free of defects in material and workmanship under normal use and service for a period of 24 months from the date of original purchase, except as noted below.

This warranty extends only to consumers and specifically does not extend to Retailers, sellers or their agents or employees. Paris does not authorize anyone, including, but not limited to, Retailers, the subsequent consumer purchaser of the product from a Retailer or remote purchasers, to obligate Paris in any way beyond the terms set forth herein.

This warranty does not cover damage caused by misuse or abuse; accident; alteration to the product; attachment of any unauthorized accessory; improper use of an electrical/power supply that causes malfunction; loss of power; dropped or crushed product; malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance; tampering with or attempt to modify the product; unauthorized opening of the product; transportation damage; theft; neglect; vandalism; environmental conditions; loss of use during the period the product is at a repair facility or otherwise awaiting parts or repair; or any other conditions whatsoever that are beyond the control of Paris.

This warranty is effective only if the product is purchased and operated in the country in which the product is purchased. A product that requires modifications or adaptations to enable it to operate in any other country than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications is not covered under this warranty.

This warranty does not extend to the purchase of opened, used, repaired, repackaged and/or resealed products, including but not limited to sale of such products on Internet auction sites and/or sales of such products by surplus or bulk resellers. Any and all warranties or guarantees shall immediately cease and terminate as to any products or parts thereof which are repaired, replaced, altered, or modified, without the prior express and written consent of Paris.

Paris shall not in any way be liable to you or any third party for any damages you or any third party may suffer as a result of use, intended or unintended, or misuse of this product in conjunction with any device, equipment or accessory other than the appropriate device or equipment for which this product is designed. Paris will not be responsible for any damages you or any third party may suffer as a result of misuse of this product outlined above. If you are responsible for this product's use with any unintended device and damages result from such use, you agree to indemnify Paris for any resulting injuries to any third parties.

WHAT WE WILL DO TO CORRECT DEFECTIVE PRODUCT: If Paris determines that a returned product has a defect in manufacture or workmanship under normal use, Paris will, at its sole discretion, repair or replace the defective part or parts, or if necessary, provide a like or comparable product from its product line. Paris will repair or replace the defective product free of charge and return the product to the stated consumer's US address only, free of charge. If replacement parts for defective materials are not available, Paris reserves the right to make comparable product substitutions in lieu of repair or replacement. No refunds will be given. If Paris determines that the product is not defective, it will return the product to the consumer at the consumer's expense.

HOW DO YOU GET SERVICE: To obtain warranty service, contact our

Weego Customer Support Specialist:

by email: support@myweego.com

via online: myweego.com/support

Do not return product for warranty service to your Retailer. The Specialist will provide direction on how to return the defective product for service. Paris must be notified of claim within warranty period and in writing. Paris must receive product within 10 days after consumer notified Paris of a possible claim.

REMEDIES: The warranty provided herein shall be the sole and exclusive warranty. There shall be no other warranties express or implied, or any other obligation on the part of the company with respect to products covered by this warranty. Paris shall have no liability for any incidental, consequential or special damages. In no event shall this warranty require more than the repair or replacement of any part or parts which are found to be defective within the effective period of the warranty.

HOW STATE LAW MAY RELATE TO THE WARRANTY: This warranty provides you with specific legal rights. You may have additional rights which may vary from state to state. Because of individual regulations, some of the above limitations and exclusions may not apply to you.



12V DC

Adapter

Item# JSFSA

Owner's Manual & Warranty



Compatible with Weego Jump Starter N70



Learn About Your Weego 12V DC Adapter!

There are so many tools and accessories you can power through the 12V (12 Volt) “cigarette” adapter in your car, but Weego is all about portability. Use the Weego 12V DC Adapter to power your 12V electronics on the go using your Weego Jump Starter as the power source!

Before Getting Started

The port used to power your 12V electronics is rated for 12V and 10A (10 amps). For this reason, make sure the power draw of your tool and/or accessory is 10A or less – this information can be found in the product’s manual or on the product itself. Weego Jump Starters won’t power anything that needs more than 10A to run!

Ready, Get Set, Weego!

1. Connect your 12V DC Adapter into the 12V/10A port of your Weego Jump Starter.
2. Connect the barrel plug of your tool or accessory into the barrel socket of your Weego 12V DC Adapter.
3. Power on your Weego and enjoy! It’s as simple as that.

Keep in Mind . . .

Run time will vary depending on a number of factors, including:

- Power draw of your accessory – the more amps it needs, the faster it will drain your battery.
- Simultaneously charging other devices – We suggest not using your Weego Jump Starter to charge other devices (like phones and laptops) while powering electronics through the 12V DC Adapter because this will drain your battery too quickly.

Warnings

- **DO NOT** use your Weego Jump Starter to jump start a vehicle while powering electronics through the 12V DC Adapter.
- **DO NOT** connect an accessory or tool that draws a current larger than 10A. Weegos are only equipped to power any tool or accessory requiring 10A or less during use.
- **DO NOT** expose your Weego 12V DC Adapter to moisture, or use in a wet environment, especially when plugged into the Weego Jump Starter and/or while using the product to power 12V electronics.
- **DO NOT** use the 12V DC Adapter in any way other than as directed in this manual.
- **DO NOT** use 12V barrel jack extension cables to extend the reach of your Weego 12V DC Adapter.
- **DO NOT** place fingers or other foreign objects into the 12V DC Adapter.

Visit myweego.com to learn more about other Weego products and accessories.

Weego is dedicated to providing the best possible service. To reach Weego Customer Support, visit myweego.com/support