

Be Daringly Innovative



Voice Assistant

Step 1: Long press the MFB on either earbud for 2 seconds to activate voice assistant

Step 2: The respective voice assistant screen pops up and you may place your commands at ease

Tips: You may try the following commands,

- What is the weather?
- Play a song
- Set a reminder



Airdopes

631

Twin Wireless Ear-buds


Get ready to immerse yourself in pure audio bliss with your very own pair of boAt Airdopes 631. Please consider this manual as your guiding map towards the shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

Smart Power Off

Step 1: After usage, remove both the earbuds from your ears

Step 2: Place the earbuds back into the charging case in correct orientation


Step 3: The earbuds will automatically switch off (and enter into charging mode)



Manual Power Off

Step 1: Long press the MFB on either earbud for 5 seconds until the LED flashes red, in order to manually switch off the earbuds. Please note that this powers off both the earbuds

Step 2: Please keep the earbuds back into the charging case to charge the earbuds



In the box

1x pair of Ear-Buds

1x Charging Case

2x Pairs of Additional Earmuffs

4 User Manual

1x Type-C Charging Cable

2x SportClip

Product Overview

1


MFB (Multi Function Button) / Power Button

2

Indicator Lights

3

Type-C Charging Port




Power On (First Time User)

Step 1: To automatically switch the earbuds on (Smart Power On) simply take them out from the charging case


OR

To manually switch the earbuds on (Manual Power On), long press the Multifunction Button (MFB, we'll refer to this as MFB for sake of convenience) on both earbuds for 3 seconds until the LED starts to flash in white


Step 2: The earbuds enter into pairing mode indicated by alternate white and red LED flashes.




Step 3: Turn on Bluetooth functionality on your phone and search.




Step 4: Select 'Airdopes 631' right/ left from the list (The connected earbud is the Master earbud)



Step 5: Once the Master earbud gets connected, a connection window for another earbud also pops up. Please pair with the same to establish the complete connection.




Congratulations! Your earbuds are now connected successfully via Bluetooth



Notes:

- Pairing mode lasts for 5 minutes. If the pairing time is missed then you will need to reconnect the ear-buds and follow the above mentioned procedure
- Airdopes 631 remembers previously connected devices; once switched on, the ear-buds automatically reconnect to the previously connected devices



Factory Reset

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 631


Step 1: Place both the earbuds back into the charging case in correct orientation to switch them off

Step 2: Triple tap the MFB on both earbuds to perform the Factory Reset. Once done, it gets indicated by a white LED flash

Step 3: Shut the lid of the charging case and then re-open it again

Step 4: Once you take the earbuds out from the charging case, they automatically restart

Congratulations! Your Airdopes 631 has been Reset



Single Earbud Usage


Step 1: Please note that both the earbuds can be used in mono mode. Use Smart Power On for switching on the desired earbud

Step 2: The selected earbud will automatically enter the connection mode indicated by alternating white and red LED flashes


Step 3: Turn on Bluetooth on your phone/media device and search for 'boAt Airdopes 631' to connect

Notes:


- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage.
- You cannot skip tracks or return to the previous tracks in Mono mode.



Common Problems with Solutions

If only one earbud is functioning:

Simply insert the earbuds back into the case and take them out or perform the Factory Reset

If earbuds are not in scan mode:

Simply insert the earbuds back into the case and take them out or perform the Factory Reset

LED Indicators / Functionalities

2 Seconds

Long press the MFB on either earbud for 2 seconds to activate voice assistant (White LED)

3 Seconds

Long press the MFB on both earbuds up to 3 seconds for Manual Power On (White LED)


5 Seconds

Long press the MFB on either earbud up to 5 seconds for Manual Power Off (Red LED)

Triple Tap

Triple tap the MFB on both earbuds to perform the Factory Reset (White LED)

MFB (Multi Function Button)



Specifications

Bluetooth Version	V5.0
Water Resistance	IPX5
Chipset	QUALCOMM
SNR	57dB
THD	2%
Music Playtime	Up to 5.5H Per Charge (Up to 22H with Case)
Talk Time	Up to 5.5H
Standby Time	Up to 55 Days
Transmission Range	10m
Driver Size	6mm
Bluetooth Profile	HFP /AVRCP /A2DP /SPP
Mic Sensitivity	-42±3db
Battery Earbuds	55mAh x2
Battery Charging Case	450mAh
Charging Time	Up to 2H
Product Weight	60g

Troubleshooting


Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection/scan mode	Perform the Factory Reset
If earbuds disconnect during phone call	Charge the earbuds or perform the Factory Reset
If there are other exceptions in usage	Place the earbuds back into the charging case and try using them again or perform the Factory Reset

Charging The Case

Step 1: To charge the case, plug one end of the charging cable into the case and the other end into a USB port/ charging adapter

Step 2: The blinking white LED on the case indicates that the charging case is being charged. Once the charging case gets fully charged, the LED turns off

Note: The LED located on the charging case indicates the battery status of the case.



Warning

Please follow the instructions to operate

Please don't use the ear-buds in extreme temperatures

Please don't use the product near water

Please keep the product away from heat sources, as the heat may damage it

Don't jam the ports such as charger port, LED port, etc.

It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life.

Advisable: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the volume control on the phone/ media device.

Charging norms & Precautionary Guidelines:

1) Charger/Brid/Adapter

1) Cable/Wire

: 5V/2A

: Standard Cable (35 Strands @0.10mm diameter/strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

Airdopes

Twin Wireless Ear-buds

boat

Be Daringly Innovative

