



T63

PRODUCT USER MANUAL


Specifications

Product Name: T63	Bluetooth: TMKB T63
Backlight: RGB	Material : Case-ABS, Keycaps-ABS
Battery: 3000 mAh	Optional Mode: Wired / Bluetooth / 2.4G
Key: 63 Keys	Interface Type: Type-C / Bluetooth / 2.4G
Size: 292.8×101×42mm	Product Weight: 640g±20g
Package Included: Keyboard, Type-C Cable, Keycaps Puller、User Manual、2.4G Dongle	

If you have any problems or need assistance related to this product, please feel free to ask our customer service for help.
Email:customer@Kemove.com

Instruction for Using Fn Key


Bluetooth



- ① Set the switch of the back to bluetooth mode.
- ② Long press Fn+C/V/B, the light of C/V/B key blinks to turn on the Bluetooth pairing, and search "TMKB T63" to complete the connection pairing.
- ③ Short press Fn+C/V/B to switch to the connected Bluetooth device 1/2/3.

Instruction for Using Fn Key


Profile & Function



- Fn**: check current configuration layer, system layout and Bluetooth channel.
1. **Fn** key pressed ,the lighting key(Q/W/E/R/T KEY) corresponded to the current configuration layer .
 2. **Fn** key pressed, the lighting key (Z/X KEY) corresponded to the current system.
 3. **Fn** key pressed, the lighting key(C/V/B KEY) corresponded to the current channel of Bluetooth.

Instruction for Using Fn Key


Profile & Function



- Fn+1**: F1
Fn+4: F4
Fn+7: F7
Fn+0: F10
- Fn+2**: F2
Fn+5: F5
Fn+8: F8
Fn+.: F11
- Fn+3**: F3
Fn+6: F6
Fn+9: F9
Fn++: F12
- Fn+Esc**: `~
Fn+Shift+Esc: ~`

Instruction for Using Fn Key


Profile & Function



- Fn+U**: PrtSc
Fn+J: Ins
Fn+M: Del
- Fn+I**: ScrLK
Fn+K: Home
Fn+.: End
- Fn+O**: Pause
Fn+L: PgUp
Fn+>: PgDn

Instruction for Using Fn Key


Profile & Function



- Fn+Q**: Profile 1
Fn+T: Profile 0
Fn+Win: Win key locked / unlocked (Win key light change to white when locked, it follows current light mode when Win key is unlocked.)
Fn+Spacebar: Fn key locked/unlocked (Fn key flashes red light when locked, it follows current light mode when Fn key is unlocked.)
- Fn+W**: Profile 2
Fn+E: Profile 3
Fn+R: Profile 4

Instruction for Using Fn Key


Multi-Media



- Fn+A**: Play / Pause
Fn+F: Mute
- Fn+S**: Previous song
Fn+G: Volume down
- Fn+D**: Next song
Fn+H: Volume up


Instruction for Using Fn Key

Lighting



- Fn+Backspace**: Turn the light on / off
Fn+Enter: Switch light colours
Fn+.: Weaken light brightness
- Fn+]**: Change custom lighting
Fn+/?: Switch light modes
Fn+~: Speed down light effect
- Fn+|**: Power saving mode
Fn+↑: Increase light brightness
Fn+→: Speed up light effect

Toggle switch & Indicator



BT Mode
The switch set to BT mode, connect keyboard to BT device to use.

2.4G mode
The switch set to 2.4G mode, plug the receiver into computer to use.

Wired mode
The switch set to wired mode, plug the cable into computer to use.

Fn+N: 2.4G mode
● Turn on 2.4G mode
Fn+right Alt: Battery status:
● 0%~20% The spacebar key flashes red light
● 20%~80% The spacebar key flashes green light
● 80%~100% The spacebar key flashes blue light

Fn+C/V/B:
Bluetooth mode
● Turn on BT1 mode
● Turn on BT2 mode
● Turn on BT3 mode