



T63

PRODUCT USER MANUAL


Specifications

Product Name: T63	Bluetooth: TMKB T63
Backlight: RGB	Material : Case-ABS, Keycaps-ABS
Battery: 3000 mAh	Optional Mode: Wired / Bluetooth / 2.4G
Key: 63 Keys	Interface Type: Type-C / Bluetooth / 2.4G
Size: 292.8×101×42mm	Product Weight: 640g±20g
Package Included: Keyboard、Type-C Cable、Keycaps Puller、User Manual、2.4G Dongle	

If you have any problems or need assistance related to this product, please feel free to ask our customer service for help.
Email:customer@Kemove.com

Instruction for Using Fn Key

Bluetooth



Fn+C=BT 1


Fn+V=BT 2

Fn+B=BT 3

- ① Set the switch of the back to bluetooth mode.
- ② Long press Fn+C/V/B, the light of C/V/B key blinks to turn on the Bluetooth pairing, and search "TMKB T63" to complete the connection pairing.
- ③ Short press Fn+C/V/B to switch to the connected Bluetooth device 1/2/3.

Instruction for Using Fn Key

Profile & Function




Fn: check current configuration layer, system layout and Bluetooth channel.

1. Fn key pressed ,the lighting key(Q/W/E/R/T KEY) corresponded to the current configuration layer .
2. Fn key pressed, the lighting key (Z/X KEY) corresponded to the current system.
3. Fn key pressed, the lighting key(C/V/B KEY) corresponded to the current channel of Bluetooth.

Instruction for Using Fn Key

Profile & Function



Fn+1: F1

Fn+4: F4

Fn+7: F7

Fn+0: F10

Fn+2: F2

Fn+5: F5

Fn+8: F8

Fn+_: F11

Fn+3: F3

Fn+6: F6

Fn+9: F9


Fn++: F12

Fn+Esc: `

Fn+Shift+Esc: ~

Instruction for Using Fn Key

Profile & Function



Fn+U: PrtSc

Fn+J: Ins

Fn+M: Del

Fn+I: ScrLK

Fn+K: Home

Fn+,: End


Fn+O: Pause

Fn+L: Pgup

Fn+>: PgDn

Instruction for Using Fn Key

Profile & Function



Fn+Q: Profile 1

Fn+T: Profile 0


Fn+Tab: Press long until light of the keyboard blinks, the keyboard reset to the factory default settings.

Fn+Win: Win key locked / unlocked (Win key light change to white when locked, it follows current light mode when Win key is unlocked.)

Fn+Spacebar: Fn key locked/unlocked (Fn key flashes red light when locked, it follows current light mode when Fn key is unlocked.)

Instruction for Using Fn Key

Multi-Media



Fn+A: Play / Pause

Fn+F: Mute

Fn+S: Previous song


Fn+G: Volume down

Fn+D: Next song

Fn+H: Volume up

Instruction for Using Fn Key

Lighting



Fn+Backspace: Turn the light on / off

Fn+Enter: Switch light colours

Fn+↓: Weaken light brightness

Fn+[]: Change custom lighting

Fn+/: Switch light modes


Fn+←: Speed down light effect

Fn+|: Power saving mode

Fn+↑: Increase light brightness

Fn+→: Speed up light effect

Toggle switch & Indicator



BT Mode

The switch set to BT mode, connect keyboard to BT device to use.

2.4G mode

The switch set to 2.4G mode, plug the receiver into computer to use.

Wired mode

The switch set to wired mode, plug the cable into computer to use.

Fn+N: 2.4G mode

● Turn on 2.4G mode

Fn+right Alt: Battery status:

● 0%~20% The spacebar key flashes red light

● 20%~80% The spacebar key flashes green light

● 80%~100% The spacebar key flashes blue light

Fn+C/V/B:

Bluetooth mode

● Turn on BT1 mode

● Turn on BT2 mode

● Turn on BT3 mode