## 尺寸:80mm\*130mm

INSTRUCTION MANUAL

Product Illustration

O Down-page button (6) Data interface (9) shell



(WiFi mode shutdown needs to exit the APP).

Power on the direct video mode short press\* " key to start recordings video state short press\* " " key to start recordings video state short press\* " in the state precording and save the current video file, in the main interface to enter the video mode first switch to the video know and then short press\* " in " key to enter the video mode (turn on the time-lapse video recording video file suffix is GAP).

(3) Videotane:

(4) Take a picture:

(5) Photo album:

▶ Installation of TF card

Insert the TF card as shown
 Please use a genuine TF card
 Support 8-256G, U3 high speed card

► Main interface operating

The device power on directly into the recording mode the recording mode short press "④" or" ▶ key to enter the main interface, in the main interface short press "④" ▶ \*key to switch icross and select the desired mode short press " ▶ \*key to enter.

\*\*Rey to enter.\*\*

(6) Set up:

Reset

APP Download

• In the main interface select the setup icon short press "■" to enter the setup, in the setup menu can be selected up and down by short press "② ② key, short press "■" key can be modified by various parameter settings, long press "⑤" to return to the previous step or exit.

APP operation photo and video; preview interface clic

 § "to start video, video state click" 
 § "to stop vid
 and save the current video file, click" 
 "to take a
 photo and save the current photo.

printo and save the current printo.

Recorder file download: preview interface select.

Click to enter the "cycle of video "(picture download selection capture events will be automatically downloaded) to open the need to download the video file, in the lower-left to click on the" the "to enter the download state, (High-resolution video segmentation is long, the download speed is state.

Connect a computer

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subje-

This device complies with part 15 of the FUL KWIES, Uperaum 10 to the following two conditions:

(1) this device may not cause harmful interference.

(2) this device must accept any interference received, including interference that may cause undesired operation.

Charge the battery after each use, about 3 hours to fill up (charging time depends on the adapter), and then charge the battery for another 20 minutes as much as possible after filling up to ensure the battery is full for use.

Usage scene:

Operating temperature: