



Recycle Disassemble Instruction (Dismantled Information)

**Requirements according to ANNEX VII of DIRECTIVE 2012/19/EU
on waste electrical and electronic equipment (WEEE)**

Materials and components with hazardous content

LCDs may contain hazardous substances like Pb and BFRs which are covered by exemptions under the RoHS directive. However, the majority is present in the printed circuit boards assembly. In order to reduce emissions as much as possible, a complete disposal of the old appliance is required. This treatment may only be performed in authorized handling plants.








Product Name: LCD Monitor

Model No.: EX240N





Disassembly Tools

Tool	picture
Philips Screwdriver for M3 Screw	 A red-handled Philips screwdriver with a silver metal shaft and a black tip, lying horizontally on a light brown wooden surface.
Nosed Pliers	 A pair of red-handled nose pliers with long, thin jaws, lying horizontally on a light brown wooden surface.
Diagonal Cutting Pliers	 A pair of red-handled diagonal cutting pliers with short, thick jaws, lying horizontally on a light brown wooden surface.
Slotted screwdriver	 A green-handled slotted screwdriver with a silver metal shaft and a black tip, lying horizontally on a light brown wooden surface.
Six Point Sockets	 A yellow-handled six-point socket with a silver metal shaft and a black tip, lying horizontally on a light brown wooden surface.
Philips Screwdriver for M2.5 Screw	 A red-handled Philips screwdriver with a silver metal shaft and a black tip, lying horizontally on a light brown wooden surface.
Knife	 A silver metal folding knife with a black handle, lying horizontally on a light brown wooden surface.



Disassembly process





**Disassemble
Vesa CVR**






Unscrew



**Disassemble
RC**



**Disassemble
SPK Wire
connector**

	<p>Disassemble Internal Remove All Tapes</p>
	<p>Disassemble HD/PCB.</p>
	<p>Remove Panel</p>



**Disassemble
ASSY Deco**



**Disassemble
ASSY MF**



**Disassemble
ASSY RC**

	<p>Disassemble all PCB.</p>
	<p>Disassemble Column</p>
	<p>Disassemble BASE</p>

Disassembly Time

Total time: 30 minutes