




**30" GAS FREESTANDING RANGE
(Electronic Ignition)**

MODELS:

WFG320M0MW0 (White)

WFG320M0MB0 (Black)

COOKTOP PARTS




COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W11508830	Instructions, Installation
	W11508816	Owners Manual
	W11508879	Sheet, Tech
2		Cooktop
	W11443181	White
	W11443182	Black
3		Panel, Manifold
	W11578508	White
	W11578514	Black
4		Knob, Burner
	W11488103	White
	W11488096	Black
5	98007225	Screw
6		Set, Grate
	W11465357	Black
7	98004722	Clip, Cooktop
8	6610473	Wire, Ground
9	98013389	Bumper, Cooktop

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	98005000	Screw
11		Cap, Burner
	W11448875	Black (Left Front & Right Front)
	W11448464	Black (Left Rear)
	W11453728	Black (Right Rear)
12	8534079	Screw, Ground
13	W11352018	Spreader, Flame (Left Front & Right Front)
	W11352020	Spreader, Flame (Left Rear)
	W11352021	Spreader, Flame (Right Rear)
14	W10613666	Bracket, Anti-Tip
15	7101P485-60	Screw, Anti-Tip Kit

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10465081	Grate, Bumper
17	8273062	Screw
18	3400701	Screw
19	98005658	Screw (Stainless)
	98006726	Screw (Black)
		FOLLOWING PARTS NOT ILLUSTRATED
	W11465032	Harness, Main
	3391018	Tie, Cable
	98005896	Clip, Wire
	98015022	Bushing, Snap
	W11492747	Insulation, Manifold


BACKGUARD PARTS



BACKGUARD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Endcap (Left Hand)	3	8534079	Screw, Ground	6	W10535746	Bracket, Console Mount
	W10873441	White	4		Panel, Control	7	98008544	Screw (White)
	W10873109	Black		W11495707	White	8	W11462420	Bracket, Control
		Endcap (Right Hand)		W11488013	Black	9	W10535815	Bracket, Rear
	W10873438	White	5		Control, Electronic	10	98006632	Screw
	W10873107	Black		W11520705	White			
2	W10535808	Backguard, Rear		W11520704	Black			


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	98007410	Bracket, Regulator	14	W10512963	Tubing (Regulator to Oven Valve)	23	W10876260	Electrode (Right Rear and Left Rear)
2	W11459683	Assembly, Tubing (Left Front)	15	W11509768	Valve, Saddle (Left Front & Right Front)		W10669525	Electrode (Left Front, Right Front)
	W11459686	Assembly, Tubing (Right Front)		W11509767	Valve, Saddle (Left Rear)	24	W10827923	Electrode (Left Front, Right Front, Left Rear, Right Rear)
3	98013634	Screw		W11509766	Valve, Saddle (Right Rear)			FOLLOWING PARTS NOT ILLUSTRATED
4	W11459685	Assembly, Tubing (Left Rear)	16	98017517	Screw		W11557997	Kit, LP Conversion
	W11459684	Assembly, Tubing (Right Rear)	17	W11509597	Assembly, Manifold			
5	W11281166	Java Tech Spark Module 4 POS	18	98005659	Screw			
6	98007225	Screw	19	W11466755	Regulator			
7	W10619922	Tube 3/8" Manifold To Reg	20	W11485872	Orifice (15K) (Left Front & Right Front)			
8	W10670196	Spread, Flame (Bake)		W11548158	Orifice, Natural (9.5K) (Left Rear)			
9	98006726	Screw (Black)		W11485871	Orifice (5K) (Right Rear)			
10	W10650358	Oven Burner Asm-US Electronic	21	W11208965	Igniter, Hot Surface			
11	W10493726	Screw	22	W10574737	Bracket, Valve			
12	W11542585	Harness, Switch						
13	W11449991	Valve, Oven						


CHASSIS PARTS



CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10675411	Box, Flue	10	W10058460	Foot, Leveling (Rear)	24	W10562043	Base, Foot
2	W10554269	Socket - Oven Light	11	W10620410	Assembly, Oven Bottom	25	W11510655	Clip, Tubing
3	W10636342	Shield, Insulation	12	W10532560	Support, Side Panel	26	W11492823	Cover
4		Panel, Side	13	W10670197	Deflector, Oven	27	W10788320	Bulb, Light
	W10666176	White (Left)	14	W10520269	Rail, Base	28	98008545	Screw (Black)
	W10666212	Black (Left)	15	W10545322	Bracket, Manifold	29	W10550642	Rack, Oven
	W10666141	White (Right)	16	W11172758	Bracket, Foot	30	W10327222	Counter Support-Hinge
	W10666211	Black (Right)	17	W10549293	Safety Valve, Rear Cover			FOLLOWING PARTS NOT ILLUSTRATED
5	98005502	Clip, Oven Botton	18	W10640762	Cord, Power		98004294	Wire Tie, Insulation
6	W10902689	Counterweight (Black and White Models)	19	W10181986	Sensor, Oven		W11048974	Insulation, Back
7	98015363	Support, Rear	20	98007193	Spacer		W10613818	Insulation, Upper
8		Frame, Front (Not Serviced)	21	W10535778	Seal, Oven		W11130754	Wrapper oven cavity insulation
9	W10519868	Foot, Leveling (Front)	22	W10493726	Screw		W11506534	Insulation,Flue
			23		Liner, Oven (Not Serviced)			

BROILER PARTS




BROILER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W11620318	Baffle, Base
2	W10119413	Screw
3	98004993	Screw
4	W10155121	Screw
5	W10624273	Cover, Broiler Left
	W10624275	Cover, Broiler Right
6	W10647966	Hinge
7	W10605426	Panel, Side

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	98006726	Screw (Black)
9	W10446851	Liner, Broiler Drawer
10	W10682676	Back Cover, Broiler
11	W10216478	Insulation, Broiler Door
12		Panel, Broiler Door
	W10874828	White
	W10874825	Black

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13		Handle, Broiler Door
	W10498563	White
	W10535809	Black
14	98004052	Bumper, Door

DOOR PARTS



DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	98006726	Screw (Black)
2	W10292266	Seal, Inner Door
3	W10544145	Upper Trim, Oven Door
4		Trim, Side
	W11184558	Left
	W11184560	Right
5	W10884775	Badge
6	W10535788	Hinge, Oven Door (White and Black Models)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7		Glass, Outer Door
	W11541421	White
	W11497630	Black
8	W10675413	Cross Support
9	W11528109	Glass, Inner
10		Handle, Oven Door
	W11533142	White
	W11533141	Black
11	98008699	Screw
12	W10493726	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13		Bracket, Glass Door Hold
	W10823829	White
	W10811550	Black
14	W11569276	Handle, Support Bracket

OPTIONAL PARTS (NOT INCLUDED)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	511873	White Porcelain (2 oz.)

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black

MISCELLANEOUS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	98012220	Kit, Door Pin