Valore Multi-Device Wireless Keyboard (AC147)



Thank you for purchasing the Valore Multi-Device Wireless Keyboard (AC147).

- Built-in rechargeable battery
- Connects up to 3 devices simultaneously (Wireless & 2.4G connectivity)
- Built-in multimedia hotkeys
- USB-C charging

Important: Please read the user manual thoroughly before using your Wireless Keyboard.

Specifications:

- Transmission: Up to 10m
- Battery type: 400mAh built-in polymer battery
- Key force: 50±10gf
- Key lifespan: 8,000,000 cycle
- Operating system:
 - Windows 8 and above
 - mac OS X 10 and above
 - Android 4.3 and above
- Material: ABS
- Dimensions (L x W x D): 376 x 145 x 24mm (keyboard)


:204 x 13 x 13.6mm (phone/tablet holder)

• Weight: 549g

Package Contents:

- Multi-device wireless keyboard x 1
- USB receiver x 1
- USB-A to USB-C cable x 1

UNDERSTANDING THE PRODUCT



START USING WIRELESS KEYBOARD

1. How to connect

Plug USB-C cable to keyboard to charge.

a) 2.4HG

Plug the USB dongle into PC USB port. Press button to switch to 2.4G channel.

- b) Bluetooth
- 1) Long press "BT1/BT2" for 5 seconds till indicator light flash.
- 2) Open the Bluetooth 'Settings' menu on a tablet, laptop, smartphone or other Bluetooth device, then search Bluetooth keyboard.
- 3) Find the Bluetooth keyboard name" Valore AC147 "and select it to connect.

2) 2.4G and Bluetooth mode conversion

Long press the 2.4GHz, BT1 or BT2 to switch between connections.

3) Controls

- 1.1: 2.4 GHz channel signals
- 1.2: 1 : Bluetooth channel 1 signals
- 1.3: Bluetooth channel 2 signals
- 1.4: ★ : Low resistance signals
- 1.5: 10: 2.4GHz channel indicator light
- 1.6: BT1: Bluetooth channel 1 indicator light
- 1.7: BT2: Bluetooth channel 2 indicator light
- 1.8: ON/OFFswitch

4) Multimedia Hotkey

∜×:Mute

√): Volume Down

◁ᢧ :Volume Up

⊲ :Previous Track

DII :Play/Pause

⊳ :Next Track

: Select All

🖟 : Copy

国: Paste

ॐ : Cut

Q :Search

:Switch the multimedia and the F1toF12 Key function

TECHNICAL SUPPORT & WARRANTY

- For Technical Support, email us at v.info@valore.sg.
- For Warranty Registration, visit www.valore.sg.

Cautions:

Read all the instructions and warnings carefully prior to using this product.

- Do not store the product in a high temperature environment.
- Do not place the product near a fire or other excessively hot environments.
- Do not expose the product to moisture or submerge it in liquid. Keep product dry at all times.
- Do not attempt to charge the product using any other method or connection other than the product's provided charging cable.
- Do not disassemble this product or attempt to repair or modify it in any manner.
- Battery usage by children should be supervised
- Be cautious of excessive drops, bumps, abrasions or other impacts to this product. If there is any damage to the product such as dents, punctures, tears, deformities or corrosion, stop using the product and contact us immediately via email at v.info@valore.sg, or return this product to the store where you have purchased it from.
- If the product produces an abnormal smell, high temperature (low temperature during) normal use), discolours or changes shape abnormally, stop using the product and contact us immediately via email at v.info@valore.sg.

DISCLAIMER & TRADEMARKS

All information, trademarks, logos, graphics, and images ("Materials") provided on this user manual are copyrighted or trademarked and are the property of Valore Lifestyle Pte Ltd. Any unauthorized use of any material contained on the instruction manual may violate copyright laws, trademark laws, laws of privacy and communications statutes. The trademarks, service marks and logos used and displayed in the Materials are registered and unregistered

trademarks and service marks of Valore and others. All other registered and unregistered company names, product names and marks mentioned herein the ("Materials") are the property of their respective owners and may be trademarks or registered trademarks.

Complies with **IMDA Standards** DA103331



