

## **Key and socket definition** •Build-in rechargeable lithium battery capacity: 1000mAh •Connection charger specification : DC 5.0V 1000mA •Headset continuous working time : about 50 hours ( Turn off LOGO ①Volume + / next key -②Volume - / previous key @Bluetooth indicator window 3Multifunction key MFB = •support stereo music playback, play / pause, volume size / music ⑤Mic key / sound effect mode selection up and down, microphone off / on and other functions switch key - ®Type C charging interface •support telephone: answer, end, reject, redial the last number and Tine in 3.5mm audio input interface

**Headset and Accessories** •The Bluetooth headset and the Bluetooth transmitter have been paired at the factory settings. Plug the Bluetooth adapter into the USB port of the 2. Type c charging

3.User Manual 4.Dongle 5.3.5mm Audio cable

6.Dongle Extension cable

**Using Statement** 

1.Do not use headphones during charging.

3.Do not use headset while driving a motor vehicle.

12. Headset restores the factory setting Under the shutdown state, long press ① and ③ button for 10 seconds to sound the prompt "beep" when the factory setting is completed. The blue

light and red light of the headset double flash 3 times at the same time.(Note: Headphone recovery from factory settings removes all previous pairing information)

computer(or use the dongle extension cable on the USB interface)/mobile

phone, and the headset will automatically connect after it is turned on.

Connect the 3.5mm audio cable to the headset; In this mode, only the microphone on the audio cable can be used, and the microphone on the headset cannot be used.

11.Bluetooth transmitter instructions

•When the headset connected the mobile phone, short press ③ twice in succession, the device will automatically redial the last phone number dialed

**Product Specification** 

•Wireless connection range : about 10m

•Normal charging time : about 3 hours

light, 60% volume play music )

**Product function** 

other common functions

on the light.

8.Last number redial

support operation voice prompt

support earphone low battery prompt

support AAC and SBC audio decoding

•support hfp1.7, hsp1.2, a2dp1.3, avrcp1.6

•support low delay game function (dongle connection)

• Switch between bee play mode and music mode: long press the ⑤ key

6. Light button: briefly press the button ④ by once to turn off or turn

prompts" In coming call", and the blue light of headset flashes.Press ③ once to answer the call,the blue light of headset ⑥ will be on when

answering the call, press ③ again to hang up the call, press and hold for 1

•When the connected mobile phone has an incoming call, the voice

for 2 seconds to switch modes, and there is a voice prompt of bee play

•Operating frequency range : 2402-2480MHZ

•Transmit power : CLASS2

•This headset has a low-power voice prompt function. When the battery enters a low-power state, there will be a voice prompt "low power" every 4 minutes, and the red indicator light of the headset flashes twice every 3

10.Charging instructions •The headset has a lithium battery, and it is recommended for you to charge the battery before first using the headset. •When the battery power of the headset is too low during use, there will be a "Low Power" prompt sound, please charge it in time.

•Insert the charging plug into the ® Type C port and the headset will automatically shut down. At this time, the charging red indicator light will be on. When it is fully charged, the red indicator light will turn off and the green indicator light will stay on.

Reminder 1. Please read the operating instructions carefully and keep them properly

before using this product; 2. Please charge the product for the first time; 3. In order to maintain the normal service life of the battery, please ensure that the product is used at least once in two weeks, and please supplement

4. Chargers produced by regular manufacturers and certified by CCC must 5. If the mobile phone cannot receive the Bluetooth headset, please confirm whether the Bluetooth headset is in the "pairing mode". If the headset has not been paired or connected for a long time, please restart the headset or restore the factory settings before using.

①Volume + / next key: short press once to increase the volume by one level, long press to switch to the next song; When the volume reaches the maximum, there will be a "Max volume" prompt tone. level, long press the previous key; When the volume is reduced to the minimum, there will be a "Min volume" prompt tone ③Multifunction key MFB: (1) Power on: press and hold for about 2 seconds, and the voice prompts

(2) Power off: in the power on state, press and hold for about 3 seconds to power off, and the voice prompts "power off (3) Pairing: in the off state, press and hold for about 6 seconds to enter the pairing state, and the voice prompts "pairing" (4) Play / pause: when playing music, press once to play or pause music. (5) Answer / end an incoming call: when there is an incoming call, short press once to answer the call, and long press for 1 second to reject the call; During a call, short press once to end the current call.

(4) Light switch button: turn off / on the logo light effect.

(1) Press once to turn off the microphone, and the voice prompts "mic off"; Press again to turn on the microphone, and the voice prompts "mic ( 2 ) Switching between game mode and music mode: long press for 2 seconds to switch modes, and there is a voice prompt of "game mode" or

⑤Mic key / sound effect mode switch key :

"music mode". **®**Bluetooth indicator window (1) Startup blue light flashes slowly (2) Pairing status red and blue lights flash alternately

(3) The blue light flashes quickly when an incoming call is made, and the blue light stays on after answering the call

®Type C charging interface: the connected charger is dc5v/1000ma, and the headset will automatically shut down when plugged in for charging.

Unable to Paring	The phone has not yet enabled the Bluetooth function or has not yet opened the discoverable status.	Start Bluetooth and set to discoverable.
	When paired, the headphones are too far from the transmitter.	Please do not distance to more than 1 meter.
	The battery power is insufficient.	Charge the battery in time.
The noise is large	The battery power is insufficient.	Charge the battery in time.
Staccato	1 The headset is too far from the transmitter, beyond the receiving range.  2 There is an obstacle between the headphones from the transmitter.	Resweak properly to listen.
The receiving distance is short	Transmitter equipment compatibility issues.      There is an obstacle between the headphones	1 . Replace the transmitting equipment 2. Reset the appropriate location to listen

(4) Red light double flashing /3 s at low battery (7)Line in 3.5mm audio input interface: when a 3.5mm plug cable is inserted, the headset will automatically shut down and play the signal of the external device. (the microphone of the headset does not support wired inpu during charging, and the red light will go out and the green light will be on for a long time after being fully charged. be turned off or on by operating 4.

## **Basic Operation Instruction**

**Product Features:** 

1.Turn on&Paring •Long press the button ③ for about 2 seconds in shutdown mode, the Bluetooth headset enters the power-on state (voice prompt "Power on"). When the headset is powered on, Paired will be connected firstly; those never paired enter pairing state (voice prompt Pairing). In the pairing state, devices with Bluetooth function, such as mobile phones, can search for and connect to the headset, and exit the pairing state after the connection is

•Manually enter matching: In the shutdown state, long press the "3" button for 6 seconds, the headset will directly enter the pairing state after it

is turned on. • After the earphone enters the pairing state, the red and blue indicator light flashes alternately in the work indicator window. Turn on the Bluetooth function of the mobile phone, set it to discoverable state, and add or search

for a new device. Find "SOMIC G810" in the device list, and select pair. Then the headset connects to the mobile phone successfully, and the voice prompt "Connected" is displayed, that is, the pairing process is complete.

1.The headset has four connection modes, including normal Bluetooth mode, Bluetooth low-latency mode (USB-A and Type C connection modes) and 3.5mm wired mode, which can be used in various scenarios and

2. Headset with game mode and music mode two kinds of sound, listening to songs, games can be.

3. The headset comes with a powerful low latency engine, which can be as low as 35ms to enjoy the game experience of audio and picture

synchronization.

4.The headset is ergonomic and lightweight, which makes it easy to wear 5.The headset has a built-in 1000mah battery, which can last you a week on

6.The headset are equipped with soft and breathable large size mesh earmuffs for comfort.

7.Headset with cool lighting, release the passion of e-sports.

•Bluetooth transmitter pairing: Bluetooth transmitter is inserted into the

computer USB port, when the equipment identification is completed, the

into the state, the blue indicator light flash, when the blue tooth transmit-

ters and blue tooth headset paired and Connected successfully finished, voice prompt "Connected", The blue light on the Bluetooth transmitter will

Remark : The Bluetooth headset and the Bluetooth transmitter have been

paired at the factory settings. Plug the Bluetooth adapter into the USB port

turned on.If it can't match,pls follow previous step to re-match again for

• When the Bluetooth headset is on, long press the "③" button for about 3

seconds, and at the same time, there will be a prompt tone of "Power off",

• When the device is connected to play music, press the volume "①" button once to increase the sound level by one level. When the volume

press the "①" key to switch to the next track for the music.

volume "2" button long to switch to the previous track.

reaches the maximum, there will be a prompt sound "Max volume". Long

• When the device is connected to play music, press the volume "@" button once to reduce the sound level by 1. When the volume reaches the

• During a call, press the "⑤" button once to turn OFF the microphone, and

to open the microphone, and the voice prompt "MIC ON" will be displayed.

the voice prompt "MIC OFF" will be displayed. Press the "⑤" button again

minimum, there will be a prompt sound "Min Volume". Hold down the

of the computer, and the headset will automatically connect after it is

blue lights flash slowly, with a thimble by pairing inside the shell of the

round hole pressing button for 2 seconds, pairing blue too

headphone and USB dongle.

4 . Volume -/ Last song

and the Bluetooth headset will turn off

G810 Wireless Gaming Headset Instruction Manual Please read this manual carefully when using it and save it

FCC Statement Changes or modifications not expressly approved by the party responsible for comp could void the user's authority to operate the equipment.	
This equipment has been tested and found to comply with the limits for a Class B didevice, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not install	gital
	ed and
communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, to	
user is encouraged to try to correct the interference by one or more of the following measures:	

- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver -- Connect the equipment into an outlet on a circuit different from that to which the receiver -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired In order not to waste your valuable time, please check the following items Fault Possible reasons **Exclusion method** phenomenon The battery power Unable to boot Charge the battery in time. is insufficient.

2.When wearing headset outdoors, choose safe sports venues and roads, adjust the appropriate volume, and pay attention to traffic safety.

Unable to	enabled the Bluetooth function or has not yet opened the discoverable status.	Start Bluetooth and set to discoverable.
Paring	When paired, the headphones are too far from the transmitter.	Please do not distance to more than 1 meter.
	The battery power is insufficient.	Charge the battery in time.
The noise is large	The battery power is insufficient.	Charge the battery in time.
Staccato	1 The headset is too far from the transmitter, beyond the receiving range. 2 There is an obstacle between the headphones from the transmitter.	Resweak properly to listen.
The receiving distance is short	1 Transmitter equipment compatibility issues. 2 There is an obstacle between the headphones from the transmitter.	1 、Replace the transmitting equipment 2、Reset the appropriate location to listen