


# RESTMO<sup>®</sup>

## WATER FLOW METER



**BRASS  
INLET**

## USER MANUAL

**0-WM-2**

## WARRANTY

Restmo provide one-year worry-free warranty. For any warranty claims within one year from the original order date, please email your order ID to Restmo Support and we will respond within 24 hours.



[support@restmo-link.com](mailto:support@restmo-link.com)

## WARNINGS

**DO NOT DISASSEMBLE THE ORIGINAL KIT.**

To avoid water leakage, follow the instructions and carefully install the device.

Only use with clear cold water.

When expecting freezing temperatures, device should be removed from the hose/faucet and stored indoors to avoid potential freeze damage.

## SPECIFICATIONS

Inlet Thread .....	3/4" NH Female (pure brass)
Outlet Thread .....	3/4" NH Male
Water Flow Rate .....	0.3~12 GPM (1~45.5 L/min)
Max Water Consumption .....	99999 Gal (99999 L)
Working Pressure .....	8~145 psi (0.5~10 bar)
Waterproof Grade .....	IPX6
Measurement Tolerance .....	± 5%
Battery .....	1x CR2032 (included)

## FEATURES

- Pure brass inlet connection
- Compact design
- Simple installation & operation
- Easy-to-read LCD screen
- Switchable unit (gallon/liter)
- Low battery indication
- 4 modes of water flow measurement:
  - (a) Real-time water flow rate
  - (b) Last-time water consumption
  - (c) Daily average water consumption of 7 days  
(count from next day)
  - (d) Total water consumption

# BATTERY INSTALLATION

## Step 1:

Unlock the battery compartment by the included circle plastic sheet or a coin.



## Step 2:

Insert the included CR2032 battery.




## Step 3:

Lock the battery compartment by the included circle plastic sheet or a coin.

## Note:

- The CR2032 battery is included in the package box.
- Insert the battery with correct direction.
- Remember to lock the battery compartment.

## DEVICE INSTALLATION



## OPERATION

- Short press the button to change measure modes.
- Long press the button (3secs) at each mode to change setups or reset.
- The LCD screen goes to sleep if there is no operation or water flow within 1min.

## FLOW MODE:

Flow mode displays the real-time water flow rate.

Long press the button to switch measurement units from gallon to liter.

TOTAL AVG SINGLE



Button



GAL ↔ L

## CONSUMPTION MODE:

Consumption mode displays the last-time water consumption.

Long press the button to reset.

TOTAL AVG SINGLE



Button



Reset Consumption

## AVG MODE:

AVG mode displays the daily water consumption of the last 7 days.

(count from next day)

Long press the button to reset.

TOTAL AVG SINGLE



Button



Reset Average

## TOTAL MODE:

Total mode displays the total water consumption.

Long press the button to reset.

TOTAL AVG SINGLE



Button



Reset Total

# Garden Watering Made Easy



[support@restmo-link.com](mailto:support@restmo-link.com)