




COSTWAY

COSTWAY



USER'S MANUAL Loft Bed with Slide HW64315

THIS INSTRUCTION BOOKLET CONTAINS **INPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first. Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway












Contact Us!

Do NOT return this item.


Contact our friendly customer service department for help first.



Before You Start




Read each step carefully before starting. It is very important to ensure each step followed in correct order, otherwise assembly difficulties may occur.



Mork in a spacious area, preferably on a carpet close to where the unit will be used.

Keep the handtools close at hand. Do not use power tools to assemble your furniture. They may scratch or damage the parts.




Welcome to visit our website and purchase our quality products!

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Presonalized Recommendations
- * Premanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.



Care and Maintenance

Use a soft, clean cloth that will not scratch the surface when dusting. Use of furniture polish is not necessary.

Should you choose to use polish, test first in an inconspicuous area. Using solvents of any kind on your furniture may damage the finish. Never use water to clean your furniture as it may cause damage to the finish.

Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently. Avoid rubbing.

Check bolts/screws periodically and tighten them if necessary.

Further advice about wood furniture care


It is best to keep your furniture in a climate-controlled environment.

Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.

It is advised to keep furniture away from direct sunlight as sun may damage the finish.

Proper care and cleaning at home will extend the life of your purchase. Following these important and helpful tips will enhance your furniture as it ages.

Detail View



PART LIST













Horizontal HB & FB x 6

Leg (Left Front) x 1

Leg (Left Back) x 1

 \bigcirc











Leg (Right Front) x 1

Leg (Right Back) x 1

Side rail (Back) x 1

 \bigcirc














Long guard rail x 2

Side rail (Front) x 1


Short guard rail x 2







HARDWARE LIST



Wood dowel



(2) x 2

Ø10*30mm


Wood dowel



(Ø15)1/4"*100mm

3 x 12

Hex-Head bolts



Hex-Head bolts



(Ø12)1/4"*70mm

(5) x 4


Hex-Head bolts



(Ø12)1/4"*35mm

6 x 5

Hex-Head bolts



7 x 3

Hex-Head bolts



1/4"*15mm (9.5mm)

8 x 32


Horizontal-Hole bolts




(Ø12)1/4"*50mm

(9) x 12

Hex-Head bolts



Wood screws



142*18*2mm

11 x 2


Hooks





(1/4")4.5*58mm


(12) x 1


Allen Key
















PLEASE BE CAREFUL DO NOT DAMAGE THE HOLE POSITION WHEN YOU USE POWER TOOLS!

