

fingers[®]



Quick Start Guide

I. Important - Warnings and Safety

1. Do not place the speaker near heat sources such as fire, radiators, stoves and other apparatus that produce heat.
2. Use only accessories supplied by FINGERS.
3. Unplug the speaker once it is fully charged, when unused for long periods of time or during lightning/thunderstorms.
4. It is recommended to refer **all** servicing to qualified personnel. Servicing is required when the speaker has been damaged in any way. Any evidence of any attempt to open and/or alter the device, including any scratch, peeling, puncturing, or removal of any of the labels, will void the Limited Warranty.

II. Care and Maintenance

1. Switch off the speaker before cleaning it.
2. Use a soft cloth to clean the surface.
3. Do not use any chemicals, solvents, or cleaning solutions containing alcohol, ammonia or abrasives.
4. Do not allow any liquid to enter into any of the openings.


III. In the box

1 x FINGERS GladiatorSound-12 Speaker
1 x USB-C Charging Cable

1 x Quick Start Guide
1 x Brand Note

IV. Connections

1. Type-C port (DC 5V) for charging
2. LED Indicator
3. USB Port
4. MicroSD port



Connection	Function
Charging Port	For Charging
LED Indicator	When charging, the red light appears, and disappears when fully charged. When speaker is on, blue light blinks continuously.
MicroSD Port	Insert the MicroSD card and then play it.
USB Port	Insert a USB drive, with priority for playback after insertion

V. On-board Controls



Function	What to do
1. Next Track/Volume Up	
Next Track/Next FM Channel	Short Press
Volume Increase	Long Press
2. MFB (Multi-Function Button)	
To switch On and Off the speaker	Long Press
Play/Pause Music	Short Press
<i>Manage Calls</i>	
Receive call	Short Press
End call	Again, Short Press
Redial last called number	Double Press
3. Modes/RGB Lights Button	
Short press to navigate the modes of Bluetooth, FM, USB and MicroSD (Note: USB/MicroSD modes can only be operational when corresponding device is inserted)	Short Press
To navigate across 5 different lighting modes of the decorative horn lights and to disable the RGB Lights	Long Press
4. Previous Track/Volume Down	
Previous Track/ Previous FM Channel	Short Press
Volume Decrease	Long Press

VI. Modes

You can enjoy your music in the following ways

i. Bluetooth ii. FM Radio iii. MicroSD iv. USB

i. BT

1. When the device is switched on, it automatically goes to BT mode.
2. If any source is connected (USB, MicroSD or AUX), press "M" till BT Mode is heard.
3. Make sure that Bluetooth is enabled on your device.
4. Find the device list and select "*FINGERS GladiatorSound-12*".
A sound prompt of "Connected" is heard and it is ready to play.



Connect 2 BT devices using Multi-Point Technology

- a) Turn off the BT function of first connected device, and search *FINGERS GladiatorSound-12* in 2nd device.
- b) Repeat the above steps (3 & 4) to pair another device.
- c) Switch off the *FINGERS GladiatorSound-12* Portable speaker, once 2nd device is connected successfully.
- d) Switch on the BT function on 1st device and *FINGERS GladiatorSound-12* portable speaker.
- e) As the speaker remembers previously connected devices - When switched on, it attempts to reconnect both previously paired devices.
- f) Now the speaker is ready to use, with both the paired devices.

ii. FM Radio

- Press on the "M" Button till the voice prompt of the word "FM Mode" is heard.
- Single press "⏻" to scan the stations automatically. You can press the same button again to stop the scan.
- Once FM radio is tuned, you can short press ("+") and ("-") to select the desired FM Channel.

iii. MicroSD

- Insert the MicroSD card in the provided port.
- You can then play your favourite tracks directly from the MicroSD Card.

iv. USB

- Insert the USB device (Pen Drive) in the provided port.
- You can then play your favourite tracks directly from the USB.

VII. Product Specifications

Parameters	GladiatorSound-12
Wireless Protocol	Bluetooth v5.3
Peak Output Power	12 W
Power Rating	DC 5V / 1A Max
Power Source	DC 5V / 1A Max
Driver unit	3 Ω 12 W, Φ 66 mm
Effective Range	Wireless range up to 10 m
Battery	1800 mAh
Charging Time	Up to 2 hours
Playback Time	Up to 12 hours
Playback Options	Bluetooth® FM Radio MicroSD USB
Microphone	Built-in
Dimensions	107 x 105 x 132 mm (L x W x H)
Weight	690 g
Colours	Rich Black

fingers.co.in | Ver. 1.0.0

*Tested under ideal conditions and in BT playback mode. Playback time may vary depending on usage, playback mode and volume levels.

• Images shown may vary from actual product. • Specifications, features and appearance are subject to change without notice.
• All logos, brands, trademarks and product names are properties of their respective owners. • Product warranty is governed by warranty terms mentioned on www.fingers.co.in • This product falls under e-waste (Management & Handling) Rules, 2011.
For proper disposal method, visit our website www.fingers.co.in



fingers