Elite™ Android Quick Start Guide for Zello

Stone Mountain

For the most up-to-date app settings and configurations, check zello.com/support.



1. Before plugging your **Elite™** speaker-microphone (SM) into the Android device, set the configuration to 3 by pressing the rear button for 4 seconds. The SM will then beep twice in quick succession.




Select Push-to-talk buttons > PTT
Headset. Choose PTT Headset and
enable Handle button in the
background when possible.

Zello For Work Users: This may need to be configured in the administration portal

- 2. The SM will beep and flash a red LED a number of times equal to the current configuration.
 - If the SM indicates configuration 3, don't do anything. After 4 seconds, the SM will beep twice in quick succession indicating it is ready for use.
 - If the SM indicates some configuration other than 3, press the rear button 3 times. The SM will then beep and flash the LED 3 times as confirmation. After 4 seconds, the SM will beep twice in quick succession indicating it is ready for use.



5. Google Assistant can interfere with Zello and wired accessories, so it should be disabled. In the Settings app, select Google > All Services > Search, Assistant & Voice > Google Assistant > General, and disable the Google Assistant toggle.



3. Plug the SM into the device. Launch Zello and tap then 3 dots in the upper-right corner and select **Options**.



 Navigate to the previous menu and select **Devices**. Select **Wired** headphones and disable **Get Help** From Google.

Note: This setting may only appear after the SM has been connected for the first time.

Innovation... Quality... Passion

Designed, Assembled, Tested and Supported with Pride in the USA, at Stone Mountain we strive to provide our customers with innovative products of the highest quality, reliability and value. We welcome and appreciate your input - Feel free to contact us.



Customer Support: 540.297.6434