



# RK SERIES

UNIVERSAL EQUIPMENT RK SERIES  
ROLLING CABINET A/V RACKS

**Assembly is EASY and offers wide-ranging configurations for your A/V equipment.**

Scan QR Codes for product details, videos and website.

RK-8U




RK-12U



RK-16U



RK-22U



- **WHEELS COME ALREADY INSTALLED FOR** convenience.
- Unpack all pieces. **CAREFULLY DISCARD ALL PLASTIC BAGS AWAY FROM CHILDREN AND PETS.**
- Depending on where you live, there are two options for rack mounting screws (**5mm North America** and **6mm Europe**). The **5mm** side is marked by the **two slots** on each of the **CORNER PILLARS**.
- Assemble the four **CORNER PILLARS** to the base first. *(Use the included screwdriver)*

## PLEASE PAY ATTENTION TO THESE DETAILS FOR A STRAIGHTFORWARD INSTALLATION.

- **CORNER PILLARS** can be installed **4 WAYS**:
  1. *ALL (5mm) Holes facing out*
  2. *ALL (6mm) Holes facing out*
  3. *(6mm) Holes on the front and (5mm) Holes in the back* **OR**
  4. *(5mm) Holes on the front and (6mm) Holes in the back*
- Remove all top screws from installed **CORNER PILLARS**.
- Insert **SIDE PANELS** and tighten bottom screws in place.
- Install **TOP PLATE** and tighten all remaining screws.




AccessAbles **RK Series** Cabinets include a complimentary AccessAbles **RKBLNK1U** Universal 1U Blank Rack Panel Spacer.


## IMPORTANT NOTES:

1. **CORNER PILLARS** HAVE TWO DIFFERENT SIZED THREADED HOLES ON EACH SIDE.
2. MAKE SURE TO USE CORRESPONDING HOLE SIZE WITH CORRECT THREADED SCREW SIZE.
3. **CORNER PILLARS** CAN BE INSTALLED USING ALL 6MM SIDE, ALL 5MM SIDE OR BOTH.
4. **CORNER PILLARS** SHOULD BE INSTALLED IN UNISON.

# PARTS INVENTORY



| #        | PARTS DESCRIPTION      | PCS                                           |
|----------|------------------------|-----------------------------------------------|
| <b>1</b> | TOP PLATE              | 1                                             |
| <b>2</b> | WHEEL BASE             | 1                                             |
| <b>3</b> | 1U RACK PANEL SPACER   | 1                                             |
| <b>4</b> | CORNER PILLARS         | 4                                             |
| <b>5</b> | SIDE PANELS            | 2                                             |
| <b>6</b> | 5MM SCREW WITH WASHERS | 48 (RK22U) 28 (RK12U)<br>36 (RK16U) 20 (RK8U) |
| <b>7</b> | 6MM SCREW WITH WASHERS | 48 (RK22U) 28 (RK12U)<br>36 (RK16U) 20 (RK8U) |
| <b>8</b> | PHILLIPS SCREWDRIVER   | 1                                             |



ANY QUESTIONS? VISIT US AT [AXCESSABLES.COM](http://AXCESSABLES.COM)