

90mm

100mm

ORIGBELIE

User Manual

External CD DVD Drive

V2.1

Thank you for purchasing the ORIGBELIE BT669 External CD DVD Drive. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model.

Package Contents

External CD DVD Drive \*1 Drawstring Bag \*1  
USB A to USB C Charging Cable \*1 User Manual \*1

Product Diagram

TF Card Slot  
SD Card Slot  
USB A Port 4  
USB A Port 3  
USB A Port 2  
USB A Port 1  
USB C Port  
(Charging port, not data port)  
Indicator Light  
USB A Data Cable  
Pop up Button  
Forced Ejection  
USB C Data Cable

Feature

Ultra-Thin Design  
This ultra thin external drive is the perfect companion for your laptop. You can use it to read CDs.

Plug & Play  
No need to download additional drivers.  
NOTE: Windows 11 requires a media player (for example: VLC media player) and a network.

USB 3.0 CD Drive  
The USB 3.0 technology offers a maximum data transfer rate of 5Gbps, Music transfer only takes a few seconds.

Extra USB C Connector  
Comes with an additional USB C connector, compatible with the latest laptops that no built in USB A interface.

Extra 4 USB Port & SD/TF Card Slot  
The drive has 4 USB port and SD/TF card slot, so it can be used as a laptop hub.

Burner & Reader  
Support burn and read discs (blu-ray disc is not supported).

Specifications

Brand	ORIGBELIE
Model	BT669
Power Supply	DC 5V/2A
Weight	355g/ 0.78lb
Length of Cable	27cm/10.6inch
Size	143*153*19mm/5.6*6.0*0.7in

Widely Compatible  
Laptop/Desktop Computer  
CD: CD-ROM, CD±R/RW  
DVD: DVD ROM, DVD RAM, DVD±R/RW  
Windows XP/7/8/10/11, Mac OS, Linux, Vista 7 /8  
NOTE: Windows 11 requires a media player (for example: VLC media player) and a network.

Not Compatible  
Blu-ray Disks/Chromebbooks/Ubuntu system/ Surface/Cell phone/TV/ Cars/ Projectors/ Tablets/ ipads/PS4

How to Use

Step 1: Connect an external drive to your laptop via the USB A/ USB C data cable.

Step 2: Set the area identification mechanism of the external drive is consistent with the area code attached to the disk (The region code attached to the DVD disc is marked on the disc. Discs without codes can be played on any player in any country).

Step 3: Press the eject button on the external drive.

Step 4: Place the disc in the tray label-side up, and close the tray by pushing it.

Note

1. Please connect the computer through the USB A/ USB C data cable built in the external drive. (extension cable is not recommended).

2. When the CD is being read or burned, please cancel the "sleep mode" of the computer, otherwise the data on the CD will be lost or damaged.

3. The front USB port of the desktop computer host may be unavailable, it is recommended to use the back USB port.

4. The USB A to USB C charging cable comes with the package is only for current transmission, not for data transmission.

5. The USB C port of the external drive is a charging port, not a data port.

Attention

1. Please use the 5V/2Acharger/ power bank to increase the power if your computer don't have enough power to support the external drive. (The computer can recognize the external CD/DVD drive, but cannot read the CD/DVD; the external CD/DVD drive can read the CD/DVD, but can not burn, etc., may be caused by the lack of power supply, at this moment, please access 5V/2Aexternal power to try it again, if still not, please contact our ORIGBELIE customer service in time.)

2. Make sure your computer has a driver before using the external drive. (VLC media player or other player software.)

3. The SD card slot and TF card slot cannot be used at the same time.

4. The portable CD/DVD burner cannot play blu-ray disc or game disc that over 8.5 GB.

5. The ORIGBELIE DVD drive only allows 4 changes of region code. Once the limit is reached, it cannot be changed.

Tips: About DVD Region Code

1. A disc purchased in one country may not be playable on a player purchased in another country. The region code attached to the DVD disc is marked on the disc(Discs without codes can be played on any player in any country).

2. So you need to set the region code of the extended CD drive to be consistent with the CD to play the CD.

Warranty & Customer Support

Customer Support  
For questions, support, or warranty claims, contact us at the address below with product model number.  
ORIGBELIE@outlook.com

Warranty Card  
Thank you for purchasing ORIGBELIE products.  
Through rigorous quality testing, all our products are 100% guarantee satisfaction provided.

Guarantee:

1. Customers buy ORIGBELIE products will get superior after-sale service.

2. You can return back for replacement within 30 days if there is any quality issues without man-made destroy or maintain, keep the packaging integrity.

3. Enjoy one year of free maintenance.

4. Guarantee excluding:  
① Man-made destroy, working in an informal working environment.  
② User unpack, refit and repair privately without authorized service.  
③ Damaged due to force majeure.  
④ Without the guarantee card or effective invoice of purchase.  
⑤ Exceeds the warranty period.

Shenzhen Top-Teck Technology Co., Ltd  
Email: ORIGBELIE@outlook.com  
Address: B2003, Building 1, Fenghui Garden, No.9 Nanhuan Road, Shijia Community, Matian Street, Guangming District, Shenzhen, Guangdong, 518000, China

Model: BT669

ORIGBELIE

説明書

外付け DVD/CDドライブ

V2.1

ORIGBELIE BT669 外付け CD/DVDドライブをお買い上げいただき、誠にありがとうございます。この取扱説明書をよくお読みになり、今後の参考のために大切に保管してください。サポートが必要な場合は、サポートチームにお問い合わせください。

製品のリースト

外付け CD/DVDドライブ \*1 巾着袋 \*1  
USB A - USB C充電ケーブル \*1 取扱説明書 \*1

製品図

TF カードスロット  
SD カードスロット  
USB Aポート 4  
USB Aポート 3  
USB Aポート 2  
USB Aポート 1  
USB C ポート  
(データポートではなく、充電ポート)  
インジケータライト  
USB A データケーブル  
ポップアップボタン  
強制イジェクト  
USB C データケーブル

製品の特徴

スリム設計  
この超薄型の外付けドライブは、ラップトップに最適です。CDの読み取りに使用できます。

プラグ&プレイ  
追加のドライバーをダウンロードする必要はありません。  
注: Windows 11 システムには、メディア プレーヤー (例えば、VLC メディア プレーヤーなど) とインターネットが必要です。

USB 3.0 CDドライブ  
USB 3.0 テクノロジーは、最大 5Gbps のデータ転送速度を実現します。音楽転送は数秒で完了します。

追加の USB C コネクタ  
追加の USB C コネクタが付属しており、USB A ポートが内蔵されていない最新のラップトップと互換性があります。

追加の4つの USB ポートと SD/TF カード スロット  
ドライブには 4 つの USB ポートと SD/TF カード スロットがあり、ラップトップ ハブとして使用できます。

書き込み&読み取る  
ディスクの書き込みと読み取りをサポートします (Blu-ray ディスクはサポートされていません)。

仕様

ブランド	ORIGBELIE
型番	BT669
電源	DC 5V/2A
重量	355グラム / 0.78ポンド
ケーブルの長さ	27cm / 10.6インチ
寸法	143*153*19mm/5.6*6.0*0.7インチ

幅広い互換性  
ノートパソコン/デスクトップパソコン  
CD: CD-ROM, CD±R/RW  
DVD: DVD ROM, DVD RAM, DVD±R/RW  
Windows XP/7/8/10/11, Mac OS, Linux, Vista 7 /8  
注: Windows 11 システムには、メディア プレーヤー (例えば、VLC メディア プレーヤーなど) とインターネットが必要です。

非対応  
Blu-ray ディスク、Chromebbook、Ubuntu システム、Surface、電話、テレビ、車、プロジェクター、タブレット、iPad、PS4

使用時のご注意

ステップ 1: USB A/USB C ケーブルを介して外付けドライブをコンピュータに接続します。

ステップ 2: 外付けドライブの地域識別メカニズムを、ディスクに添付された地域コードと一致するように設定します (ディスクには、DVD ディスクに付属の地域コードが記載されており、地域コードのないディスクは、どの国のどのプレーヤーでも再生できます)。

ステップ 3: 外付けドライブのイジェクト ボタンを押します。

ステップ 4: ディスクをレーベル面を上にしてトレイに置き、トレイを押して閉じます。

使用時のご注意

1. 外付けドライブに付属のUSB A/USB C データケーブルを使用してコンピュータに接続してください (延長ケーブルは使用しないでください)。

2. ディスクの読み取りまたは書き込みを行うときは、コンピュータの「スリープ モード」を解除してください。そうしないと、ディスク上のデータが失われたり、破損したりします。

3. デスクトップパソコン ホストの前面 USBポートが使用できない場合がありますが、背面 USBポートを使用することをお勧めします。

4. パッケージに付属のUSB A - USB C充電ケーブルは、データ転送ではなく、電流転送にのみ使用されます。

5. 外付けドライブのUSB C ポートは充電ポートであり、データ ポートではありません。

使用時のご注意

1. 外付けドライブをサポートするのに十分な電力がコンピュータにない場合は、5V/2A の充電器/モバイルバッテリーを使用して製品に電力を供給してください。(コンピュータが外付けドライブを認識できるが、ディスクを読み取れない、またはディスクを読み取れるが記録できないなどの場合は、電源不足が原因である可能性があります。この際、5V/2Aの外部電源に接続してお試しください。それでも問題が解決しない場合は、ORIGBELIE カスタマー サービスまでご連絡ください。)

2. 外付けドライブを使用する前に、コンピュータにドライバーがあることを確認してください。(VLC メディア プレーヤーまたは他のプレーヤー ソフトウェア)

3. SD カードスロットと TF カードスロットを同時に使用することはできません。

4. ポータブル CD/DVDドライブは、8.5 GBを超えるBlu-rayディスクまたはゲーム ディスクを再生できません。

5. ORIGBELIE DVDドライブでは、4 つのリージョン コードしか変更できません。上限に達すると変更できません。

ヒント: DVD 地域コードについて

1. ある国で購入したディスクは、別の国で購入したプレーヤーでは再生できない場合があります。DVD ディスクに添付されている地域コードは、ディスクにマークされています (コードのないディスクは、どの国のどのプレーヤーでも再生できます)。

2. CD を再生するには、外付けドライブの地域コードが CD と一致している必要があります。

製品保証とカスタマーサポート

カスタマーサポート  
ご質問、サポートまたは保証請求については、製品の型番を添えて、以下のアドレスまでご連絡ください。  
ORIGBELIE@outlook.com

保証書  
ORIGBELIE 製品をお買い上げいただき、誠にありがとうございます。厳格な品質テストを通じて、当社のすべての製品は 100% 満足を提供することが保証されています。

保証:

1. ORIGBELIE製品を購入したお客様は、高品質のアフターサービスを受けられます。

2. 品質に問題がある場合は、30日以内であれば返品・交換が可能です。破壊行為はなく、パッケージをそのままにしておいてください。

3. 1年間の無料メンテナンスをお楽しみください。

4. 保証には以下が含まれません  
① 破壊行為またはインフォーマルな作業環境での作業。  
② 利用者が無断で開梱、改造、修理した場合。  
③ 不可抗力による損害。  
④ 保証書または有効な購入請求書がない。  
⑤ 保証期間を過ぎた場合。

シンセン拓普泰科技有限公司  
メールアドレス:ORIGBELIE@outlook.com  
住所: B2003, Building 1, Fenghui Garden, No.9 Nanhuan Road, Shijia Community, Matian Street, Guangming District, Shenzhen, Guangdong, 518000, China

Model: BT669