


P F A Y



Please check this user manual carefully before use,
and keep it for further reference

PRODUCT OVERVIEW



USING INSTRUCTION

Skin may be slightly irritated during the first few times shaving which is normal. We suggested to use the razor regularly to allow the skin to adapt as quickly as possible (at least 3 times a week).

1. Press the switch button to turn on. Press again to turn off the shaver.
2. Let the blades slide on the skin against the growth direction of the beard and make a straight roundabout moving.
3. Shaving on dry face will get better using experience, so it's better to shave before washing face or a period after.

Precautions: The blades maybe destroyed if abuse the shaver, please check if the ring net before use. If there was any defects, please do not use it in case of injure your skin.

01/Travel lock

This electric razor is equipped with a travel locker to prevent accidental activation.

1. Lock the travel locker: when the shaver is off, longly press the ON/OFF button, working indicating flashes 2 times, it means the shaver is locked.
2. Unlock the travel lock: longly press the ON/OFF button, working indicating light turns to be stable, the shaver is unlocked and turn on directly.

02/CHARGING & DISPLAY

While charging the shaver, below are the precautions:

1. Before charging, make sure the shaver is off.
2. When the remaining battery capacity is inadequate, recharge the shaver on time.
3. Connect one end of the USB charging cable to the adapter, and the other end to the Type-c port of razor. Then plug the adapter into a socket.
4. Charge the shaver before the first use. A full charge takes 1 hour.
5. Take off the product from socket after fully charge. Do not keep the shaver connecting with power after fully charge.
6. Do not keep the shaver in package while charging.

Charging

When the shaver connects with power, red indicating light flashes, the shaver is charging. After fully charge, white working indicating light keeps stable, charging stops.

Working

While the shaver is working, white working indicating light keeps stable, shaver is able to work. When the remaining power capacity is inadequate, the red charging indicating light flashes, use the USB cable to get a charge.

Note: When the power cannot be started due to insufficient power, it can be directly connected to the USB power supply for use. If it is not used for a long time, please fully charge it at least once every six months. It can be used for about 60 minutes at full power.

03/Cleaning and Maintenance


To maintain the best performance of the shaver, we suggest to clean it after each shaving.



1. Turn off the shaver



2. The shaver head is a buckle down cover, pull the cover with a fingernail.



3. Clean the head cover and shaver main body with water
(Warm water is better)

Safety Instruction

Warning:

1. Before washing the razor in water, please separate the shaver from charging cable.
 2. While charging and discharging, please do not pull the USB cable directly.
Do not disassemble the machine to change battery by yourself.
 3. Do not charge the device for a long time.
 4. This product contains a built-in rechargeable battery, please do not throw it into fire.
Please do not charge, use or store it in high temperature environment.
 5. Do not modify or repair this product by yourself.
-

Precautions

- 1.If the charging cable is broken, do not use it to charge.
- 2.Keep the shaver dry while charging.
- 3.Use a 5V DC power socket to charge this product.
- 4.If the power cord is damaged, please replace it with appropriate cable from manufacturer or professional repair shop.
- 5.Please use and store the product at a temperature between 5°C and 35°C.
- 6.Store the product in place that far away from children.
- 7.This electric shave works for facial, do not use in other area.
8. Persons (including children) who are physically unsound, mentally impaired, and lack of relevant experience and knowledge should use it under the supervision and guidance of their guardian.
9. This product has passed the IPX7 waterproof test and can be washed with water or under the tap, but not available to soak in water for a long time.