


类型：折页

尺寸：80x80mm






IBS-TH2 PLUS

Temperature & Humidity Smart Sensor

INKBIRD
Temperature
Humidity
SENSOR
IBS-TH2 PLUS

Appearance



°C/°F/Bluetooth Button
Press the °C/°F/Bluetooth Button to turn on/off Bluetooth.
Hold the °C/°F/Bluetooth Button to switch between °C and °F.



External Temperature Probe with Cable (Standard)

Note: When the external temperature probe is inserted, the device will save the external temperature data and internal humidity data, and the temperature displayed on the screen is the external temperature.



External Temperature & Humidity Probe with Cable (Optional)

When an external temperature & humidity probe is inserted, the device will save the external temperature & humidity data, and the external temperature and humidity will be displayed on the screen.

Technical Specifications

Battery	AAA Battery*2 (not included)
Bluetooth Connection Range	30 meters (98ft)
Built-in Temperature&Humidity Sensor	
Temperature Measurement Range	-10°C~60°C/14°F~140°F
Temperature Accuracy	Typical: $\pm 0.3^{\circ}\text{C}/\pm 0.50^{\circ}\text{F}$
	Max: $\pm 0.5^{\circ}\text{C}/\pm 0.9^{\circ}\text{F}$
Humidity Range	0%RH-99%RH
Humidity Accuracy (25°C/77°F, 20%~80%RH)	Typical: $\pm 3\%\text{RH}$
	Max: $\pm 4.5\%\text{RH}$
RH Humidity Accuracy (25°C/77°F, 0%~100%RH)	Typical: $\pm 4.5\%\text{RH}$
	Max: $\pm 7.5\%\text{RH}$
External Temperature Probe	
Temperature Measurement Range	-40°C~125°C/-40°F~257°F
Temperature Accuracy	$\pm 0.5^{\circ}\text{C}/\pm 0.9^{\circ}\text{F}$
External Temperature&Humidity Probe	
Temperature Measurement Range	-40°C~60°C/-40°F~140°F
Temperature Accuracy	Typical: $\pm 0.3^{\circ}\text{C}/\pm 0.50^{\circ}\text{F}$
	Max: $\pm 0.5^{\circ}\text{C}/\pm 0.9^{\circ}\text{F}$
Humidity Range	0%RH-99%RH

Humidity Accuracy (25°C/77°F, 20%~80%RH)	Typical: $\pm 3\%\text{RH}$
	Max: $\pm 4.5\%\text{RH}$
RH Humidity Accuracy (25°C/77°F, 0%~100%RH)	Typical: $\pm 4.5\%\text{RH}$
	Max: $\pm 7.5\%\text{RH}$
Magnetic Back	Yes
Warranty	1 Year

APP CONTROL


1. Download the app




Search “Engbird” in App Store or Google Play to download it for free, or you can scan the QR code above to install it directly.

Note: Please make sure your phone supports Bluetooth.


2. Open the app, turn on Bluetooth.




3. Put the device close to your phone and click “Add Sensor” or “+” to add devices.



4. Choose a usage scenario and click “Done” to complete the connection.



5. The main interface of the app.



Note: A mobile phone can be connected to multiple sensors at the same time and a sensor can be connected to multiple phones as well.

Warning

1. Please do not disassemble the product if you are not a professional.
2. Be sure that the sensor is not covered with dust as dust may lead to inaccurate measurements.
3. Do not use alcohol to clean the sensor.



INKBIRD TECH.C.L

Support@ink-bird.com
www.ink-bird.com
+86-0755-22747857
4/F E, Bldg 713, Pengji Industrial Zone,
Liantang St, Luohu Dist., Shenzhen, China.

