

Instructions For Use - Care

- Do NOT wash or dry clean your TEMPUR® Topper
- The cover can be removed and washed in cold water, dried on a cool setting – or air dried, which is recommended
- Do NOT use chlorine products or harsh stain removers