







P2









1




R	x2	Q	x2	A	x6	C	x6
							
4.5*12mm		32*65*15		M6*35mm		Ø8*30mm	

2





E	x12	G	x6	A	x4	C	x4
							
Ø3.5*14mm		340mm		M6*35mm		Ø8*30mm	

3





4




B	x8
	
Ø15mm	

5




B	x6
	
Ø15mm	



6






7





8




K	x1	D	x6	C	x6
					
		M7*50mm		Ø8*30mm	



9




L	x2
	
M6*30mm	



10




K	x1	N	x7
			
		M6*50mm	



11




I	x16	E	x16
			
		Ø3.5*14mm	

12




F	x2	S	x2
			
M4*35mm		Ø8*30mm	

13




14




When installing No. 9, No. 11, No. 12, if the B screw cannot be tightened, please rotate the A screw on No. 9 counterclockwise 90-120 degrees, and then tighten the B screw.

15



F	x12
M4*35mm	


16




When installing No. 10, No. 11, No. 12, if the B screw cannot be tightened, please rotate the A screw on No. 10 counterclockwise 90-120 degrees, and then tighten the B screw.

J	x12	B	x12
Ø20mm		Ø15mm	


17





X3




X3

F	x12
	
M4*35mm	



18



X3



X3

E	x24	H	x12
			
Ø3.5*14mm		340mm	

