

B98 instructions

Multi-purpose Bluetooth Speaker

I. NOTE:

1. do not use this product near water and do not immerse this product in any liquid.
2. do not use this product on any heat source.
3. use, please turn the sound to the appropriate volume to avoid damage to your health and equipment.
4. use this product for the first time, please use the battery after charging.

II. Definition of keystrokes and jacks of the product (subject to the object)

- 1.[NO/OFF]: on/off
 - 2.[play / pause]: short press play / pause, in FM mode long press automatic search. When connecting Bluetooth, double-click the play key to redial the phone number that was last dialed.
 - 3.[up]: press the last song, select the last radio station, long press fast back.
 - 4.[next]: press one short, select the next radio station, press fast forward long.
 - 5.[V+]: short / long press is volume plus.
 - 6.[V-]: short / long press is volume reduction.
 - 7.[M mode]: short press mode conversion: Bluetooth mode, TF card mode, U disk mode, FM mode conversion, in FM mode by automatic search.
 - 8.[EQ]: can choose EQ sound effects when playing music.
 - 9.[LED light]: short press on-off colorful lights.
- [DC 5V] charging jack, can use the special USB power cord distributed by this machine, connect the mobile phone charger to charge. When charging, the two battery icons flicker, and the battery icon does not flicker after filling.
- [TF CARD]: insert TF card to play MP3 music.
- 12.[USB]: insert U disk to play MP3 music.
 - 13.[AUX]: insert AUX line to connect the sound source.
 - 14.[MIC : insert a microphone to shout.

Bluetooth Connection Operation

1. boot into Bluetooth mode BLUE, then open the phone Bluetooth search Bluetooth device B98 or a string of digital code to match the password, if prompted to match the password, please enter "0000" and click OK to connect
2. short press play key to answer the phone and hang up the phone
3. double-click the play button to redial the phone number that was last dialed

III. Charging instructions

Connect the charging line to the phone charger for charging DC5V 1000mA, the red light is on when charging, and the red light is extinguished after filling. The built-in protection circuit can be connected to the charger for a long time. The duration of each discharge will vary according to the sound volume when used, and the power indication will also deviate from the volume when playing.

IV. Troubleshooting

Automatic shutdown: battery power is insufficient, please charge half an hour before use.

Play automatic shutdown or restart: battery power is insufficient, please charge half an hour before use.

Speaker silent: whether the volume is turned on, please confirm the volume size.

When the sound intermittent at the same time prompt low power please charge: to connect the charger after charging back to normal.

Key no function or function disorder: turn on after shutdown to see if the key function is normal

Can not play music: MP3 the music file storage path can not be recognized by the player, please store the file in the removable device directory

V. TECHNICAL SPECIFICATION V. PACKING ANNEXES

Output power :2 X10W (RMS)1. One host

Frequency effect :100 Hz —18KHz 2. instruction manual, warranty card set

Input power: DC DC5V 1000mA 3.USB power cord a Bluetooth version :5.0 Bluetooth distance ≥ 10 meters 4. Battery

Computer Weight: g 1150

Size: x 132x 181mm 346

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.