




Original	Replacement
 Up / CH+	 Up
 Up / CH+	 CH+ / Page+
 Exit	 Exit / Cancel / Clear
 Left / Vol-	 Left
 Left / Vol-	 Vol-
 OK	 OK
 Right / Vol+	 Right
 Right / Vol+	 Vol+
 Down / CH-	 Down
 Down / CH-	 CH- / Page-
 Group	 Smart / List
 Page+	 Shift + CH+ /
 Page+	 >>I / Preset+
 Pause	 Pause / Step / Freeze
 Color	 Picture / Format
 Page-	 Shift + CH- /
 Page-	 I<< / Preset-





Original	Replacement
 UHF	 AV / Input / RDS
 Red / Recall	 Red / Netflix / Search
 Red / Recall	 Back / Return
 Green / Audio	 Green / APP / Repeat
 Green / Audio	 Audio / Lang I/II
 Yellow / Text	 Yellow / YouTube / Repeat
 Yellow / Text	 Text / Goto
 Blue	 Blue / Prime Video / Random
 RGB / YPbPr	 Setup / OPT /
 Subtitle	 Subtitle / EQ
 Wide	 Zoom / Size

Original	Replacement

