

# We're saving some paper.

View the full instruction manual online before use.

https://dhlifelabs.co.uk/help-support/

### Need Help?

0300 373 0739 9 AM-5 PM, Monday-Friday

201 Hollymoor Way, Rubery,











## Sciaire Portable

QUICK START GUIDE | CAHP-03BL09



## Your safety is important to us.

Please read the full instruction manual online and all safety instructions before you use the device.



Use only as described in the Instruction Manual. Do not carry out any maintenance other than that shown in this guide or as advised by customer support.

- ! Do not operate this device while driving.
- ! Do not place device in areas that will obstruct the driver's visibility while driving.
- ! Do not handle USB plug with wet hands.
- ! Always place device on a firm, flat level surface that is secure. Do not place device where it is likely to be bumped or knocked over.
- ! Do not sit, stand, or place heavy objects on the device.
- ! The device must be in the upright position at all times.
- ! NEVER place containers with liquid or drinks on top of the device. Spilling liquids into it can damage the device and potentially cause electric shock or create a fire hazard.
- ! This device is not recommended for use by children under the age of 8, and children and vulnerable consumers should have adequate supervision or instruction when interacting with the device.
- ! The device is intended for indoor use only.
- ! Only use the device after fully assembled.

- ! Only use this device with supplied accessories.
- ! Do not allow foreign objects to enter ventilation or exhaust opening as this may cause electric shock or damage to the device. Do not block air outlets or intakes
- ! Always follow basic precautions when using device to reduce the risk of fire, electric shock, and personal injury.
- ! Do not remove the USB power cord until the device is turned off. Exercise care when removing the power cord from the USB plug. Do not yank power cord out of the USB plug.
- ! Do not use if USB plug/power cord is damaged.
- ! Do not use if you believe the device has been damaged or is faulty. If the device is not working properly or has been dropped or damaged, contact customer support.
- ! Keep the USB power cord away from hot surfaces.
- ! To minimize the risk of a tripping hazard, do not place USB plug/power cord under carpet or cover it.
- ! Do not expose the device to moisture: avoid areas where it might come in contact with water such as bathrooms or laundry rooms.
- ! Ensure the USB outlet used is not loose or damaged. A poor electrical connection can result in electric shock, overheating of the device or damage to the device or the power cord.
- ! Prior to cleaning or other maintenance, the device must be disconnected from the supply mains.
- ! The device is not user serviceable. Do not attempt to repair the device yourself. In the event of failure, contact customer support.
- ! The device must only be supplied at safety extra low voltage of 5V DC.

Read all safety instructions in this quick start guide, the online instruction manual, and on device.



### **Product Overview**



- 1. Main Body
- 2. 3-in-1 Filter
- Bottom Cove
- 4. USB Power Cord

## **Quick Start**



### Step One

Connect power cord to device and plug into USB port.



### Step Two

Press the power symbol for one second to turn device on and press again to switch purification speed:



Low Speed



**High Speed** 



Replace Filter (see page 6 for details)



### Step Three

Press power symbol for two seconds to power off.

### Clear Air Wherever You Go

#### Car

Plugs right into the 12V outlet to freshen interior air.

#### Nursery

Keep your baby's environment clean and fresh.

#### Desk

Compact enough to fit on your desk.

#### Travel

Pack it on trips to freshen hotel room air.

#### Work

Keeps germs at bay and your work environment fresh.

#### Office

Place it in your cubicle to keep your personal space smelling fresh and clean.

## **Device Specifications**

Input Voltage	DC5V/2W
Dimensions	Bottom Diameter 2.8 inch (7 cm)
	Top Diameter 3.9 inch (10 cm)
	Height 6.8 inch (17.2 cm)
Noise	<25 dB
Net Weight	0.84 lbs (380 g)

## **Cleaning and Maintenance**

It is recommended to replace the filter every 6 months or when the power symbol has a red indication light. **NOTE:**The filter is not washable. Do not immerse it in water.





## Step One

Make sure the device is OFF and unplugged.





### Step Two

Twist open and remove the bottom cover from the device.





## Step Three

Remove the old filter and replace it with the new one





### **Step Four**

Attach the bottom cover and twist close.

To reset the red indication light, hold button for 3 Seconds.