


# Amino Remote Control Guide



- |     |                 |   |
|-----|-----------------|---|
| 1.  | DEVICE CONTROLS | TV: Powers TV on/off (if programmed)<br>STB: This button is pre-programmed to power the set top box on/off<br>AV: Changes input to TV (if programmed)   |
| 2.  | TRANSPORT KEYS  | Controls video programs<br>◀◀ REW: Rewinds programming<br>▶▶ PLAY: Plays programming / resumes a paused program<br>⏸ PAUSE: Pauses programming<br>▶▶ FF: Fast forwards video<br>◀◀ LAST CHAPTER: Goes back in programming<br>■ STOP: Stops playback of video<br>● RECORD: Starts or stops recording a program<br>▶▶ NEXT CHAPTER: Advances forward in programming |
| 3.  | SHORTCUT KEYS   | RED: Displays on-screen information about the current program<br>GREEN: Toggles closed captioning on/off<br>YELLOW: Displays on-screen program guide<br>BLUE: Goes back one level within menus  |
| 4.  | MENU            | Displays on-screen menu or home screen  |
| 5.  | INFO            | Displays on-screen information about the current program  |
| 6.  | PVR             | Button not active   |
| 7.  | NAVIGATION      | ARROW KEYS: Navigates within the on-screen guide/menus<br>OK: Executes the currently selected menu option<br>LEFT/RIGHT: Rewinds/fast forwards video  |
| 8.  | BACK            | Goes back one level within menus  |
| 9.  | EXIT            | Exits the current menu item or back to LIVE TV  |
| 10. | GUIDE           | Displays the on-screen program guide  |
| 11. | CH +/-          | Changes channel up/down and pages up/down within the on-screen program guide  |
| 12. | VOL +/-         | Increases or decreases TV volume  |
| 13. | UP ARROW        | Pages up within the on-screen program guide   |
| 14. | DOWN ARROW      | Pages down within the on-screen program guide   |
| 15. | P<P             | Displays previous channel   |
| 16. | MUTE            | Turns TV volume on/off  |
| 17. | NUMBER KEYS     | Allows direct access to specific channels and menu items  |
| 18. | TEXT            | Teletext button (press and release) or TV SHIFT function (press and hold)   |
| 19. | TITLES          | Turns subtitles on/off  |