

2002-03

**Saturn Vue
SUV**



Year: 2002

Make: Saturn

Model: Vue

IN-DASH APPLICATION:

Dash Type: DIN and Half

Dash Kit: SN1527

Harness: GMO4

FRONT SPEAKERS:

Side Mirror Cover: 1.25"

Door: 6" 3-Hole speaker in factory adapter

When installing an aftermarket 5 ¼" or 6 ½" speaker, a speaker adapter is required. We recommend the Scosche SAC656 or SAU56 speaker adapter.

REAR SPEAKERS:

Rear Door: 6" 3-hole speaker in factory adapter

When installing an aftermarket 5 ¼" or 6 ½" speaker, a speaker adapter is required. We recommend the Scosche Sac656 or SAU56 speaker adapter.

WIRE COLOR CODES:

+12V Constant	=	Orange
+12V Accessory Switched	=	Grey
-12V Chassis Ground	=	Black
+12V Illumination	=	
+12V Dimmer	=	
LF+	=	Tan
LF-	=	Grey
RF+	=	Lt Green
RF-	=	Dk Green
LR+	=	Brown
LR-	=	Yellow
RR+	=	Dk Blue
RR-	=	Lt Blue

2002 Saturn Vue Sport Utility

PRELIMINARY: Disconnect the negative battery cable.

ANTENNA: The factory antenna is located atop rear fender.

RADIO REMOVAL AND IN-DASH DISASSEMBLY:

Note: The factory radio provision is for a DIN style radio.

An installation kit is required when installing an aftermarket stereo. We recommend the Scosche SN1527.

1. Remove shifter bezel using fingers or panel removal tool and pull over shifter and out of the way.
2. Remove (4) 9/32 screws securing pocket and pull pocket out.
3. Remove radio/climate control bezel using fingers and carefully disconnect and remove.
4. Extract (2) 9/32 securing radio, disconnect and remove.



FRONT DOOR SPEAKER DISASSEMBLY:

Note: The factory speaker provision is for a 6" 3-Hole Custom Mounting, mounted to a factory speaker adapter.

1. Remove power mirror cover and extract (1) Philips head screws from behind.
2. Extract (1) Philips head screw from front lower portion of door panel.
3. Extract (1) Philips head screw from door opener cup, disconnect and remove.
4. Using panel popper, push in tab on bottom of door handle to remove top front "cover" and extract (2) Philips head screws from behind.
5. Extract (3) 9/32 screws securing speakers.



REAR DOOR SPEAKER DISASSEMBLY:

Note: The factory speaker provision is for a 6" Custom Mounting, mounted in a factory speaker adapter.

1. Extract (1) Philips head screw from front lower portion of door panel.
2. Extract (1) Philips head screw from door opener cup, disconnect and remove.
3. Using panel popper, push in tab on bottom of door handle to remove top front "cover" and extract (2) Philips heads crews from behind.
4. Pull door panel up and away to remove.

