


User Manual







在未连接状态下: 5分钟无操作自动关机 (重复拨动开关键开机)

自动连接:

单击拍照/录视频

### 连接遥控器



指示灯闪烁进入配对状态, 手机搜索"Selfie"匹配, 配对成功后,指示灯熄灭。

开机可自动连接已配对手机。

### 可拆手机夹



利用手机推动 夹子后固定

## 拆卸手机夹




### 手机支架









## 使用三脚架





## 调节自拍杆



自拍器型号 C03 材料 ABS+不锈钢 折疊长度 196mm 1075 mm 总长度 196x52x37mm 产品重量 162g CR2032(可更换) 电池 (电池不得暴露在诸如日照、火烤或类似过热环境中)

规格

### 提醒

#### ·遥控器兼容

Android 4.4以上 iOS 5.1以上

#### ·Android设备设置

如果你在相机选项下改变了你的 "音量键功能",请把它改为"默认"或者 "拍照",让遥控器正常工作。















**□•** 拍照键:



#### Use the remote control



### Remote Control

# Take out the remote control

First time connection: Turn on the remote control and the light flashes to enter the pairing state. Search "Selfie" 0 with your phone to match, after successful pairing, the indicator light will turn off.

## In the unconnected state:

No operation of the remote control for 5 mins, it will automatically shut down. (Repeatedly toggle the power key to turn on)

#### Automatic connection: Turning on the remote control automatically connects the paired phone.

## Connect Your Phone





### Detachable Phone Clip




Use the phone to push the clip to clamp the phone

### Remove the phone clip



### Phone Holder











## Use the Tripod





## Adjust the Selfie Stick





### Specification

Opcomoation	
Remote Model	C03
Main Material	ABS+Stainless Steel
Folded Length	196mm
Extended Length	1075mm
Product Size	196x52x37mm
Product Weight	162g
Battery	CR2032(Replaceable)
· · · · · · · · · · · · · · · · · · ·	

(the Battery must not be exposed to sunlight, fire or Remind

Android 4.4 or above, iOS 5.1 or above

·Remote control compatibility:

·Android devices settings:

#### · Reorient or relocate the receiving antenna. · Increase the separation between the equipment and

#### · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

 Consult the dealer or an experienced radio/TV technician for help. If you change your "volume key function" on Caution:Any changes or modifications to this device not explicitly approved by manufacturer could void the camera, be sure to change it to the "default your authority to operate this equipment.

more of the following measures:

FCC Statement

This equipment has been tested and found to comply

with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful interference in a residential installation. This equipment

generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio

communications. However, there is no guarantee that

this equipment does cause harmful interference to

interference will not occur in a particular installation.If

radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or

### value"or"Shooting".Getting the remote Thank you for your support!



control to work.



#### RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)This device may not cause harmful interference,and (2)this device must accept any interference received, including interference that may cause undesired operation.