

INSTRUCTION MANUAL



Light Kit for Angel 43257



Thank You

For Purchasing this product. To give you the perfect hidden-line effect, we use severely thin aviation-grade wire with high tension and pressure tolerance. However, due to its thin nature, be careful not to cut through it as it might be susceptible to shearing during installation. Always be careful not to press brick pieces down on the wire.




Let's Get Started

if you face any challenges, please feel free to reach out via **support@gameofbricks.eu** Please note that we offer 2 years of free light kit maintenance.

Step 1 (Bag 1)



Step 1 (Bag 1)




Step 1 (Bag 1)



Step 1 (Bag 1)



Step 1 (Bag 1)



Step 1 (Bag 1)



Step 1 (Bag 1)



Step 1 (Bag 1)



Step 1 (Bag 1)



Step 2 (Bag 2)



Step 2 (Bag 2)



Step 2 (Bag 2)



Step 2 (Bag 2)



Step 2 (Bag 2)



Step 2 (Bag 2)



Step 2 (Bag 2)



Step 3 (Bag 3)



Step 3 (Bag 3)



Step 3 (Bag 3)



Step 3 (Bag 3)



Step 3 (Bag 3)



Step 3 (Bag 3)



Step 3 (Bag 3)



Step 3 (Bag 3)



Step 3 (Bag 3)



Step 3 (Bag 3)



Step 3 (Bag 3)



Step 4 - Classic Version

The following pictures are only for Clasic Version.
Please skip to page 39 if you ordered Remote Version.

Step 4 - Classic Version



Step 4 - Classic Version



Step 4 - Classic Version



Step 5 (Bag 4)



Step 5 (Bag 4)



Step 5 (Bag 4)



Step 5 (Bag 4)



Step 6 - Sound Version

The following pictures are only for Sound Version.

Step 6 (Bag 5)



Step 6 (Bag 5)



Step 6 (Bag 5)



Step 6 (Bag 5)



Sound Activation

SOUND GUIDE

(only if sound not working or crackly)

#1 fix

If the sound is crackling (but working properly), please see **How to replace or a power bank**. It will solve your problem.



#2 fix

Speaker (if any) disconnected, wire is broken.

Q1 Check the speaker (if any) is connected properly. If the speaker is disconnected, it will not work.

Q2 Check the speaker (if any) is connected properly. If the speaker is disconnected, it will not work.

<https://www.amazon.com/dp/B000000000>

Q3 Check the speaker (if any) is connected properly. If the speaker is disconnected, it will not work.



#3 fix


Please see the sound module by using our data for step-by-step guide. Please see **How to replace or a power bank**. It will solve your problem.

<https://www.amazon.com/dp/B000000000>

#4 fix

Please check if sound (if any) is in the sound module. If the sound is not working, it will not work.

You can do it by connecting the sound module using your USB cable (if any). It will solve your problem.



<https://www.amazon.com/dp/B000000000>

The main questions are:

Q1 How do you change the power bank and the sound (if any) is not working?

Q2 How do you change the power bank and the sound (if any) is not working?

<https://www.amazon.com/dp/B000000000>

Q3 How do you change the power bank and the sound (if any) is not working?

<https://www.amazon.com/dp/B000000000>

Q4 How do you change the power bank and the sound (if any) is not working?

Remote and Sound Guide

Remote and Sound guides with clickable
Youtube links are available on our website:
<https://gameofbricks.eu/pages/instructions>



Connect light kit to the battery box and installation will be complete. If you would like to use another power source, please make sure the maximum voltage is 6V.

