



INSTEON Developer Notes
On/Off Outlet (2663-222)

Table of Contents

Revision History	v
Device Description	6
Details	6
Example Standard Length Message	7
Example Extended Length Message	8
Messages Sent From – On/Off Outlet	9
Assign to ALL-Link Group	9
<i>Command Example:</i>	<i>9</i>
<i>Docklight Example:</i>	<i>9</i>
Success Report	10
<i>Command Example:</i>	<i>10</i>
<i>Docklight Example:</i>	<i>10</i>
Messages Sent To – On/Off Outlet	11
INSTEON Engine Version	11
<i>Command Example:</i>	<i>11</i>
<i>Docklight Example:</i>	<i>11</i>
Ping	12
<i>Command Example:</i>	<i>12</i>
<i>Docklight Example:</i>	<i>12</i>
ID Request	13
<i>Command Example:</i>	<i>14</i>
<i>Docklight Example:</i>	<i>14</i>
ON (Top Outlet)	15
<i>Command Example:</i>	<i>15</i>
<i>Docklight Example:</i>	<i>15</i>
OFF (Top Outlet)	16
<i>Command Example:</i>	<i>16</i>
<i>Docklight Example:</i>	<i>16</i>
ON (Bottom Outlet)	17
<i>Command Example:</i>	<i>17</i>
<i>Docklight Example:</i>	<i>17</i>
OFF (Bottom Outlet)	18
<i>Command Example:</i>	<i>18</i>
<i>Docklight Example:</i>	<i>18</i>
Direct Group On	19
<i>Command Example:</i>	<i>19</i>
<i>Docklight Example:</i>	<i>19</i>
Direct Group Off	20
<i>Command Example:</i>	<i>20</i>
<i>Docklight Example:</i>	<i>20</i>
Status Request	21
<i>Command Example:</i>	<i>21</i>
<i>Docklight Example:</i>	<i>21</i>
Status Request 2	22

<i>Command Example:</i>	22
<i>Docklight Example:</i>	22
Read Configuration Byte	23
<i>Command Example:</i>	23
<i>Docklight Example:</i>	24
Database Delta.....	25
<i>Command Example:</i>	25
<i>Docklight Example:</i>	25
Beep	26
<i>Command Example:</i>	26
<i>Docklight Example:</i>	26
Remote Enter Linking Mode	27
<i>Command Example:</i>	28
<i>Docklight Example:</i>	28
Remote Exit Linking Mode.....	29
<i>Command Example:</i>	29
<i>Docklight Example:</i>	29
Remote Enter UnLinking Mode	30
<i>Command Example:</i>	31
<i>Docklight Example:</i>	31
Programming Lock On.....	32
<i>Command Example:</i>	32
<i>Docklight Example:</i>	32
Programming Lock Off.....	33
<i>Command Example:</i>	33
<i>Docklight Example:</i>	33
LED Blink on Traffic On	34
<i>Command Example:</i>	34
<i>Docklight Example:</i>	34
LED Blink on Traffic Off.....	35
<i>Command Example:</i>	35
<i>Docklight Example:</i>	35
Load Sense On (Bottom Outlet).....	36
<i>Command Example:</i>	36
<i>Docklight Example:</i>	36
Load Sense Off (Bottom Outlet).....	37
<i>Command Example:</i>	37
<i>Docklight Example:</i>	37
Load Sense On (Top Outlet).....	38
<i>Command Example:</i>	38
<i>Docklight Example:</i>	38
Load Sense Off (Top Outlet).....	39
<i>Command Example:</i>	39
<i>Docklight Example:</i>	39
LED Off	40
<i>Command Example:</i>	40
<i>Docklight Example:</i>	40
LED On.....	41

<i>Command Example:</i>	41
<i>Docklight Example:</i>	41
Keybeep On	42
<i>Command Example:</i>	42
<i>Docklight Example:</i>	42
Keybeep Off	43
<i>Command Example:</i>	43
<i>Docklight Example:</i>	43
RF Off	44
<i>Command Example:</i>	44
<i>Docklight Example:</i>	44
RF On	45
<i>Command Example:</i>	45
<i>Docklight Example:</i>	45
Powerline Off	46
<i>Command Example:</i>	46
<i>Docklight Example:</i>	46
Powerline On	47
<i>Command Example:</i>	47
<i>Docklight Example:</i>	47
Read Configuration Byte 2	48
<i>Command Example:</i>	48
<i>Docklight Example:</i>	49
X10 Off	50
<i>Command Example:</i>	50
<i>Docklight Example:</i>	50
X10 On	51
<i>Command Example:</i>	51
<i>Docklight Example:</i>	51
Error Blink Off	52
<i>Command Example:</i>	52
<i>Docklight Example:</i>	52
Error Blink On	53
<i>Command Example:</i>	53
<i>Docklight Example:</i>	53
Cleanup Report Off	54
<i>Command Example:</i>	54
<i>Docklight Example:</i>	54
Cleanup Report On	55
<i>Command Example:</i>	55
<i>Docklight Example:</i>	55
Smart Hops On	56
<i>Command Example:</i>	56
<i>Docklight Example:</i>	56
Smart Hops Off	57
<i>Command Example:</i>	57
<i>Docklight Example:</i>	57
Get for Group/Button	58

<i>Command Example:</i>	59
<i>Docklight Example:</i>	59
Set X10 Address	60
<i>Command Example:</i>	60
<i>Docklight Example:</i>	61
Set LED Brightness	62
<i>Command Example:</i>	62
Appendix	64
Checksum Information	64
<i>Example of Checksum:</i>	64
Memory Map	65
<i>All-Link Database (AL /L) Overview</i>	65
<i>EEPROM Structure Overview</i>	65
<i>AL /L Record Format</i>	65
<i>Overwriting an Empty AL /L Record</i>	66
<i>Creating a New AL /L Record</i>	66
Get Database	67
<i>Command Example:</i>	69
<i>Docklight Example:</i>	70
Set Database	71
<i>Command Example:</i>	72
<i>Docklight Example:</i>	72

Revision History

Release Date	Author	Description
05/06/2014	jtalmich	V0.1 for On/Off Outlet
05/07/2014	jlockyer	Minor typo fixes
05/07/2014	jtalmich	Added new command (Status Request 2)
05/23/2014	jtalmich	Removed unsupported command
06/27/2014	jtalmich	Added 2 new commands (Direct Group On & Direct Group Off)

Device Description

Details

Device Name	On/Off Outlet
Product SKU	2663-222
Product Website	
Category	0x02 – Switched Lighting Control
Subcategory	0x39
Tested Firmware Version	CA
Supports SD Messaging	YES
Supports ED Messaging	YES
I2CS enabled (CS)	YES

Example Standard Length Message

A Standard Length Message (SD) is comprised of exactly nine (9) bytes.

Byte(s)	Description	Example
1-3	Transmitting INSTEON Device ID	AA BB CC
4-6	Receiving INSTEON Device ID (Target Device)	11 22 33
7	Flag Byte (Message Type)	0F
8	Command 1	11
9	Command 2	FF

Standard Message Formatted	AA BB CC 11 22 33 0F 11 FF
-----------------------------------	----------------------------

The above example will send an ON(11) at Full(FF) command to device 11 22 33.*

*For a detailed explanation of INSTEON Messaging, please see the [INSTEON Manual](#)

Example Extended Length Message

An Extended Length Message (ED) is comprised of exactly nine (23) bytes.

Byte(s)	Description	Example
1-3	Transmitting INSTEON Device ID	AA BB CC
4-6	Receiving INSTEON Device ID (Target Device)	11 22 33
7	Flag Byte (Message Type)	1F
8	Command 1	20
9	Command 2	01
10-22	Data1 – Data13	00 00
23	Data14 (Checksum)	DF

Extended Message Formatted	AA BB CC 11 22 33 1F 20 01 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 DF
-----------------------------------	--

The above example will send a Set Operating Flags (20) of Programming Lock Off (01) command to device 11 22 33.*

*For a detailed explanation of INSTEON Messaging, please see the [INSTEON Manual](#)

Messages Sent From – On/Off Outlet

When an INSTEON device is active to trigger a group message the messages are sent in the following order *depending on flag options for some devices

Message Sent (Type)	Example
Group Broadcast Message on Activation	AA BB CC 00 00 01 CF 11 01
Direct Message for CleanUp	AA BB CC 11 22 33 40 11 01
Group Broadcast Message Success Report	AA BB CC 11 01 01 CF 06 00

All INSTEON Devices will send a group message for a particular activation. For Multi Group devices, the Group number will change depending on the group that was activated. The CleanUp messages and Success Reports will be the same with exception to the Group Number.

Assign to ALL-Link Group

This command is sent after holding down the SET Button for 3 seconds on the device.

Command Name	Assign to ALL-Link Group
Message Length	Standard Message (SD)
Message Type	Broadcast
To Address (Hi Byte)	0x02
To Address (Mid Byte)	0x39
To Address (Low Byte)	Firmware Revision
Command 1	0x01
Command 2	Hardware Revision

Command Example:

Assign to ALL-Link Group	AA BB CC 02 39 C2 8B 01 01
---------------------------------	----------------------------

The above example is the command an On/Off Outlet sends when it goes into Linking Mode after its SET Button has been pressed and held for about 3 seconds. The To Address contains the Device Category (0x02), Device Subcategory (0x39), and Firmware Revision (0xC2). Command 2 contains the Hardware Revision (0x01).

Docklight Example:

02 50 1A CE D1 02 39 C2 8B 01 00 STD INSTEON RX

Success Report

This command is sent at the end of a group broadcast.

Command Name	Success Report
Message Length	Standard Message (SD)
Message Type	Broadcast
To Address (Hi Byte)	Cmd1 being cleaned up
To Address (Mid Byte)	Number of devices to be cleaned up
To Address (Low Byte)	Group number
Command 1	0x06
Command 2	Number of failed cleanups

Command Example:

Success Report	AA BB CC 11 02 01 CB 06 01
-----------------------	----------------------------

The above example is the message an On/Off Outlet sends out after a group broadcast. The To Address contains the Cmd1 being cleaned up (0x11), number of devices to be cleaned up (0x02), and the group number (0x01). Command 2 contains the number of failed cleanups (0x01)

Docklight Example:

```
02 50 21 7D B9 11 02 01 CB 06 00 INSTEON STD RX
Cleanup Report Zero Error Example (Cmd1=0x11, 2 Devices in Group, Group 1)
02 50 21 7D B9 11 02 01 CB 06 00 INSTEON STD RX
Cleanup Report Zero Error Example (Cmd1=0x11, 2 Devices in Group, Group 1)

02 50 21 7D B9 11 02 01 CB 06 01 INSTEON STD RX
Cleanup Report One Error Example (Cmd1=0x11, 2 Devices in Group, Group 1)
02 50 21 7D B9 11 02 01 CB 06 01 INSTEON STD RX
Cleanup Report One Error Example (Cmd1=0x11, 2 Devices in Group, Group 1)
```

Messages Sent To – On/Off Outlet

INSTEON Engine Version

This command requests the INSTEON Engine version of the device.

Command Name	INSTEON Engine Version
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x0D
Command 2	0x00

Command Name	INSTEON Engine Version Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x0D
Command 2	0x02 (Indicates i2CS engine version)

Command Example:

INSTEON Engine Version	AA BB CC 11 22 33 0F 0D 00
INSTEON Engine Version Response	11 22 33 AA BB CC 2B 0D 02

The above example device 11 22 33 is asked what its Engine Version is (0x0D 0x00). Device 11 22 33 then responds back that it has an i2CS engine version (0x02).

Docklight Example:

```
9/24/2013 13:35:39.123 [RX] - 02 62 21 7D B9 0F 0D 00 06 INSTEON STD TX
02 50 21 7D B9 1A 77 7B 2B 0D 02 INSTEON STD RX
i2CS Engine Version
```

Ping

This command checks that the device is able to respond over INSTEON.

Command Name	Ping
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x0F
Command 2	Ignored Value

Command Name	Ping Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x0F
Command 2	Same as what was received in Command 2

Command Example:

Ping	AA BB CC 11 22 33 0F 0F 00
Ping Response	11 22 33 AA BB CC 2B 0F 00

The above example is the communication that goes on between a Controller and the On/Off Outlet when it is sent a Ping command. The device 11 22 33 is sent a Ping Command (0x0F). The device 11 22 33 then responds back to device AA BB CC with a Ping Response of the exact same thing it received in Command 1 and Command 2.

Docklight Example:

```
9/24/2013 13:35:40.329 [TX] - 02 62 21 7D B9 0F 0F 00
9/24/2013 13:35:40.355 [RX] - 02 62 21 7D B9 0F 0F 00 06 INSTEON STD TX
02 50 21 7D B9 1A 77 7B 2B 0F 00 INSTEON STD RX
Ping Response
```

ID Request

This command asks for the device's Device category, Device Subcategory, Firmware Revision, and Hardware Revision. It is the same info the device sends when it goes into Linking Mode.

Command Name	ID Request
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x10
Command 2	Ignored Value

Command Name	ID Request Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x10
Command 2	Same as what was received in Command 2

Command Name	ID Request Data
Message Length	Standard Message (SD)
Message Type	Broadcast
Transmitting Device ID	On/Off Outlet
To Address (Hi Byte)	Device Category
To Address (Mid Byte)	Device Subcategory
To Address (Low Byte)	Firmware Revision
Flags Byte	Message Type
Command 1	0x01
Command 2	Hardware Revision

Command Example:

ID Request	AA BB CC 11 22 33 0F 10 00
ID Request Response	11 22 33 AA BB CC 2B 10 00
ID Request Data	11 22 33 02 39 C2 8B 01 00

The above example is the communication that goes on between a Controller and the On/Off Outlet when it is sent an ID Request command. The device 11 22 33 is sent an ID Request Command (0x10). The device 11 22 33 then responds back to device AA BB CC with a ID Request Response of the exact same thing it received in Command 1 and Command 2. The device 11 22 33 then responds back with the ID Request Data of Device category (0x02), Device subcategory (0x39), Firmware Revision (0xC2), and the Hardware Revision (0x00). Essentially the device sends out the exact same thing it sends out when it goes into Linking Mode without going into Linking Mode.

Docklight Example:

```

2/26/2014 17:01:57.067 [TX] - 02 62 00 00 04 0F 10 00
2/26/2014 17:01:57.082 [RX] - 02 62 00 00 04 0F 10 00 06 INSTEON STD TX
02 50 00 00 04 AA AA 01 2B 10 00 INSTEON STD RX
  ID Request
02 50 00 00 04 02 39 C2 8B 01 00 INSTEON STD RX
  Assign to ALL-Link Group/ID Request

```

ON (Top Outlet)

This command turns ON the load for the top outlet.

Command Name	ON (top outlet)
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x11
Command 2	0x01 -> 0xFF = On, 0x00 = Off

Command Name	ON (top outlet) Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x11
Command 2	Same as what was received in Command 2

Command Example:

ON (top outlet)	AA BB CC 11 22 33 0F 11 FF
ON (top outlet) Response	11 22 33 AA BB CC 2B 11 FF

The above example the On/Off Outlet is sent the command to turn the load for the top outlet to On (Command 1 = 0x11, Command 2 = 0xFF). The On/Off Outlet then responds back with the exact same message.

Docklight Example:

```
5/6/2014 10:05:25.099 [TX] - 02 62 00 00 04 0F 11 FF
5/6/2014 10:05:25.115 [RX] - 02 62 00 00 04 0F 11 FF 06 INSTEON STD TX
02 50 00 00 04 1A 77 7B 27 11 FF INSTEON STD RX
```

OFF (Top Outlet)

This command turns OFF the load for the top outlet.

Command Name	OFF (top outlet)
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x13
Command 2	Ignored Value

Command Name	OFF (top outlet) Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x13
Command 2	Same as what was received in Command 2

Command Example:

OFF (top outlet)	AA BB CC 11 22 33 0F 13 00
OFF (top outlet) Response	11 22 33 AA BB CC 2B 13 00

The above example the On/Off Outlet is sent the command to turn the load for the top outlet to Off (Command 1 = 0x13). The On/Off Outlet then responds back with the exact same message.

Docklight Example:

```

5/6/2014 12:41:36.744 [TX] - 02 62 00 00 04 0F 13 00
5/6/2014 12:41:36.770 [RX] - 02 62 00 00 04 0F 13 00 06  INSTEON STD TX
02 50 00 00 04 1A 77 7B 2B 13 00  INSTEON STD RX
Light OFF

```

ON (Bottom Outlet)

This command turns ON the load for the bottom outlet

Command Name	ON (bottom outlet)
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x11
Command 2	0x01 -> 0xFF = On, 0x00 = Off
Data 1	0x02
Data 2 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	ON (bottom outlet) Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x11
Command 2	Same as what was received in Command 2

Command Example:

ON (bottom outlet)	AA BB CC 11 22 33 1F 11 01 02 00 00 00 00 00
ON (bottom outlet) Response	00 00 00 00 00 00 00 00 00 EC 11 22 33 AA BB CC 2B 11 01

The above example device 11 22 33 is sent a command to turn the load for the bottom outlet to On (Command 1 = 0x11, Command 2 = 0x01, Data 1 = 0x02). The On/Off Outlet then responds back with the exact same data in Command 1 and Command 2.

Docklight Example:

```
5/6/2014 12:45:35.001 [TX] - 02 62 00 00 04 1F 11 01 02 00 00 00 00 00 00 00 00 00 00 EC
5/6/2014 12:45:35.022 [RX] - 02 62 00 00 04 1F 11 01 02 00 00 00 00 00 00 00 00 00 00 EC 06
INSTEON EXT TX
02 50 00 00 04 1A 77 7B 2B 11 01 INSTEON STD RX
```

OFF (Bottom Outlet)

This command turns OFF the load for the bottom outlet.

Command Name	OFF (bottom outlet)
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x13
Command 2	Ignored Value
Data 1	0x02
Data 2 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	OFF (bottom outlet) Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x13
Command 2	Same as what was received in Command 2

Command Example:

OFF (bottom outlet)	AA BB CC 11 22 33 1F 13 00 02 00 00 00 00
OFF (bottom outlet) Response	00 00 00 00 00 00 00 00 00 EB 11 22 33 AA BB CC 2B 13 00

The above example the On/Off Outlet is sent the command to turn the load for the bottom outlet to Off (Command 1 = 0x13, and Data 1 = 0x02). The On/Off Outlet then responds back with the exact same message in Command 1 and Command 2.

Docklight Example:

```
5/6/2014 12:45:38.729 [TX] - 02 62 00 00 04 1F 13 00 02 00 00 00 00 00 00 00 00 00 00 EB
5/6/2014 12:45:38.750 [RX] - 02 62 00 00 04 1F 13 00 02 00 00 00 00 00 00 00 00 00 00 EB 06
INSTEON EXT TX
02 50 00 00 04 1A 77 7B 2B 13 00 INSTEON STD RX
```

Direct Group On

This command is a Group On message that is sent directly to the device.

Command Name	Direct Group On
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x32
Command 2	Group Number: Group 1 = Top Outlet Group 2 = Bottom Outlet

Command Name	Direct Group On Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x32
Command 2	Same as what was received in Command 2

Command Example:

Direct Group On	AA BB CC 11 22 33 0F 32 02
Direct Group On Response	11 22 33 AA BB CC 2B 32 02

The above example the On/Off Outlet is sent a Direct Group 2 On command (Command 1 = 0x32, Command 2 = 0x02). The On/Off Outlet then responds back with the exact same message and the bottom outlet should turn ON.

Docklight Example:

```

6/27/2014 14:23:43.341 [TX] - 02 62 22 92 0D 0F 32 02
6/27/2014 14:23:43.357 [RX] - 02 62 22 92 0D 0F 32 02 06 INSTEON STD TX
02 50 22 92 0D 1A 77 7B 2B 32 02 INSTEON STD RX

```

Direct Group Off

This command is a Group Off message that is sent directly to the device.

Command Name	Direct Group Off
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x33
Command 2	Group Number: Group 1 = Top Outlet Group 2 = Bottom Outlet

Command Name	Direct Group Off Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x33
Command 2	Same as what was received in Command 2

Command Example:

Direct Group Off	AA BB CC 11 22 33 0F 33 01
Direct Group Off Response	11 22 33 AA BB CC 2B 33 01

The above example the On/Off Outlet is sent a Direct Group 1 Off command (Command 1 = 0x33, Command 2 = 0x01). The On/Off Outlet then responds back with the exact same message and the top outlet should turn OFF.

Docklight Example:

```
6/27/2014 14:23:59.512 [TX] - 02 62 22 92 0D 0F 33 02
6/27/2014 14:23:59.531 [RX] - 02 62 22 92 0D 0F 33 02 06 INSTEON STD TX
02 50 22 92 0D 1A 77 7B 2B 33 02 INSTEON STD RX
```

Status Request

This command asks the device for the current On-Level of the top outlet and its Database Delta.

Command Name	Status Request
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x19
Command 2	0x00

Command Name	Status Request Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Configuration Byte	Message Type
Command 1	Database Delta
Command 2	Current On-Level of Top Outlet

Command Example:

Status Request	AA BB CC 11 22 33 0F 19 00
Status Request Response	11 22 33 AA BB CC 2B 01 FF

The above example device 11 22 33 is sent a command that asks it for its Status (Command 1 = 0x19, Command 2 = 0x00). Device 11 22 33 then responds back with its Status in Command 1 (0x01 = Database Delta is 1) and Command 2 (0xFF = Top Outlet is On).

Docklight Example:

```

5/5/2014 16:05:15.772 [TX] - 02 62 00 00 04 0F 19 00
5/5/2014 16:05:15.788 [RX] - 02 62 00 00 04 0F 19 00 06 INSTEON STD TX
  Status Request
02 50 00 00 04 1A 77 7B 2B 00 FF INSTEON STD RX

5/5/2014 16:05:23.533 [TX] - 02 62 00 00 04 0F 19 00
5/5/2014 16:05:23.562 [RX] - 02 62 00 00 04 0F 19 00 06 INSTEON STD TX
  Status Request
02 50 00 00 04 1A 77 7B 27 01 00 INSTEON STD RX

```

Status Request 2

This command asks the device for the current On-Level of both outlets and its Database Delta.

Command Name	Status Request 2
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x19
Command 2	0x01

Command Name	Status Request 2 Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Configuration Byte	Message Type
Command 1	Database Delta
Command 2	Current On-Level of both outlets: 0x00 = Both Outlets Off 0x01 = Only Top Outlet On 0x02 = Only Bottom Outlet On 0x03 = Both Outlets On

Command Example:

Status Request 2	AA BB CC 11 22 33 0F 19 01
Status Request 2 Response	11 22 33 AA BB CC 2B 03 03

The above example device 11 22 33 is sent a command that asks it for its Status (Command 1 = 0x19, Command 2 = 0x01). Device 11 22 33 then responds back with its Status in Command 1 (0x01 = Database Delta is 3) and Command 2 (0x03 = Both Outlets On).

Docklight Example:

```

5/7/2014 10:48:00.993 [TX] - 02 62 00 00 04 0F 19 01
5/7/2014 10:48:01.013 [RX] - 02 62 00 00 04 0F 19 01 06 INSTEON STD TX
02 50 00 00 04 1A 77 7B 2B 03 03 INSTEON STD RX

```

Read Configuration Byte

This command asks the device for its Configuration Byte.

Command Name	Read Configuration Byte
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x1F
Command 2	0x00

Command Name	Read Configuration Byte Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Configuration Byte	Message Type
Command 1	0x1F
Command 2	Configuration Byte: bit 0 = Programming Lock On/ Off bit 1 = LED Blink On/ Off on TX bit 2 = LoadSense 2 On/ Off bit 3 = LoadSense On/ Off bit 4 = LED On /Off bit 5 = Keybeep On/ Off bit 6 = RF On /Off bit 7 = Powerline On /Off (0x00 is the default Config Byte. Default settings are in Bold.)

Command Example:

Read Configuration Byte	AA BB CC 11 22 33 0F 1F 00
Read Configuration Byte Response	11 22 33 AA BB CC 2B 1F 00

The above example device 11 22 33 is sent a command that asks it for its Configuration Byte (Command 1 = 0x1F, Command 2 = 0x00). Device 11 22 33 then responds back with its Configuration Byte (0x00). This means that device 11 22 33 has Programming Lock Off, LED Blink on TX Off, LoadSense 2 Off, LoadSense Off, LED On, Keybeep Off, RF On, and Powerline On.

Docklight Example:

```
2/27/2014 13:51:36.916 [TX] - 02 62 00 00 04 0F 1F 00
2/27/2014 13:51:36.940 [RX] - 02 62 00 00 04 0F 1F 00 06 INSTEON STD TX
  Read Operating Flags 1
02 50 00 00 04 AA AA 01 2B 1F 00 INSTEON STD RX
```

Database Delta

This command asks the device for its current Database Delta Number. The Database Delta increments with any database write. The Database Delta is cleared on power cycle.

Command Name	Database Delta
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x1F
Command 2	0x01

Command Name	Database Delta Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x1F
Command 2	Database Delta

Command Example:

Database Delta	AA BB CC 11 22 33 0F 1F 01
Database Delta Response	11 22 33 AA BB CC 2B 1F 03

The above example device 11 22 33 is sent a command that asks it for its Database Delta (Command 1 = 0x1F, Command 2 = 0x01). Device 11 22 33 then responds back with its Database Delta (0x03). This means that device 11 22 33 has had three Database writes since its last power cycle.

Docklight Example:

```
9/13/2013 10:21:54.135 [TX] - 02 62 29 70 02 0F 1F 01
9/13/2013 10:21:54.161 [RX] - 02 62 29 70 02 0F 1F 01 06 INSTEON STD TX
                                02 50 29 70 02 1A 77 7B 2B 1F 01 INSTEON STD RX Database Delta
```

Beep

This command will beep the On/Off Outlet beeper once.

Command Name	Beep
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x30
Command 2	0x01

Command Name	Beep Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x30
Command 2	0x01

Command Example:

Beep	AA BB CC 11 22 33 0F 30 01
Beep Response	11 22 33 AA BB CC 2B 30 01

The above example device 11 22 33 is sent a command that asks it to beep once (Command 1 = 0x30, Command 2 = 0x01). Device 11 22 33 then responds back with the exact same data in Command 1 and Command 2 (Command 1 = 0x30, Command 2 = 0x01). The device should also beep once as well.

Docklight Example:

```

3/12/2013 16:18:43.155 [TX] - 02 62 1A CE D1 0F 30 01
3/12/2013 16:18:43.163 [RX] - 02 62 1A CE D1 0F 30 01 06 INSTEON STD TX
3/12/2013 16:18:43.467 [RX] - 02 50 1A CE D1 14 84 E2 2B 30 01 STD INSTEON RX

```

Remote Enter Linking Mode

This command puts the device into Linking Mode

Command Name	Remote Enter Linking Mode
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x09
Command 2	Group Number
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Remote Enter Linking Mode Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x09
Command 2	Same as what was received in Command 2

Command Name	Assign to ALL-Link Group
Message Length	Standard Message (SD)
Message Type	Broadcast
Transmitting Device ID	On/Off Outlet
To Address (Hi Byte)	Device Category
To Address (Mid Byte)	Device Subcategory
To Address (Low Byte)	Firmware Revision
Flags Byte	Message Type
Command 1	0x01
Command 2	Hardware Revision

Command Example:

Remote Enter Linking Mode	AA BB CC 11 22 33 1F 09 01 00 00 00 00
Remote Enter Linking Mode Response	00 00 00 00 00 00 00 00 00 00 F6
Assign to ALL-Link Group	11 22 33 AA BB CC 2B 09 01
	11 22 33 02 39 C2 8B 01 00

The above example, device 11 22 33 is sent a command that tells it to go into Linking Mode (0x09) and to link to Group 1(0x01). Device 11 22 33 will ACK the command and then goes into Linking Mode.

Docklight Example:

```

3/3/2014 10:02:01.224 [TX] - 02 62 00 00 04 1F 09 01 00 00 00 00 00 00 00 00 00 00 00 00 F6
3/3/2014 10:02:01.246 [RX] - 02 62 00 00 04 1F 09 01 00 00 00 00 00 00 00 00 00 00 00 00 F6 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 09 01 INSTEON STD RX
Remote Enter Linking Mode

```

Remote Exit Linking Mode

This command tells the device to exit linking mode.

Command Name	Remote Exit Linking Mode
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x08
Command 2	Ignored Value

Command Name	Remote Exit Linking Mode Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x08
Command 2	Same as what was received in Command 2

Command Example:

Remote Exit Linking Mode	AA BB CC 11 22 33 1F 08 00
Remote Exit Linking Mode Response	11 22 33 AA BB CC 2B 08 00

The above example device 11 22 33 is sent a command that tells it to exit Linking Mode (0x08).

Docklight Example:

```
1/30/2014 11:53:13.594 [TX] - 02 62 1A CB 70 0F 08 01
1/30/2014 11:53:13.615 [RX] - 02 62 1A CB 70 0F 08 01 06 INSTEON STD TX
1/30/2014 11:53:13.913 [RX] - 02 50 1A CB 70 AA AA 01 2B 08 01 STD INSTEON RX
```

Remote Enter UnLinking Mode

This command tells the device to enter unlinking mode.

Command Name	Remote Enter UnLinking Mode
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x0A
Command 2	Group Number

Command Name	Remote Enter UnLinking Mode Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x0A
Command 2	Same as what was received in Command 2

Command Name	Set Button Held
Message Length	Standard Message (SD)
Message Type	Broadcast
Transmitting Device ID	On/Off Outlet
To Address (Hi Byte)	Device Category
To Address (Mid Byte)	Device Subcategory
To Address (Low Byte)	Firmware Revision
Flags Byte	Message Type
Command 1	0x01
Command 2	Hardware Revision

Command Example:

Remote Enter UnLinking Mode	AA BB CC 11 22 33 1F 0A 01
Remote Enter UnLinking Mode Response	11 22 33 AA BB CC 2B 0A 01
Set Button Held	11 22 33 10 0A DC 8B 01 00

The above example, device 11 22 33 is sent a command that tells it to go into UnLinking Mode (0x0A) and to unlink from Group 1(0x01). Device 11 22 33 will ACK the command and then goes into UnLinking Mode.

Docklight Example:

```

1/30/2014 11:53:09.648 [TX] - 02 62 1A CB 70 0F 0A 01
1/30/2014 11:53:09.674 [RX] - 02 62 1A CB 70 0F 0A 01 06 INSTEON STD TX

1/30/2014 11:53:09.962 [RX] - 02 50 1A CB 70 AA AA 01 2B 0A 01 STD INSTEON RX

1/30/2014 11:53:10.154 [RX] - 02 50 1A CB 70 10 0A DC 8B 01 00 STD INSTEON RX

```

Programming Lock On

This command tells disables the ability of the device to go into Linking Mode.

Command Name	Programming Lock On
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x00
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Programming Lock On Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x00

Command Example:

Programming Lock On	AA BB CC 11 22 33 1F 20 00 00 00 00 00 00 00
Programming Lock On Response	00 00 00 00 00 00 00 00 00 E0 11 22 33 AA BB CC 2B 20 00

The above example device 11 22 33 is sent a command that disables the ability to go into Linking Mode (0x20 0x00).

Docklight Example:

```
9/19/2013 10:44:40.362 [TX] - 02 62 29 70 02 1F 20 00 00 00 00 00 00 00 00 00 00 00 00 E0
9/19/2013 10:44:40.378 [RX] - 02 62 29 70 02 1F 20 00 00 00 00 00 00 00 00 00 00 00 00 E0
                                06 INSTEON EXT TX
                                02 50 29 70 02 1A 77 7B 2B 20 00 INSTEON STD RX Set Operating
                                Flags (Programming Lock On)
```

Programming Lock Off

This command enables the ability of the device to go into Linking Mode.

Command Name	Programming Lock Off
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x01
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Programming Lock Off Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x01

Command Example:

Programming Lock Off	AA BB CC 11 22 33 1F 20 01 00 00 00 00 00 00
Programming Lock Off Response	00 00 00 00 00 00 00 00 00 DF 11 22 33 AA BB CC 2B 20 01

The above example device 11 22 33 is sent a command that enables the ability to go into Linking Mode (0x20 0x01).

Docklight Example:

```
9/18/2013 18:13:37.279 [TX] - 02 62 29 70 02 1F 20 01 00 00 00 00 00 00 00 00 00 00 DF
9/18/2013 18:13:37.291 [RX] - 02 62 29 70 02 1F 20 01 00 00 00 00 00 00 00 00 00 00 DF
06 INSTEON EXT TX
02 50 29 70 02 1A 77 7B 2B 20 01 INSTEON STD RX Set Operating Flags (Programming Lock Off)
```

LED Blink on Traffic On

This command enables the feature of the LED blinking on traffic.

Command Name	LED Blink on Traffic On
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x02
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	LED Blink on Traffic On Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x02

Command Example:

LED Blink on Traffic On	AA BB CC 11 22 33 1F 20 02 00 00 00 00 00 00
LED Blink on Traffic On Response	00 00 00 00 00 00 00 00 00 DE 11 22 33 AA BB CC 2B 20 02

The above example device 11 22 33 is sent a command that enables LED blinking on traffic (0x20 0x02).

Docklight Example:

```

2/5/2014 14:07:46.855 [TX] - 02 62 1A CB 70 1F 20 02 00 00 00 00 00 00 00 00 00 00 00 DE
2/5/2014 14:07:46.877 [RX] - 02 62 1A CB 70 1F 20 02 00 00 00 00 00 00 00 00 00 00 00 DE 06
INSTEON EXT TX

```

```

2/5/2014 14:07:47.404 [RX] - 02 50 1A CB 70 AA AA 01 2B 20 02 STD INSTEON RX

```

LED Blink on Traffic Off

This command disables the feature of the LED blinking on traffic.

Command Name	LED Blink on Traffic Off
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x03
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	LED Blink on Traffic Off Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x03

Command Example:

LED Blink on Traffic Off	AA BB CC 11 22 33 1F 20 03 00 00 00 00 00 00
LED Blink on Traffic Off Response	00 00 00 00 00 00 00 00 DD 11 22 33 AA BB CC 2B 20 03

The above example device 11 22 33 is sent a command that disables LED Blink on Traffic (0x20 0x03).

Docklight Example:

```

2/5/2014 14:07:48.238 [TX] - 02 62 1A CB 70 1F 20 03 00 00 00 00 00 00 00 00 00 00 DD
2/5/2014 14:07:48.252 [RX] - 02 62 1A CB 70 1F 20 03 00 00 00 00 00 00 00 00 00 00 DD 06
INSTEON EXT TX

2/5/2014 14:07:48.780 [RX] - 02 50 1A CB 70 AA AA 01 2B 20 03 STD INSTEON RX

```

Load Sense On (Bottom Outlet)

This command enables the load sense feature for the bottom outlet.

Command Name	Load Sense On (Bottom Outlet)
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x04
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Load Sense On (Bottom Outlet) Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x04

Command Example:

Load Sense On (Bottom Outlet)	AA BB CC 11 22 33 1F 20 04 00 00 00 00 00 00 00 00 00 00 00 00 DC
Load Sense On (Bottom Outlet) Response	11 22 33 AA BB CC 2B 20 04

The above example device 11 22 33 is sent a command that enables Load Sense on the bottom outlet (0x20 0x04).

Docklight Example:

```
2/5/2014 14:07:46.855 [TX] - 02 62 1A CB 70 1F 20 04 00 00 00 00 00 00 00 00 00 00 00 00 00 DC
2/5/2014 14:07:46.877 [RX] - 02 62 1A CB 70 1F 20 04 00 00 00 00 00 00 00 00 00 00 00 00 00 DC 06
INSTEON EXT TX

2/5/2014 14:07:47.404 [RX] - 02 50 1A CB 70 AA AA 01 2B 20 04 STD INSTEON RX
```

Load Sense Off (Bottom Outlet)

This command disables the load sense feature for the bottom outlet.

Command Name	Load Sense Off (Bottom Outlet)
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x05
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Load Sense Off (Bottom Outlet) Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x05

Command Example:

Load Sense Off (Bottom Outlet)	AA BB CC 11 22 33 1F 20 05 00 00 00 00 00 00 00 00 00 00 00 00 DB
Load Sense Off (Bottom Outlet) Response	11 22 33 AA BB CC 2B 20 05

The above example device 11 22 33 is sent a command that disables Load Sense on the bottom outlet (0x20 0x05).

Docklight Example:

```

2/5/2014 14:07:48.238 [TX] - 02 62 1A CB 70 1F 20 05 00 00 00 00 00 00 00 00 00 00 00 00 00 DB
2/5/2014 14:07:48.252 [RX] - 02 62 1A CB 70 1F 20 05 00 00 00 00 00 00 00 00 00 00 00 00 DB 06
INSTEON EXT TX

2/5/2014 14:07:48.780 [RX] - 02 50 1A CB 70 AA AA 01 2B 20 05 STD INSTEON RX

```

Load Sense On (Top Outlet)

This command enables the load sense feature for the top outlet.

Command Name	Load Sense On (Top Outlet)
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x06
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Load Sense On (Top Outlet) Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x06

Command Example:

Load Sense On (Top Outlet)	AA BB CC 11 22 33 1F 20 06 00 00 00 00 00 00 00 00 00 00 00 00 00 00 DA
Load Sense On (Top Outlet) Response	11 22 33 AA BB CC 2B 20 06

The above example device 11 22 33 is sent a command that enables Load Sense on the top outlet (0x20 0x06).

Docklight Example:

```
2/5/2014 14:07:46.855 [TX] - 02 62 1A CB 70 1F 20 06 00 00 00 00 00 00 00 00 00 00 00 00 00 DA
2/5/2014 14:07:46.877 [RX] - 02 62 1A CB 70 1F 20 06 00 00 00 00 00 00 00 00 00 00 00 00 00 DA 06
INSTEON EXT TX

2/5/2014 14:07:47.404 [RX] - 02 50 1A CB 70 AA AA 01 2B 20 06 STD INSTEON RX
```

Load Sense Off (Top Outlet)

This command disables the load sense feature for the top outlet.

Command Name	Load Sense Off (Top Outlet)
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x07
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Load Sense Off (Top Outlet) Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x07

Command Example:

Load Sense Off (Top Outlet)	AA BB CC 11 22 33 1F 20 07 00 00 00 00 00 00 00 00 D9
Load Sense Off (Top Outlet) Response	11 22 33 AA BB CC 2B 20 07

The above example device 11 22 33 is sent a command that disables Load Sense on the top outlet (0x20 0x07).

Docklight Example:

```
2/5/2014 14:07:48.238 [TX] - 02 62 1A CB 70 1F 20 07 00 00 00 00 00 00 00 00 00 00 00 D9
2/5/2014 14:07:48.252 [RX] - 02 62 1A CB 70 1F 20 07 00 00 00 00 00 00 00 00 00 00 00 D9 06
INSTEON EXT TX

2/5/2014 14:07:48.780 [RX] - 02 50 1A CB 70 AA AA 01 2B 20 07 STD INSTEON RX
```

LED Off

This command disables the LED (except for Linking and Unlinking Mode Status)

Command Name	LED Off
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x08
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	LED Off Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x08

Command Example:

LED Off	AA BB CC 11 22 33 1F 20 08 00 00 00 00 00 00
LED Off Response	00 00 00 00 00 00 00 00 00 D8 11 22 33 AA BB CC 2B 20 08

The above example device 11 22 33 is sent a command that disables the LED, except for Linking and UnLinking Mode status (0x20 0x08).

Docklight Example:

```

3/3/2014 10:33:08.798 [TX] - 02 62 00 00 04 1F 20 08 00 00 00 00 00 00 00 00 00 00 00 00 D8
3/3/2014 10:33:08.812 [RX] - 02 62 00 00 04 1F 20 08 00 00 00 00 00 00 00 00 00 00 00 00 D8 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 08 INSTEON STD RX
LED Off

```

LED On

This command enables the LED

Command Name	LED On
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x09
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	LED On Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x09

Command Example:

LED On	AA BB CC 11 22 33 1F 20 09 00 00 00 00 00 00
LED On Response	00 00 00 00 00 00 00 00 00 D7 11 22 33 AA BB CC 2B 20 09

The above example device 11 22 33 is sent a command that enables the LED (0x20 0x09).

Docklight Example:

```

3/3/2014 10:33:13.966 [TX] - 02 62 00 00 04 1F 20 09 00 00 00 00 00 00 00 00 00 00 D7
3/3/2014 10:33:13.980 [RX] - 02 62 00 00 04 1F 20 09 00 00 00 00 00 00 00 00 00 00 D7 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 09 INSTEON STD RX
LED On

```

Keybeep On

This command enables a beep on any key press.

Command Name	Keybeep On
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x0A
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Keybeep On Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x0A

Command Example:

Keybeep On	AA BB CC 11 22 33 1F 20 0A 00 00 00 00 00 00
Keybeep On Response	00 00 00 00 00 00 00 00 00 D6 11 22 33 AA BB CC 2B 20 0A

The above example device 11 22 33 is sent a command that enables a beep on any key press (0x20 0x0A).

Docklight Example:

```

3/3/2014 10:46:26.289 [TX] - 02 62 00 00 04 1F 20 0A 00 00 00 00 00 00 00 00 00 00 00 00 D6
3/3/2014 10:46:26.310 [RX] - 02 62 00 00 04 1F 20 0A 00 00 00 00 00 00 00 00 00 00 00 00 D6 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 0A INSTEON STD RX
KeyBeep On

```

Keybeep Off

This command disables a beep on any key press.

Command Name	Keybeep Off
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x0B
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Keybeep Off Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x0B

Command Example:

Keybeep Off	AA BB CC 11 22 33 1F 20 0B 00 00 00 00 00
Keybeep Off Response	00 00 00 00 00 00 00 00 D5 11 22 33 AA BB CC 2B 20 0B

The above example device 11 22 33 is sent a command that disables a beep on any keypress (0x20 0x0B).

Docklight Example:

```

3/3/2014 10:46:36.162 [TX] - 02 62 00 00 04 1F 20 0B 00 00 00 00 00 00 00 00 00 00 00 00 D5
3/3/2014 10:46:36.180 [RX] - 02 62 00 00 04 1F 20 0B 00 00 00 00 00 00 00 00 00 00 00 00 D5 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 0B INSTEON STD RX
KeyBeep Off

```

This command disables all RF capabilities as an originator, device will still hop messages.

Command Name	RF Off Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x0C

RF Off	AA BB CC 11 22 33 1F 20 0C 00 00 00 00 00
RF Off Response	00 00 00 00 00 00 00 00 D4 11 22 33 AA BB CC 2B 20 0C

Docklight Example:

```
3/3/2014 10:46:26.289 [TX] - 02 62 00 00 04 1F 20 0C 00 00 00 00 00 00 00 00 00 00 00 D4  
3/3/2014 10:46:26.310 [RX] - 02 62 00 00 04 1F 20 0C 00 00 00 00 00 00 00 00 00 00 00 D4 06  
INSTEON EXT TX  
02 50 00 00 04 AA AA 01 2B 20 0C INSTEON STD RX
```

RF On

This command enables RF communication.

Command Name	RF On
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x0D
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	RF On Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x0D

Command Example:

RF On	AA BB CC 11 22 33 1F 20 0D 00 00 00 00 00 00
RF On Response	00 00 00 00 00 00 00 00 00 D3 11 22 33 AA BB CC 2B 20 0D

The above example device 11 22 33 is sent a command that enables RF (0x20 0x0D).

Docklight Example:

```
3/3/2014 10:46:36.162 [TX] - 02 62 00 00 04 1F 20 0D 00 00 00 00 00 00 00 00 00 00 00 00 D3
3/3/2014 10:46:36.180 [RX] - 02 62 00 00 04 1F 20 0D 00 00 00 00 00 00 00 00 00 00 00 00 D3 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 0D INSTEON STD RX
```

Powerline Off

This command disables powerline communication. On power cycle powerline will turn back On.

Command Name	Powerline Off
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x0E
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Powerline Off Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x0E

Command Example:

Powerline Off	AA BB CC 11 22 33 1F 20 0E 00 00 00 00 00 00
Powerline Off Response	00 00 00 00 00 00 00 00 00 D2 11 22 33 AA BB CC 2B 20 0E

The above example device 11 22 33 is sent a command that disables powerline (0x20 0x0E).

Docklight Example:

```

3/3/2014 10:46:26.289 [TX] - 02 62 00 00 04 1F 20 0E 00 00 00 00 00 00 00 00 00 00 00 00
3/3/2014 10:46:26.310 [RX] - 02 62 00 00 04 1F 20 0E 00 00 00 00 00 00 00 00 00 00 00 D2 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 0E INSTEON STD RX

```

Powerline On

This command enables powerline communication.

Command Name	Powerline On
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x0F
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Powerline On Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x0F

Command Example:

Powerline On	AA BB CC 11 22 33 1F 20 0F 00 00 00 00 00
Powerline On Response	00 00 00 00 00 00 00 00 D1 11 22 33 AA BB CC 2B 20 0F

The above example device 11 22 33 is sent a command that disables a beep on any keypress (0x20 0x0F).

Docklight Example:

```
3/3/2014 10:46:36.162 [TX] - 02 62 00 00 04 1F 20 0F 00 00 00 00 00 00 00 00 00 00 00 D1  
3/3/2014 10:46:36.180 [RX] - 02 62 00 00 04 1F 20 0F 00 00 00 00 00 00 00 00 00 00 00 D1 06  
INSTEON EXT TX  
02 50 00 00 04 AA AA 01 2B 20 0F INSTEON STD RX
```

Read Configuration Byte 2

This command asks the device for its Configuration Byte 2.

Command Name	Read Configuration Byte 2
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x1F
Command 2	0x05

Command Name	Read Configuration Byte 2 Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Configuration Byte	Message Type
Command 1	0x1F
Command 2	Configuration Byte: bit 0 = Reserved for Internal Use bit 1 = No X10 On/Off bit 2 = Error Blink On/Off bit 3 = Cleanup Report On/Off bit 4 = Lock Buttons On/Off bit 5 = Reserved for Internal Use bit 6 = Smart Hops On/Off bit 7 = Reserved for Internal Use (0x0D is the default Config Byte. Default settings are in Bold.)

Command Example:

Read Configuration Byte 2	AA BB CC 11 22 33 0F 1F 05
Read Configuration Byte 2 Response	11 22 33 AA BB CC 2B 1F 0D

The above example device 11 22 33 is sent a command that asks it for its Configuration Byte 2 (Command 1 = 0x1F, Command 2 = 0x05). Device 11 22 33 then responds back with its Configuration Byte (0x0D). This means that device 11 22 33 has Error Blink On, Cleanup Report On, Lock Buttons Off, and Smart Hops On.

Docklight Example:

```
5/6/2014 11:07:15.931 [TX] - 02 62 00 00 04 0F 1F 05
5/6/2014 11:07:15.950 [RX] - 02 62 00 00 04 0F 1F 05 06 INSTEON STD TX
  Read Operating Flags 2
02 50 00 00 04 1A 77 7B 2B 1F 0D INSTEON STD RX
```

X10 Off

This command disables X10 communication

Command Name	X10 Off
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x12
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	X10 Off Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x12

Command Example:

X10 Off	AA BB CC 11 22 33 1F 20 12 00 00 00 00 00 00
X10 Off Response	00 00 00 00 00 00 00 00 00 CE 11 22 33 AA BB CC 2B 20 12

The above example device 11 22 33 is sent a command that disables X10 communication (0x20 0x12).

Docklight Example:

```

3/3/2014 10:46:26.289 [TX] - 02 62 00 00 04 1F 20 12 00 00 00 00 00 00 00 00 00 00 00 CE
3/3/2014 10:46:26.310 [RX] - 02 62 00 00 04 1F 20 12 00 00 00 00 00 00 00 00 00 00 00 CE 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 12 INSTEON STD RX

```

X10 On

This command enables X10 communication

Command Name	X10 On
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x13
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	X10 On Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x13

Command Example:

X10 On	AA BB CC 11 22 33 1F 20 13 00 00 00 00 00
X10 On Response	00 00 00 00 00 00 00 00 00 CD 11 22 33 AA BB CC 2B 20 13

The above example device 11 22 33 is sent a command that enables X10 communication (0x20 0x13).

Docklight Example:

```

3/3/2014 10:46:36.162 [TX] - 02 62 00 00 04 1F 20 13 00 00 00 00 00 00 00 00 00 00 00 00 CD
3/3/2014 10:46:36.180 [RX] - 02 62 00 00 04 1F 20 13 00 00 00 00 00 00 00 00 00 00 00 00 CD 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 13 INSTEON STD RX

```

Error Blink Off

This command disables the Error Blink feature.

Command Name	Error Blink Off
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x14
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Error Blink Off Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x14

Command Example:

Error Blink Off	AA BB CC 11 22 33 1F 20 14 00 00 00 00 00 00
Error Blink Off Response	00 00 00 00 00 00 00 00 00 CC 11 22 33 AA BB CC 2B 20 14

The above example device 11 22 33 is sent a command that disables Error Blink (0x20 0x14).

Docklight Example:

```

3/3/2014 10:46:26.289 [TX] - 02 62 00 00 04 1F 20 14 00 00 00 00 00 00 00 00 00 00 00 CC
3/3/2014 10:46:26.310 [RX] - 02 62 00 00 04 1F 20 14 00 00 00 00 00 00 00 00 00 00 00 CC 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 14 INSTEON STD RX

```

Error Blink On

This command enables the Error Blink feature.

Command Name	Error Blink On
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x15
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Error Blink On Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x15

Command Example:

Error Blink On	AA BB CC 11 22 33 1F 20 15 00 00 00 00 00
Error Blink On Response	00 00 00 00 00 00 00 00 00 CB 11 22 33 AA BB CC 2B 20 15

The above example device 11 22 33 is sent a command that enables Error Blink (0x20 0x15).

Docklight Example:

```

3/3/2014 10:46:36.162 [TX] - 02 62 00 00 04 1F 20 15 00 00 00 00 00 00 00 00 00 00 00 00 CB
3/3/2014 10:46:36.180 [RX] - 02 62 00 00 04 1F 20 15 00 00 00 00 00 00 00 00 00 00 00 00 CB 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 15 INSTEON STD RX

```

Cleanup Report Off

This command tells the device to disable Cleanup Reports.

Command Name	Cleanup Report Off
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x16
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Cleanup Report Off Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x16

Command Example:

Cleanup Report Off	AA BB CC 11 22 33 1F 20 16 00 00 00 00 00 00
Cleanup Report Off Response	00 00 00 00 00 00 00 00 00 CA 11 22 33 AA BB CC 2B 20 16

The above example device 11 22 33 is sent a command that disables Cleanup Reports (0x20 0x16).

Docklight Example:

```
2/5/2014 16:43:43.860 [TX] - 02 62 1A CB 70 1F 20 16 00 00 00 00 00 00 00 00 00 00 00 CA
2/5/2014 16:43:43.888 [RX] - 02 62 1A CB 70 1F 20 16 00 00 00 00 00 00 00 00 00 00 CA 06
INSTEON EXT TX
```

```
2/5/2014 16:43:44.416 [RX] - 02 50 1A CB 70 AA AA 01 2B 20 16 STD INSTEON RX
```

Cleanup Report On

This command tells the device to enable Cleanup Reports.

Command Name	Cleanup Report On
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x17
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Cleanup Report On Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x17

Command Example:

Cleanup Report On	AA BB CC 11 22 33 1F 20 17 00 00 00 00 00 00
Cleanup Report On Response	00 00 00 00 00 00 00 00 00 C9 11 22 33 AA BB CC 2B 20 17

The above example device 11 22 33 is sent a command that enables Cleanup Reports (0x20 0x17).

Docklight Example:

```
2/5/2014 16:43:45.070 [TX] - 02 62 1A CB 70 1F 20 17 00 00 00 00 00 00 00 00 00 00 C9
2/5/2014 16:43:45.088 [RX] - 02 62 1A CB 70 1F 20 17 00 00 00 00 00 00 00 00 00 00 C9 06
INSTEON EXT TX

2/5/2014 16:43:45.615 [RX] - 02 50 1A CB 70 AA AA 01 2B 20 17 STD INSTEON RX
```

Smart Hops On

This command Enables Smart Hops

Command Name	Smart Hops On
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x1C
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Smart Hops On Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x1C

Command Example:

Smart Hops On	AA BB CC 11 22 33 1F 20 1C 00 00 00 00 00 00
Smart Hops On Response	00 00 00 00 00 00 00 00 00 C4 11 22 33 AA BB CC 2B 20 1C

The above example device 11 22 33 is sent a command that enables Smart Hops, which will start the hops at the last received Ack (0x20 0x1C).

Docklight Example:

```
3/3/2014 10:46:26.289 [TX] - 02 62 00 00 04 1F 20 1C 00 00 00 00 00 00 00 00 00 00 00 00 C4
3/3/2014 10:46:26.310 [RX] - 02 62 00 00 04 1F 20 1C 00 00 00 00 00 00 00 00 00 00 00 00 C4 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 1C INSTEON STD RX
```

Smart Hops Off

This command disables Smart Hops

Command Name	Smart Hops Off
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x20
Command 2	0x1D
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Smart Hops Off Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x20
Command 2	0x1D

Command Example:

Smart Hops Off	AA BB CC 11 22 33 1F 20 1D 00 00 00 00 00
Smart Hops Off Response	00 00 00 00 00 00 00 00 C3 11 22 33 AA BB CC 2B 20 1D

The above example device 11 22 33 is sent a command that disables Smart Hops, which means the start hops will always be 1 (0x20 0x1D).

Docklight Example:

```
3/3/2014 10:46:36.162 [TX] - 02 62 00 00 04 1F 20 1D 00 00 00 00 00 00 00 00 00 00 00 C3
3/3/2014 10:46:36.180 [RX] - 02 62 00 00 04 1F 20 1D 00 00 00 00 00 00 00 00 00 00 00 C3 06
INSTEON EXT TX
02 50 00 00 04 AA AA 01 2B 20 1D INSTEON STD RX
```

Get for Group/Button

This command asks the device for its Group/Button Data

Command Name	Get for Group/Button
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	LED Bulb
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00
Data 1	0x00 -> 0xFF (Group/Button)
Data 2 – Data 14	0x00

Command Name	Get for Group/Button Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	LED Bulb
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00

Command Name	Get for Group/Button Data
Message Length	Extended Message (ED)
Message Type	Broadcast
Transmitting Device ID	LED Bulb
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00
Data 1	Same as what was received in Data 1
Data 2	0x01
Data 3 – Data 4	N/A
Data 5	X10 House Code
Data 6	X10 Unit Code
Data 7 – Data 8	N/A
Data 9	LED Brightness
Data 10 – Data 14	N/A

Command Example:

Get for Group/Button	AA BB CC 11 22 33 1F 2E 00 01 00 00 00
Get for Group/Button Response	00 00 00 00 00 00 00 00 00 00
Get for Group/Button Data	11 22 33 AA BB CC 2B 2E 00
	11 22 33 AA BB CC 11 2E 00 01 01 00 00
	20 20 1F FF 3F 00 01 00 00 00

The above example, device 11 22 33 is sent a command that asks for its Get for Group/Button Data for Group 1(0x2E 0x00 0x01). Device 11 22 33 responds back with no X10 Address (Data 5 = 0x20 and Data 6 = 0x20) and a bright LED brightness level (Data 9 = 0x3F).

Docklight Example:

```

5/6/2014 10:28:33.346 [TX] - 02 62 00 00 04 1F 2E 00 01 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
5/6/2014 10:28:33.372 [RX] - 02 62 00 00 04 1F 2E 00 01 00 00 00 00 00 00 00 00 00 00 00 00 00 00 06
INSTEON EXT TX
02 50 00 00 04 1A 77 7B 2B 2E 00 INSTEON STD RX
02 51 00 00 04 1A 77 7B 11 2E 00 01 01 00 00 20 20 1C FE 11 00 00 00 9D 01 INSTEON EXT RX
Get for Group/Button

```

Set X10 Address

This command sets the device's X10 Address

Command Name	Set X10 Address
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	LED Bulb
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00
Data 1	Group (0x01 = Top Outlet, 0x02 = Bottom Outlet)
Data 2	0x04
Data 3	House Code (0x20 = No X10 Address)
Data 4	Unit Code
Data 5 – Data 13	0x00
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Set X10 Address Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	LED Bulb
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00

Command Example:

Set X10 Address	AA BB CC 11 22 33 1F 2E 00 01 04 06 0C 00 00 00 00 00 00 00 00 00 BB
Set X10 Address Response	11 22 33 AA BB CC 2B 2E 00

The above example, device 11 22 33 is sent a command that sets the X10 Address for the top outlet to A1 (Command 1 = 0x2E, Command 2 = 0x00, Data 1 = 0x01 for Group 1, Data 2 = 0x04 which indicates we're setting the X10 Address, Data 3 = 0x06 which sets the House Code to A, and Data 4 = 0x0C which sets the Unit Code to 1).

Docklight Example:

```
5/6/2014 10:44:22.304 [TX] - 02 62 00 00 04 1F 2E 00 01 04 06 0C 00 00 00 00 00 00 00 00 00 BB
5/6/2014 10:44:22.328 [RX] - 02 62 00 00 04 1F 2E 00 01 04 06 0C 00 00 00 00 00 00 00 00 BB 06
INSTEON EXT TX
02 50 00 00 04 1A 77 7B 2B 2E 00 INSTEON STD RX
```

Set LED Brightness

This command sets the device's LED Brightness

Command Name	Set LED Brightness
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	LED Bulb
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00
Data 1	0x00
Data 2	0x07
Data 3	0x11 -> 0x7F (dimkest -> brightest)
Data 4 – Data 13	0x00
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Set LED Brightness Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	LED Bulb
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00

Command Example:

Set LED Brightness	AA BB CC 11 22 33 1F 2E 00 00 07 7F 00
Set LED Brightness Response	00 00 00 00 00 00 00 00 00 00 4C
	11 22 33 AA BB CC 2B 2E 00

The above example, device 11 22 33 is sent a command that sets its LED Brightness to Very Bright (Command 1 = 0x2E, Command 2 = 0x00, Data 1 = 0x00, Data 2 = 0x07 which indicates we're setting the LED Brightness, Data 3 = 0x7F which is the highest it can be set to).

```
5/6/2014 10:59:47.304 [TX] - 02 62 00 00 04 1F 2E 00 00 07 7F 00 00 00 00 00 00 00 00 00 00 4C
5/6/2014 10:59:47.324 [RX] - 02 62 00 00 04 1F 2E 00 00 07 7F 00 00 00 00 00 00 00 00 00 00 4C 06
INSTEON EXT TX
Set LED Brightness (High)
02 50 00 00 04 1A 77 7B 2B 2E 00 INSTEON STD RX
```

Appendix

Checksum Information

For Set Database, Set Properties and 0x20, Data14 will contain a 2s compliment of cmd1 through 2nd to last data record in the last data record.

Example of Checksum:

Message for Checksum Example	AA	BB	CC	11	22	33	1F	2E	00	01	05	FF	00
	00	00	00	00	00	00	00	00	00	00	DD		

The above example, device 11 22 33 is sent a command that requires a checksum in Data 14. The checksum is calculated by summing all the values from Command 1 to Data 13($0x2E + 0x01 + 0x05 + 0xFF = 0x133$). We then calculate the compliment of the last byte($0x33$ compliment = $0xCC$). Then we add 1($0x01$) to find the checksum for Data 14($0xCC + 0x01 = \text{checksum} = 0xCD$).

Memory Map

All-Link Database (AL /L) Overview

The AL /L starts at the top of external (serial) EEPROM and grows downward. In the INSTEON On/Off Outlet, top of memory is 0x0FFF. Each AL /L Record is 8 bytes long, so the first record starts at 0x0FF8, the second record starts at 0x0FF0, and so on down to 0x0300 for a total of 416 links. In what follows, the 3-byte INSTEON Address contained in a record is called the *Device ID* or sometimes just the *ID*. The high byte (MSB) of the Device ID is *ID2*, the middle byte is *ID1*, and the low byte (LSB) is *ID0*.

EEPROM Structure Overview

Location	Comments
0x0FF8	All-Link Database Record
0x0FF0	Ack
0x0FD8	On/Off Outlet
.....	Controller
0x0300	Last Record, 416 total links allowed
0x02xx	Addressing below 0x0300 is ignored by the database

AL /L Record Format

INSTEON On/Off Outlet AL Record Format

Database entries with Record Control Bit 6: 0 = Responder and Group 1 will control the local load.

Field	Description
Record Control	Record Control Flag Bits: Bit 7: 1 = Record is in use, 0 = Record is available Bit 6: 0 = Responder to (Slave of) Device ID Bit 5: Not Used Bit 4 & Bit 3: SmartHops (Keeps track of what the start hop should be) Bit 2: Not Used Bit 1: 1 = Record has been used before, 0 = High Water Mark Bit 0: Not Used
Group	All-Link Group Number this Device ID belongs to
ID	Device ID
Data 1	On Level
Data 2	Ramp Rate
Data 3	Not Used

To add a record to an AL /L, you search for an existing record that is marked available. (Available means the same as empty, unused or deleted.) If none is available, you create a new record at the end of the AL /L.

An unused record will have bit 7 of the *Record Control* byte set to zero. The last record in an AL /L will have bit 1 of the *Record Control* byte set to zero.

Overwriting an Empty AL /L Record

If you found an empty record, you simply overwrite it with your new record data.

Change bit 7 of the *Record Control* byte from zero to one to show that the record is now in use.

Set bit 6 of the *Record Control* byte to one if the device containing the AL /L is an INSTEON Controller of the INSTEON Responder Device whose *ID* is in the record. If instead the device containing the AL /L is an INSTEON Responder to the INSTEON Controller Device whose *ID* is in the record, then clear bit 6 of the *Record Control* byte to zero. In other words, within an AL /L, setting bit 6 means “I’m a Controller,” and clearing bit 6 means “I’m a Responder.”

Put the ALL-Link Group number in the *Group* field, and put the *Device ID* in the *ID* field. Finally, set the *Data 1*, *Data 2*, and *Data 3* fields appropriately for the *Record Class* you are storing.

Creating a New AL /L Record

To create a new record at the end of the AL /L, find the record with bit 1 of the *Record Control* byte set to zero, indicating that it is the last record in the AL /L. Flip that bit to one.

Get Database

This command asks the device for a record in its database or the entire database.

Command Name	Get Database
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00
Data 1	Ignored Value
Data 2	0x00
Data 3	0x00 -> 0xFF (Hi Byte Address)
Data 4	0x00 -> 0xFF (Lo Byte Address)
Data 5	0x00 -> 0xFF (# of Records, 0x00 dumps all records)
Data 6 – Data 14	Ignored Value

Command Name	Get Database Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00

Command Name	Get Database Data
Message Length	Extended Message (ED)
Message Type	Broadcast
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00
Data 1	0x00
Data 2	0x01
Data 3	0x00 -> 0xFF (Hi Byte Address)
Data 4	0x00 -> 0xFF (Lo Byte Address)
Data 5	0x00
Data 6	Link Type Byte: Bit 0 = 0 Bit 1 = High Water (Marks the highest record used in the database) Bit 2 = 0 Bit 3 & Bit 4 = SmartHop (Keeps track of what the start hop should be) Bit 5 = 1 Bit 6 = Controls Me=0; I Control=1 Bit 7 = Inactive=0; Active=1
Data 7	Group Number of Link
Data 8	Linked Device ID (Hi Byte)
Data 9	Linked Device ID (Mid Byte)
Data 10	Linked Device ID (Lo Byte)
Data 11	On-Level of Link
Data 12	Ramp Rate of Link
Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Empty Record
Message Length	Extended Message (ED)
Message Type	Broadcast
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00
Data 1	0x00
Data 2	0x01
Data 3	0x00 -> 0xFF (Hi Byte Address)
Data 4	0x00 -> 0xFF (Lo Byte Address)
Data 5	0x00
Data 6	0x00
Data 7	0x00
Data 8	0x00
Data 9	0x00
Data 10	0x00
Data 11	0x00
Data 12	0x00
Data 13	0x00
Data 14	Calculated Checksum (See below in Checksum Information)

Command Example:

Get Database	AA BB CC 11 22 33 1F 2F 00 00 00 00 00 00 00 00
Get Database Response	00 00 00 00 00 00 00
Get Database Data	11 22 33 AA BB CC 2B 2F 00
	11 22 33 AA BB CC 11 2F 00 00 01 0F FF 00 A2 00
	11 CC AB FF 1F 01 79
Empty Record	11 22 33 AA BB CC 11 2F 00 00 01 0F F7 00 00 00
	00 00 00 00 00 00 CA

The above example, device 11 22 33 is sent a command that asks it for its entire database (0x2F 0x00 0x00 0x00 0x00 0x00 0x00). Device 11 22 33 Acks the command then sends out its first database record (0x0F 0xFF). The next spot is an empty record so the device stops sending out its database (0x0F 0xF7).

Docklight Example:

```

9/23/2013 16:29:24.266 [TX] - 02 62 29 70 02 1F 2F 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
9/23/2013 16:29:24.279 [RX] - 02 62 29 70 02 1F 2F 00 00 00 00 00 00 00 00 00 00 00 00 00 00
                                06 INSTEON EXT TX Get Database
                                02 50 29 70 02 1A 77 7B 2B 2F 00 INSTEON STD RX
                                02 51 29 70 02 1A 77 7B 11 2F 00 00 01 0F FF 00 A2 00 11 CC AB FF
                                1F 01 79 INSTEON EXT RX
                                02 51 29 70 02 1A 77 7B 11 2F 00 00 01 0F F7 00 AA 00 1C 30 B4 00
                                1C 00 04 INSTEON EXT RX
                                02 51 29 70 02 1A 77 7B 11 2F 00 00 01 0F EF 00 AA 01 18 94 F1 00
                                1F 00 6B INSTEON EXT RX
                                02 51 29 70 02 1A 77 7B 11 2F 00 00 01 0F E7 00 AA 01 1A 77 7B 00
                                00 00 23 INSTEON EXT RX
                                02 51 29 70 02 1A 77 7B 11 2F 00 00 01 0F DF 00 00 00 00 00 00 00
                                00 00 E2 INSTEON EXT RX

```

Set Database

This command writes a record to the device's database.

Command Name	Set Database
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	On/Off Outlet
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00
Data 1	Ignored Value
Data 2	0x02
Data 3	0x00 -> 0xFF (Hi Byte Address)
Data 4	0x00 -> 0xFF (Lo Byte Address)
Data 5	0x01 -> 0x08 (# of bytes to write, over 0x08 is an error and ignored)
Data 6	
Data 7	Group Number of Link
Data 8	Linked Device ID (Hi Byte)
Data 9	Linked Device ID (Mid Byte)
Data 10	Linked Device ID (Lo Byte)
Data 11	On-Level of Link
Data 12	Ramp Rate of Link
Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Set Database Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	On/Off Outlet
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00

Command Example:

Set Database	AA BB CC 11 22 33 1F 2F 00 00 02 0F F7 08 AA 00 18 A1 C5 00 1C 00 7D
Set Database Response	11 22 33 AA BB CC 2B 2F 00

The above example, device 11 22 33 is sent a command that writes a record to its database at location 0x0F 0xF7 (0x2F 0x00 0x00 0x02 0x0F 0xF7)

Docklight Example:

```

9/24/2013 09:41:43.127 [TX] - 02 62 29 70 02 1F 2F 00 00 02 0F F7 08 AA 00 18 A1 C5 00 1C 00 7D
9/24/2013 09:41:43.146 [RX] - 02 62 29 70 02 1F 2F 00 00 02 0F F7 08 AA 00 18 A1 C5 00 1C 00 7D
06 INSTEON EXT TX Set Database
02 50 29 70 02 1A 77 7B 2B 2F 00 INSTEON STD RX

```