


Owner's Guide

Manuel de l'utilisateur



Elite Seat Guardian™ with Tablet Holder

Elite Seat Guardian™ avec support pour tablette



KEEP FOR FUTURE REFERENCE

Please read the instructions carefully before using this product.

CONSERVER POUR CONSULTATION FUTURE

Veuillez lire attentivement ces instructions avant d'utiliser ce produit.

MKTR0890
CCD-0355-000 REV 1

! IMPORTANT INFORMATION

Warning..... 3

⚙ INCLUDED PARTS

Included Parts..... 4

👉 HOW TO USE

How To Use 5

Removal 8

How To Clean 8

CUSTOMER SERVICE

Contact Us 8

! RENSEIGNEMENTS IMPORTANTS

Mise en garde 10

⚙ PIÈCES INCLUSES

Pièces incluses..... 11

👉 MODE D'EMPLOI

Mode d'emploi 12

Désinstallation 15

Entretien 15


💬 SERVICE À LA CLIENTÈLE

Contactez-nous 15

**WARNING:**


Do not leave child unattended. Inside car temperatures can rise rapidly and create a safety hazard. Children have died when left unattended inside vehicles. This is not a toy. Use for intended purpose only. Do not allow children to play with it. Always install the child safety seat in accordance to the child safety seat manufacturer's installation instructions. Adjust position of Elite Seat Guardian™ with Tablet Holder as needed to center child safety seat on Elite Seat Guardian™ with Tablet Holder.

INCLUDED PARTS




INSTALLATION


1. Unbuckle head restraint strap at top of back panel.




2. Place Elite Seat Guardian™ with Tablet Holder in center of desired seating location.



3. If vehicle is equipped with a head restraint in desired seating location, attach head restraint strap around vehicle head restraint and adjust strap length to position back panel of Elite Seat Guardian™ with Tablet Holder at desired/proper height.




NOTE: For installations in vehicles without a head restraint, the back panel may need to be folded to prevent the back panel from falling over.





INSERTING TABLET

Tablet sleeve can fit a tablet of up to 11 inches without a case.

1. Disengage the locking tab and elastic bands at the top of the tablet sleeve and pull open.



2. Insert the tablet from the top.
3. Close the tablet sleeve and secure with the elastic bands. Push in the locking tab until it locks in place.



REMOVAL

1. Remove child safety seat.
2. Unbuckle head restraint strap and remove Elite Seat Guardian™ with Tablet Holder from vehicle.
3. Store in a cool, dry place.

HOW TO CLEAN

Wipe with clean, damp cloth. Do not bleach. Air-dry. Do not machine wash or dry.

CONTACT US

If you have any questions or wish to provide comments about this product, feel free to contact our Customer Satisfaction team at **1-800-344-BABY (2229)** (Monday–Thursday 8:00am–5:00pm PST, Friday 8:00am–1:00pm PST) or visit our website at **www.munchkin.com**.


FRENCH
—
FRANÇAIS

⚠ MISE EN GARDE :

Ne pas laisser l'enfant sans surveillance. La température à l'intérieur d'un véhicule peut monter rapidement et mettre en danger ses occupants. Chaque année, des enfants meurent après avoir été laissés sans surveillance à l'intérieur d'un véhicule. Ce produit n'est pas un jouet. N'utiliser que selon l'usage prévu. Toujours installer le siège de voiture conformément aux directives du fabricant du siège de voiture. Au besoin, régler la position du protecteur Elite Seat


Guardian™ avec support pour tablette pour que le siège de voiture pour enfant soit placé en son centre sur Elite Seat Guardian™ avec support pour tablette.

PIÈCES INCLUSES




INSTALLATION


1. Détacher la sangle de fixation de l'appuie-tête, dans le haut du panneau arrière.




2. Placer le protecteur Elite Seat Guardian™ avec support pour tablette au centre du siège du véhicule.



3. Si le siège est muni d'un appuie-tête, attacher la sangle autour de celui-ci et régler la longueur de la sangle pour que le panneau arrière du protecteur Elite Seat Guardian™ avec support pour tablette soit placé à la hauteur souhaitée ou appropriée.




REMARQUE : Si le siège du véhicule n'est pas muni d'un appuie-tête, replier le panneau arrière du protecteur pour l'empêcher de glisser vers l'avant.




INSERTION DE LA TABLETTE

La pochette pour tablette convient aux tablettes allant jusqu'à 11 pouces sans étui.


1. Désengager la languette de verrouillage et les bandes élastiques situées en haut de la pochette pour tablette et tirer pour l'ouvrir.



2. Insérer la tablette par le haut.



3. Refermer la pochette pour tablette et la fixer à l'aide des bandes élastiques. Pousser la languette de verrouillage jusqu'à ce qu'elle s'enclenche.



DÉSINSTALLATION

1. Enlever le siège de voiture pour enfant.
2. Détacher la sangle de fixation de l'appuie-tête et enlever le protecteur Elite Seat Guardian™ avec support pour tablette du véhicule.
3. Le ranger dans un endroit frais et sec.

ENTRETIEN

Essuyer avec un linge humide et propre. Ne pas javelliser. Laisser sécher à l'air. Ne pas laver ni sécher en machine.

CONTACTEZ-NOUS

Si vous avez des questions ou des commentaires sur ce produit, n'hésitez pas à contacter notre équipe de satisfaction client au **1 800 344-BABY (2229)** (du lundi au jeudi de 8 h à 17 h HNP et le vendredi de 8 h à 13 h HNP) ou visitez notre site Web au **www.munchkin.com**.



munchkin.com
800.344.2229



© 2024 MUNCHKIN, INC. 7835 GLORIA AVE., VAN NUYS, CA 91406. MUNCHKIN BABY CANADA LTD., 3-8460 MOUNT PLEASANT WAY, MILTON, ON L9T 8W7.
MADE IN CHINA / FABRIQUÉ EN CHINE. WWW.MUNCHKIN.COM/PATENTS 40682-IS-2